

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.



Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CONTENTS AND SPECIFICATIONS MAY VARY FROM THOSE ILLUSTRATED.
Manufactured by

33298
TANG RONG ROAD,
CHANGPING, DONGGUAN, CHINA
All Rights Reserved.
MADE IN CHINA



Each Remote Control
ALKALINE BATTERIES RECOMMENDED.
2 "AA" BATTERIES (NOT INCLUDED)

Each Laser Battle Hunter
ALKALINE BATTERIES RECOMMENDED.
5 "AA" BATTERIES (NOT INCLUDED)

Battery Care Instruction:
Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

Safety Tips
NEVER point the infrared light at eyes!
NEVER drive your vehicle on streets!
DO NOT pick up vehicle while in motion.

Avoid collisions with wall or hard surfaces.
Keep fingers, hair and loose clothing away from tires and the wheel hubs while the vehicle is switched ON.
Adult supervision is recommended when this vehicle is being operated. To avoid accidental operation, remove all batteries when not in use. Surfaces may become hot and cause burns if electronics get wet. Do not operate Vehicle through water or snow.

BEFORE RETURNING TO STORE
PLEASE VISIT
THE CUSTOMER SERVICE WEBSITE
BELOW FOR IMMEDIATE ASSISTANCE
REGARDING QUESTIONS OR
PROBLEMS WITH THIS PRODUCT.
www.toysinquiry.com



Press FIRE button to shoot

HOW TO WIN




When hit, the Laser Battle Hunter will make an explosion sound and shake. Number of hit is indicated by how many alert sound that the vehicle made.

3 HITS TO WIN!

To reset and play again:
Press and hold the Slide Left Button, Slide Right Button and Fire Button for 3 seconds until a power-up sound is heard.

AUTONOMOUS MODE

Autonomous Mode Makes 1 Laser Battle Hunter a Moving Target for 1 minute




C Wait for the LED Light to stop flashing. Hear Beep sound. The vehicle is in Small Patrol range as the default.

D PATROL RANGES

- Small patrol range (default)
Hear 1 Beep.
- Medium patrol range
Hear 2 Beeps.
- Large patrol range
Hear 3 Beeps.

There are 3 Auto Patrol Ranges.
Small range: around 3ft (around 0.9m)
Medium range: around 9ft (around 2.73m)
Large range: around 15ft (around 4.6m)
(Vary on different surfaces)




E After selecting one of the Patrol range, then TO START (OR STOP) AUTO MODE. Press the Fire button of the Auto mode controller to start (or stop) the autonomous action. The Autonomous Laser Battle Hunter will run for 1 minute. Use your ON mode Laser Battle Hunter to shoot the Autonomous Laser Battle Hunter as many times as possible as it moves around and fires at you autonomously.



SCORING

The Autonomous Laser Battle Hunter stops after 1 minute, it will play a series of "beeps"= The number of times the Autonomous Laser Battle Hunter was hit. To play again: Hit the FIRE button of the controller of the Autonomous Laser Battle Hunter and repeat the process.

DECORATION



Use all "S" numbers for Shadow and use all "R" numbers for Reaper. Match the shape and number to the correct location.



TROUBLE SHOOTING / HINT

Problem / Question	Solution / Hint
Could not turn the controller on or it is not working properly	Most likely the batteries are too low to be usable. Insert 2 new AA Alkaline batteries. Make sure you move the ON/OFF/AUTO to either ON or AUTO position.
Could not turn the Laser Battle Hunter on or it is not working properly	Most likely the batteries are too low to be usable. Insert 5 new AA Alkaline batteries. Make sure you move the INDOOR/OFF/OUTDOOR to either INDOOR or OUTDOOR. Batteries are installed with incorrect polarities. Check the + and - markings to make sure the batteries are properly aligned.
Could not pair the controller and the Laser Battle Hunter	Get them closer. Try to pair them away from other electronic devices or an internet router and retry again.
Laser Battle Hunter's LED keeps flashing slowly and it cannot be controlled	The Laser Battle Hunter was hit 3 times and lost the battle. Press and hold the Slide Left Button, Slide Right Button and Fire Button for 3 seconds until a power-up sound is heard (refer to page 7).
No drifting	Depending on the various surface of ground. Ease of drifting on slippery surface.

QUICK TIPS

When your vehicle starts lose power, it may lose functions or performance. It's time for fresh batteries. If your vehicle gets too far away, it won't work properly. Don't drive your vehicle in sand or through water or snow or grass. Don't store your vehicle near heat or in direct sunlight. Always turn switches OFF and remove all batteries for storage.

Cleaning instruction:

To clean, wipe excess dirt from toy. Remove batteries first. Wipe toy clean with wet cloth using plain water. Then Wipe dry. DO NOT IMMERSE IN WATER and DO NOT CLEAN VEHICLE WITH ANY CHEMICALS. Let the toy completely dry before putting Batteries back into clean, dry battery compartment.

5+

WATCH INSTRUCTIONAL VIDEO
<https://vr-entertain.com>
click SUPPORT





INSTRUCTION MANUAL

START HERE


Controller

1. Turn "ON/OFF/AUTO" switch to the OFF position
2. Open the battery compartment cover by loosening the screw counter-clockwise
3. Insert 2x1.5V AA batteries (not included) following the correct polarity
4. Replace the battery compartment cover by tightening the screw clockwise



Laser Battle Hunter


1. Slide the "INDOOR / OFF / OUTDOOR" switch to the OFF position
2. Open the battery compartment cover by loosening the screw (turn counter-clockwise) and insert 5x1.5V AA batteries (not included) following the correct polarity
3. Replace the battery compartment cover and tighten the screw. (turn clockwise)



INDOOR / OFF / OUTDOOR

SYNC THE CONTROLLER



1 Turn controller on:
Slide the 'ON/OFF/AUTO' switch to the ON position.



Wait for the LED light to stop flashing. Hear power-up sound.

Repeat to sync another controller with another Laser Battle Hunter (up to 8 Laser Battle Hunters)


2 Turn the Laser Battle Hunter on:
Decide if the Laser Battle Hunter will be used indoors or outdoors. Slide the switch to either INDOOR or OUTDOOR.



NOTE: Attack range will be decreased in the INDOOR mode to minimize signal reflection

NOTE: Autonomous Drive Mode switch position
See page 8 for instructions


BASIC DRIVE / BASIC SPIN




Forward



Spin Left




Reverse



Spin Right


BASIC SLIDE



Slide Left



Slide Right




Press Left or Right Buttons




Press Left or Right Buttons


ADVANCED MOVES




Forward Left Turn



Backwards Left Turn




Forward Right Turn



Backwards Right Turn

HOW TO ATTACK



Attack Zone
Aim to the rear of opponent Laser Battle Hunter



Attack from behind



Attack from front & Sides

Turn towards your opponent to defend your Laser Battle Hunter

Infrared shooting distances vary depending on the lighting conditions the vehicles are operating in. The stronger the light (such as direct sunlight indoor or outdoor), the less the shooting range distance will be. In strong light try to get closer to take a shot to get a more powerful shot at your opponent.