此面英文版为反面

DeePoon

Deepoon VR All-In-One Headset
Getting Started Guide
www.deepoon.com
This manual's images and content may differ from the product.

1. Product Description

In The Box	Deepoon VR All-In-One Headset (M2)
	Main Head Strap & Top Head Strap
	Charger & Charging Line
	Foam Cushioning
	Earphone
	Product Instructions & Warranty Guide
	Lens Cloth
Optional Accessories	Bluetooth Gamepad
	3D Phase Sound Earphone
Screen	Samsung AMOLED 5.7"
	Image Resolution 2560x1440
CPU	Model Samsung Exynos7420
	Type 4 coreA57+4 core A53
	Craft 14nm
GPU	Type Mail T760 MP8
	Frequency MAX 772MHz
Memory	RAM 3GB LPDDR4
	ROM 32GB
	Support 128GB Micro SD(TF) Card in Maximum
Battery	Polymer lithium ion battery
	3000mAh，3.8V
	About 3 hours battery life
Sensor	Opto-sensor & Range sensor
	Gravity sensor
	Compass
	Gyroscope
Touchpad	Capacitive touch panel
FOV	96°
WIFI	2.4G & 5.8G

2. Keys & Interface Function





Button		Function Overview
Power Key		Press and hold 3 seconds: On/Off Press and hold 8 seconds: Force to restart Gently press: Standby/Wake up
Back Key		Press Longer: Back to the home interface Gently Press: Back to the previous interface
Focus Adjustment Wheel	+ -	Rotate: Make user see more clear
Touchpad		Swipe: Swipe and switch pages Tap: Make selections
Volume Key		Press to adjust the volume

Pilot Lamp Status	Function Overview
Blue Light On	Switch on/Running Properly
Green Light On	Charging completed
Red Light On	Low battery
Yellow Light On	On charging
Light Off	Power off/Standby



Interface	Description
Charging interface	Connect the charger for charging (Don't charge it when using)
Micro USB interface	Connect the computer to transfer data, support OTG to connect external devices
Headphone jack	International Standard
TF slot	Pull the plug out, insert the TF card as picture shows

3.Instructions

Installing the straps

1. Carefully Insert the hook(from the Top Head Strap) into the gap between the steel column and the shell.



2. Slide the top head strap through the loop, to the back of the Main Head Strap and use the velcro to fasten it. The velcro shoud be below the strap.



Put the device on

1. Align your face and the foam cushion and put on the device.
2. Adjust the length of the Top Head Strap and the Main Head Strap to place the device comfortably over your face.

4.Replacing the Foam Cushion

After long time using, the foam cushion might be worn out, replace it when necessary.
1.Carefully strip away the Foam Cushion from the nose area.
2.Install the Foam Cushion as it shows in the picture, and then gently press onto the device.



5.Touchpad Functions

Tapping

1. Move your head and make the cursor align to your selection.
2.Tap the touchpad with your finger.



Swiping



6.Cursor Positioning Directions

The device will identify head's movements, translate them as location information into current screen environment.



7.Selection Instructions

By moving your head and tapping on touchpad, you can choose the applications and options.
1.Rotate the head to move the cursor to the area you want to select.
2.Tap the touch pad (on the right handside of the device).



8.Tips for Viewing

1.We suggest you to take a break aftering wearing the device longer than 30 minutes, visual fatigue can be reduced.
2.Use the adjust Focus Adjustment Wheel when you find the picture not clear.
3.Please ensure the safety of the surroundings before using the device(best in a safe room), do avoid to get injuried by collision to sharp objects.



9.Network Connection Directions.

Connect the Internet for online services, games and applications.
1.Enter the system settings, get into the WiFi settings.
2.Select a network , enter the password by tapping letters and numbers from the keyboard popped up. Touchpad would be used.
3.Click “complete” and wait for the the connection to the network.

10.Health and Safety Information

Please read the following security guide before using the device, to ensure the safety and proper use.

Follow the warnings below,to prevent accidents such as fire or explosion.
-Do avoide any physical collision or damaging to the device.
-Use the charger and accessories approved by the manufacturer.
-Do not touch the device by wet hands. Do not use the device in humid places， such as bathroom or swimming pool.

Read the following warnings,to prevent personal injury or device damage.
-Do not store the device in hot or cold place. Temperature is suggested to be between 0 degree to 40 degree.
-Keep the device dry， do not use it outdoor in thunderstorming weather.
-To avoid the possibility of hearing impairment, do not use the earphone or headphone in high volume for long time.
-Not recommend to under 13 children use .The guardian should limit the using time and ensure frequent breaks for under 13 children and the over 65 elderly users.

11.Warning

-This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
-Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

The equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

12.Declaration

M2 North America edition is limited using channel 1-11. This limited operation can be only set by software and was done before the product down from the product line. All the products for North America marketing were embedded this limited before shipping.Customers have no way to choose the channel 12 & 13. Limited by local law regulations, version for North America does not have region selection option.

FCC ID：2AJPQM2
LeXiang Corporation