

Light Up Lantern Speaker

AURORA

True Wireless Compatible

FCC ID: 2AJQ7AURORA

USER MANUAL



for use with Bluetooth enabled devices

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- RF Exposure Information**
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

•DEVICE FUNCTIONS

1 Light Mode Switch
Long press : TWS connection

2 Short press : Previous song
Long press : Volume decrease

3 Short Press: Pause / Play /
Hand free Calling

4 Short press : Next song
Long press : Volume increase

5 ON/OFF Switch
Mode(s) Switch: Wireless /
FM/ TF


6 Charging port

7 LED Indicator

8 Micro SD (TF) Card Slot

9 AUX Input

10 USB Flash Drive Slot



SPECIFICATIONS	
Wireless Version / Wireless Distance	5.0 + EDR / up to 10 Metres
Output Power / Horn Type	1 x 5 Watts / 4.0 57mm
FM Frequency Range	87-108MHz
Unit Size	185*95*80mm
Power Input	DC 5V (1.0 A)
Charging Time	2 - 3 hours
Play time	up to 2-3 hours
Built-In Rechargeable Battery	3.7V / 1200mAh
Micro SD (TF) Card/USB Drive	Support up to 32GB
Multiple Functions	Wireless Play / FM Radio / USB Drive / Hands-Free Call / TF card / AUX Input / TWS Connection / LED Colorful Lights

•FM RADIO MODE INFORMATION

To use your AURORA speaker for FM Radio Mode, please follow the instructions below.

1. Turn on the [ON/OFF] button and quick press to switch to FM radio mode,
2. Press the [SCAN] button to begin scanning for channels.
3. Once you find a a desired station channel, press the [PREV] button again to save the channel.
4. Press the [VOL-] volume and [VOL+] volume buttons to change station channels.
5. If a radio frequency can't be heard, plug in the USB cord to the speaker. The cord will act as an antenna to search for stations. There is no need to plug in the other side to a USB port.

•INSTRUCTIONS

Please ensure that your device(Mobile Phone, Tablet or other devices) is paired with the Wireless Speaker to stream music wirelessly. Once it is paired, play music from your device.

Music Mode	Function	Operation buttons
Playing music	Increase Volume	Long press [VOL+] key
Playing music	Decrease Volume	Long press [VOL-] key
Playing music	Play	Short press [PLAY] key
Playing music	Pause	Short press [PLAY] key
Playing music	Previous song	Short press [PREV] key
Playing music	Next song	Short press [NEXT] key

Handsfree Mode	Function	Operation buttons
Incoming Call	Answer incoming call	Short press [CALL] key
Incoming Call	Reject incoming call	Long press [CALL] key
Incoming Call	End the Call	Short press [CALL] key
ON the line	Increase Volume	Long press [VOL+] key
ON the line	Decrease Volume	Long press [VOL-] key

•LIMITED LIFETIME WARRANTY

Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarentee of 24 months does not apply to decrease in the accumulators effective capacity caused by its use or age. Effective capacity gradually decreases depending on the method of use of the accumulator. **WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS.** For more information please visit, www.goijoy.com

Tip: Must choose the formal manufacturer certified charger, output voltage of 5v. If the product is not in use for a long time, please charge it.

QUEST USA CORP.
495 Flatbush Ave Brooklyn, NY 11225

© GOIJOY & IJOY are registered trademarks of QUEST USA CORP. All other trademarks and trade names are property of their respective owners. Designed by GOIJOY & IJOY in New York. All rights reserved QUEST USA CORP. Brooklyn, NY. Limited lifetime warranty. To activate your product warranty go to our website www.goijoy.com & register this product.

Made in China.