

FOLD

FRONT

BACK

ijoy LIP SYNC LED KARAOKE MIC & SPEAKER USER MANUAL for use with  enabled devices	ijoy Distributed by Quest USA Corp. 495 Flatbush Ave Brooklyn, NY 11225 © GOIJOY & IJOY are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOIJOY & IJOY in New York. All rights reserved Quest USA Corp. Made in Malaysia. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by QUEST USA CORP. is under license. Other trademarks and trade names are those of their respective owners.	•INSTRUCTIONS ① — Short press once for volume down; long press to play previous song. ② M Manually switch play mode, Bluetooth/TF card/U disk/FM Radio, etc. ③ + Short Press once to volume up; long press to play next song. ④ Short Press to switch the LED lighting, long press 2 seconds to turn off the LED lighting. ⑤ Long press 3 seconds to turn on/off; short press to play/ pause. ⑥ Short Press to turn on/off sound cancellation. ⑦ ⑧ ⑨ ⑩ ⑪ ⑫ ⑬ ⑭ ⑮ ⑯ ⑰	Common problems handling: 1. If the indicator is not on, please check whether the speaker power is sufficient, or plug the spekaer in 5V/1A power supply for charging, charging time is about 1to 1.5hours. 2. No sound from the microphone, maybe the power is not turned on, or the mode is not correct, or the volume is not adjusted. Please adjust the volume of the microphone. 3. If the speaker does not have reverb, the reverb switch may be off, please turn on the reverb switch. 4. If the microphone is noisy, it may be due to ambient noise, signal interference, microphone too close to the speaker, etc., please re-adjust the direction of the microphone. 5. If Bluetooth playback is interrupted, it may be because the Bluetooth is too far away, or there is an obstacle between the phone and the loud speaker, affecting the signal transmission, please close to the connected phone, avoid the obstacle. 6. If Bluetooth can not be connected, it may be because the distance is too far, there are obstacles, or by other phones connected, please close to the phone to avoid obstacles disconnect the phone. 7. If you can not charge, check whether the charger is normal, when the speaker charging, whether red indicator of the charging port is on.	•BATTERY CAUTION The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Never dissassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substance. Always confirm that the temperature is 5 degrees Celsius before you change the battery. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct sunlight or fire. Never use the battery pack in an unventilated vehicle where excessive internal temperatures may be encountered. Always keep the battery out of reach of infants and small children.	•OTHER IMPORTANT SAFETY INFORMATION Disposal of old electrical & electronic equipment (Applicable in the European Union and other European Countries with seperate collection systems.) The trash can symbol (seen on bottom right) on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over the the applicable collection point for recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the enviornment and human health which could otherwise be caused by innapropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.
•YOUR IJOY PRODUCT Thank you for purchasing and using the “IJOY LIP SYNC” wireless bluetooth speaker. This product can provide high quality listening and enjoyment for your mobile phone, computer and multimedia. Before using this product, carefully read this manual to correctly manipulate and play its best performance, Please ask your local dealer or call us if you have any questions. PACKAGE CONTENTS 1 Lip Sync LED mic & speaker 1 USB-C charging cord 1 User Manual •PAIRING YOUR PRODUCT •After turning on the speaker, it will automatically be ready to connect in Bluetooth mode. •Turn on the Bluetooth function of the device you wish to connect and search for “IJOY LIP SYNC”. From the list of found devices, select “IJOY LIP SYNC”. •IJOY LIP SYNC is now connected to your device.	•SPECIFICATIONS BT version: BT 5.3 Battery Capacity: Speaker - 600mAh, Microphone - 300mAh Playtime: up to 5 hours Battery Charging: 1-1.5H Input: DC 5V/1A Output Power: 5 W Frequency range: 90 Hz -18 KHz Power mode: DC charging and built-in Battery FCC ID: 2AJQ7LIPSYNC FCC ID: 2AJQ7LIPSYNCMIC	⑦ Long press 3 seconds to switch the microphone on/off, short press once to turn off stereo. ⑧ + Short Press to microphone volume up, double click to reverb volume up. ⑨ — Short Press to microphone volume down, double click to reverb volume down. ⑩ Long press to switch the magic sound. ⑪ Microphone indicator, blue light flashing when unconnected, blue light is always on once connected successfully, red light is on when charging, red light is off once charge full. ⑫ Microphone Type-C 5V charging port. ⑬ Headphone jack. ⑭ TF slot, insert MP3 audio class file automatically switch toTF mode. ⑮ Audio Type-C 5V charging port. ⑯ USB plug-in with MP3 audio class files automatically switch to USB mode. ⑰ Audio indicator, blue light flicker when not connected, blue light will be on when connected successfully, red light will be on when charging, red light will be off when full.	•FCC ID STATEMENT This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.	•BATTERY DISPOSAL Please do not attempt to change the battery yourself. If the battery has died and you do not want us to replace your battery, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.	IMPORTANT REMINDERS This device can ONLY be charged by 5V adapters/ USB ports only. Quick charging devices over 5V may cause heat and fire.

ATTENTION VENDOR: PLEASE FOLD ON GREEN LINES AND PRINT DOUBLE SIDED
DO NOT PRINT GREEN LINES WITH MANUAL