






USER MANUAL

©Disney
www.disney.com

• ASSEMBLE YOUR BUDDY

- Insert the prongs into the holes on top of the keyboard.



- **USE OPERATION**

- Remove the back cover. Take out the USB receiver inside the battery compartment.
- Install 1 1.5V AA Alkaline battery (not included).
- Close the battery cover.
- Plug the USB receiver to your computer's USB port, the wireless keyboard will connect automatically.

• **PACKAGE INCLUDES**

- 1X Wireless 2.4g Keyboard
- 1X Manual
- 1X USB Receiver
- BATTERIES NOT INCLUDED

• SPECIFICATIONS

- Power Supply: 1 x 1.5V AA Alkaline battery (not included)

- **FCC**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

• OTHER SAFETY INFORMATION

Disposal of old electrical & electronic equipment (Applicable in the European Union and other European Countries with separate collection systems.) The trash can symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over at the applicable collection point for recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.

- **WARNING**

1. Keep the device away from fire, water and avoid submerging the product in water to avoid explosion, leakage.
2. No one except professional technicians should attempt to disassemble the device in order to avoid damaging the product

• **BATTERY CAUTION**

The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed or in any way abnormal. Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substances. Always confirm the temperature is 41°Fahrenheit before you change the battery. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct light or fire. Always keep the battery out of the reach of infants and small children.

• **RF WARNING STATEMENT:**

For Molded Buddy wireless keyboard

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

For DISNEY MOLD WIRELESS COMPACT KEYBOARD for Dongle
This equipment complies with FCC radiation exposure limits set forth for
an uncontrolled environment.

• PRODUCT SPECIFICATIONS

Wireless 2.4g keyboard

Material: ABS

Size: 14.85" x 6.35" x 1.8" (377x161x46mm)

Weight: $\approx 615\text{g}$

⚠ WARNING: TO AVOID BATTERY LEAKAGE

- 1) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222).
- 2) Always purchase the correct size and grade of battery most suitable for intended use.
- 3) Do not mix old and new batteries, alkaline, standard [Carbon - Zinc] or rechargeable [Nickel-cadmium] batteries.
- 4) Clean the battery contacts and those of the device prior to battery installation.
- 5) Ensure the batteries are installed correctly with the regard to polarity (+ and -).
- 6) Always remove batteries if consumed or if product is to be left unused for a long time.



FCC ID: 2AJQ7MWKKBD1
FCC ID: 2AJQ7MWKRCV1

DISTRIBUTED BY QUEST USA CORP., 495 FLATBUSH AVE., BROOKLYN, NY 11225

© GOIJOY & IJOY ARE REGISTERED TRADEMARKS OF QUEST USA CORP. ALL OTHER TRADEMARKS AND TRADE NAMES ARE PROPERTY OF THEIR RESPECTIVE OWNERS. DESIGNED BY GOIJOY & IJOY IN NEW YORK. ALL RIGHTS RESERVED QUEST USA CORP.



MADE IN CHINA