

DO NOT PRINT RED FOLD AND CUT LINES. OPEN USER MANUAL DIMENSIONS: 6.46"W x 5.5" H

 CUT LINE

2.4 GHz WIRELESS 

Note:
If OTG is idle for 5–10 minutes, it may turn off automatically.
After recording, there's no need to unplug the receiver to play your videos.
If your mic enters reverb mode, press the button twice quickly to toggle it off (or on again).

Made in Malaysia.

Please check with your dealer for help.


Note:
For Oppo, Vivo, iQoo, and Realme phones, go into your phone's settings, search "OTG," and enable OTG power supply to ensure compatibility.

Diagram of the front of the device. It features a large, rounded rectangular display screen at the top, showing a grid of small dots and a small icon on the left. Below the screen is a rectangular navigation pad with three vertical lines. At the bottom is a circular power button with a power symbol. A label "Switch key" points to the power button.

FUNCTION	HOW TO USE	LIGHT
Power On	Press Switch Key Once	Green Light On
Power Off	Press Switch Key (For 3 Seconds)	Light Off
Pairing		Red & Green Lights (Flash Alternately)
Paired		Green Light Stays On
Pause	Press Switch Key Once	Green Light Flashes Slowly During Pause
Reset	Press Switch Key Once	Green Light Stays On
Low Battery Alarm	(Power On State)	Red Light Appear Every 10 Seconds
Charging	Charging With Cable	The Red Light Turns Off At Full Charge

FUNCTION	HOW TO USE	LIGHT
Power On	Plug in the Device	Green Light On
Power Off	Unplug the Device	Green Light Off
Pairing		Green Light Flashes Slowly
Paired		Green Light On

Disposal of old electrical & electronic equipment (Applicable in the European Union and other European Countries with separate collection systems.) The trash can symbol (seen on bottom right) on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.



FCC ID: 2AJQ7VIBEMIC

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.