

LEDVANCE

LEDVANCE LLC

200 Ballardvale Street

Wilmington, MA 01887

NAED

74099

DATE

9/29/16

GRAPHIC ARTIST

db

PART NUMBER

E21265

STRUCTURE NUMBER

5.5" X 3.615"

LAM DOCUMENT

n/a

ZNP/ZN2

ZNP 3350719

NUMBER OF COLORS

5

SPOT COLORS

PANTONE 021

PROCESS COLORS

C

M

Y

K

LITHO

This electronic file and derivations of this file are property of LEDVANCE LLC

An APPROVED proof must be obtained from Corporate Packaging prior to production

SYLVANIA

LEDVANCE LLC

900 Tyrone Pike

Versailles, KY 40383

LEDVANCE LTD./LTEE

5450 Explorer Drive

Mississauga, Ontario L4W 5N1

Fabrique aux Chine

1-800-LIGHTBULB (1-800-544-4828)

www.sylvania.com (US & Canada)

01 (800) 716 7007

www.ledvance.com.mx (Mexico)

SYLVANIA and LIGHTIFY are registered trademarks.

LIGHTIFY®

SMART CONNECTED LIGHT

Smart Switch

8 Functions / 4 Buttons

Wall Mountable

Battery Included

CR2032

Package Contents/Dimensions

1

A

B

C

D

E

F

2.5"

2.5"

.50"

.70"

A. Metal Mounting Plate

B. Holding Plate

C. Mobile Switch

D. Double Sided Tape

E. Screws

F. Wall Anchors

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.

WARNINGS

• This Product is not a toy and should not be stored or left in a location accessible to young children.

• Observe proper polarity when charging batteries. Switch may not function properly if batteries are inserted incorrectly.

• To prevent danger from explosion or leakage, do not throw batteries into fire or expose them to excessive heat.

• This products contains a button battery. If swallowed, it could cause severe injury or death in just 2 hours. Seek medical attention immediately.

• To avoid possible fire, product damage, or early lamp failure this lamp should not be used in heat-producing appliances.

• Do not open, short circuit or mutilate batteries as injury could occur.

• Please preserve our environment by recycling Lithium batteries or disposing of them in accordance with local, state and federal regulations.

• To prevent danger from explosion or leakage, do not throw batteries into fire or expose them to excessive heat.

• Remove batteries if consumed or if product is to be left unused for a long time.

• Always purchase the correct size and grade of battery most suitable for the intended use.

• Replace all batteries of a set at the same time

• Clean the battery contacts and also those of the device prior to battery installation

• Ensure the batteries are installed correctly with regard to polarity (+ and -)

• Remove batteries from equipment which is not to be used for an extended period of time.

• Remove used batteries promptly.

1

Installation (Screw Mount)

A

1.1

1.2

1.3

1.4

LED behavior

Blinking green

Power on, activity

Continuous blinking blue

Device is in pairing or configuration mode

Continuous blinking red

Battery is low

Shows red light

Operation failed

2

2. Add the LIGHTIFY® Switch to your LIGHTIFY® system

2.1

Press the "+"-Button

4

Change the battery

2.3

Select "4 Button Switch"

3.6

Press: return

2.5

Make sure your Switch is listed and press: next

3.4

Press here to assign an action to short pressing

3

Configure the LIGHTIFY® Switch

3.1

Press the Switch configuration button

SIDE 1

Package Contents/Dimensions

1

A

B

C

D

E

F

2.5"

2.5"

.50"

.70"

A. Metal Mounting Plate

B. Holding Plate

C. Mobile Switch

D. Double Sided Tape

E. Screws

F. Wall Anchors

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.

1

Installation (Tape Mount)

B

1.1

1.2

1.3

1.4

2.2

Select "Add Switches"

4.2

4.3

2.4

Follow the on-screen instructions for pairing

3.7

Press: "Done" to save the configuration

2.6

Your Switch will now be shown in the device list

3.5

Press here to assign an action to long pressing

3.2

Choose a button to configure

3.3

Press here to assign a light to this switch button

SIDE 2