

Compatible with

sleek, wireless set puts convenience and control comfortably at your fingertips. The keyboard also offers a palm rest for comfort, vertical storage to save space. The laser mouse feels good in either hand with a contoured design and soft rubber side grips. Advanced 2.4 GHz wireless offers a long-range wireless connection that virtually eliminates delays, dropouts and interference. Included, tiny, unifying receiver stays in your laptop, and you can easily add a compatible wireless mouse or number pad without the hassle of multiple USB receivers.

- Keyboard
- Mouse
- User Guide

- Features:**
- Auto-Sleep not using it
 - 80m Mesh

- Auto-Sleep not using it

- Auto Sleep Function: Automatic sleep mode turns the mouse off when you're not using it
- 30m Working Range: Work comfortably and with ease at your desk or away
- Precision Tracking: The high-define optical sensor tracks the mouse's movements with smooth accuracy for optimal performance and productivity
- Slip Proof: Protect your keyboard and mouse from those accidental spills
- Plug & Play: Simply insert the wireless USB receiver into your device and you'll be up and running quickly as the mouse driver will download and install automatically
- Nano Receiver: The tiny receiver stays in your notebook or desktop without affecting other USB ports.
- Compact and Portable Design: The compact, ergonomic design helps keep your comfortable wherever you want to use your laptop—at home, at work, or on the go
- 2.4GHz Wireless Connection: Using a compact nano receiver, provides the ultimate freedom and mobility for your mouse with a completely reliable wireless connection so you can always be productive
- Compatibility: Compatible with Windows® and Mac®

Precautions

Please read all safety instructions before use of the product.

1. Do not disassemble the device or attempt to fix it.
2. Do not attempt to replace any part of this product. Battery is replaceable.
3. Do not crush, puncture or dispose of in fire.
4. Do not store or use the device in a high temperature environment, including intense sunlight or heat.
5. Avoid excessive drops, bumps, abrasions and impacts.
6. If there is any reason to believe that there is internal damage to the device, discontinue use immediately.
7. If you find that the device is too hot, is emitting an odor, or is deformed, punctured or exhibits any suspicious or abnormal behavior, discontinue use immediately and contact our customer service.


A diagram of a mobile phone repair station. On the left is a computer mouse with callouts 1 (pointing to the cord) and 2 (pointing to the button). In the center is a repair station with a callout 3 pointing to the top surface. On the right is a mobile phone with callouts 4 (pointing to the screen) and 5 (pointing to the back cover).

1. Left Button
2. Right Button
3. Scroll Wheel
4. Battery Case

as shown in the im

1. Remove the Battery case cover and insert the battery as shown in the image:


1. Remove the Battery case cover and insert the battery as shown in the image:



2. Remove the Nano-USB receiver



3. Insert the Nano-USB receiver into your Desktop PC or Laptop. The drivers will download and install automatically.



Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If you are experiencing interference with your radio or television reception, you can determine if your equipment is the cause by performing the following steps:

- 1) Turn the equipment off. If the interference stops, the user is responsible for correcting it by using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- 2) Contact the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference,
- 2) This device must accept any interference received, including interference that may be undesired operation.

The user is responsible for ensuring that this equipment does not cause interference. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.