

BONX Parrot_manual

2024 11 06 V4

For Your Safety Warning

● When using the product, be careful not to disturb other people around you.● Do not use in areas where it is dangerous and you are unable to hear ambient noise around you. Pay careful attention when using while performing work that requires your full attention.● When using the product, pay careful attention to traffic conditions, pedestrian traffic, and so on; follow all road traffic laws and regulations (hereinafter referred to as "traffic laws") while using the product. There is the possibility of causing a traffic accident when using the product.● There may be cases where wearing headsets while operating an automobile, bicycle, or motorcycle is regulated by local traffic laws. Please contact your local municipality before using.● When using the product, check to make sure the product itself is firmly in place in order to prevent the Earbud from coming off.● In the unlikely event that the Earbud comes off and remains in your ear, do not forcibly remove it; seek medical advice and follow the instructions of medical staff.● Pay careful attention not to turn the volume up too high on connected equipment. Exposure to loud sounds for extended periods of time has the risk of damaging ears and causing hearing loss. Before using, carefully check the volume before placing against the ear.● This product uses a rechargeable battery. A new battery will charge up to its full capacity only after first being fully charged and fully depleted 2-3 times. Do not leave a fully charged battery connected to the charger. Overcharging will shorten the life of the battery.● Keep the battery in a place with a temperature range of 0-45°C. Placing in a location outside that temperature range—an extremely hot or cold location (for example, somewhere in direct sunlight or inside a hot car) in summer or winter—may result in the following: leakage, overheating, rupture, discharge, and the shortening of the life of the battery. Even if fully charged, there may be cases where the product does not work temporarily.● Submitting the product battery to any of the following may cause fires or chemical burns:strong physical impacts; electrically charged materials contacting the battery electrode; overcharging and over-discharging through use of rapid chargers and so on; handling incorrectly. Damaged batteries may generate heat and have the danger of exploding.● Because the product battery was not designed to be replaced with other batteries, removing the product battery and replacing with other batteries is prohibited. Removing and replacing the battery is dangerous and has the risk of damaging the product.● When disposing of the battery, please follow local laws and regulations. Recycle as much as possible; do not dispose of the battery in your normal household waste; do not burn. There is a risk of explosion.● This product contains small parts and cords that may become stuck in the throat and cause suffocation. Please store out of reach of children. If children use the product, there is the possibility it could cause serious injury or death.● Do not submit the product body to strong impacts. Strong impacts may cause damage or product failure.● Do not use if the product is damaged or broken. We assume no responsibility if the product is used in a damaged or broken state.● We assume no responsibility in the case of any accident that occurs if the product is used in a way that does not follow the provided safety precautions, or is used in a way that deviates from the intended use or laws and regulations, such as traffic laws, provided in the safety precautions.● Do not charge a product with built-in rechargeable batteries if ambient temperatures above 0-45 °C.● Product with built-in rechargeable batteries should not be heated to temperatures above 60 °C.● Do not charge the product if there is a clear defect in the product that contains the rechargeable battery.

Caution

● Do not use or handle the battery under the following conditions. (- use, storage or transportation of the battery in an excessively high or low temperature environment / disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery / leaving a battery in an extremely high temperature surrounding environment / leaving a battery in an extremely low air pressure surrounding environment) Handling under the above conditions may cause battery leakage, and in extreme cases, explosion, heat generation, fire, smoke or gas generation.● The intended use

of the product is, in conjunction with our smartphone application, for group calls in the context of sports, including skiing, snowboarding, cycling, fishing, and so on. This product has been developed and designed to be used with our smartphone application. We do not offer support related to how to use our smartphone application on smartphones other than those specified. We ask for your understanding.● Do not place near heating equipment, in dusty or hot areas, in direct sunlight, or where the product may come in contact with water. Doing so may cause the product to break.● To clean dirt from the exterior of the BONX earpiece, wipe with a soft towel. For particularly stubborn stains, wipe with a cloth moistened with a mild detergent. Paint thinner, benzene, and alcohol will damage the surface finish; do not use them.● Operating within the frequency band used by this product are industrial, scientific, and medical equipment, factory production lines, and so on, where private radio stations for mobile identification are used (radio stations requiring licenses), as well as low-power radio stations (radio stations that do not require licenses). Before using the product, confirm that these types of radio stations are not operating nearby. In the unlikely event of radio interference between the product and these types of radio stations, refrain from using the product and address the issue promptly, such as by changing locations. This product is a wireless device featuring a sophisticated built-in 2.4GHz band data communication system. The modulation system uses FH-SS.● The Bluetooth® product name and logo are registered trademarks of Bluetooth® SIG, Inc. BONX Inc. uses all of these based on a license.● BONX® and the BONX® logo are trademark registered in Japan, and registrations pending in the United States and other countries by BONX Inc.● All brands described in the instruction manual are protected property of their respective owners.● Designs, specifications and what is described in this manual are subject to change without prior notice.

- Federal Communications Commission Part 15 -

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement, in portable exposure condition without restriction.

⚠ WARNING : Risk on Cancer From Lead And Reproductive Harm From Lead Exposure -www.P65Warnings.ca.gov

Note Internal Rechargeable Lithium-ion Battery

This device uses an internal rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead, by charging it several times. If the battery does not recharge, please contact us for repair information. Use LPS (100W less) power PS2 products

WARNING/DISPOSAL OF UNIT

Please do NOT attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions below.
- Never dispose of used batteries/electronics with ordinary solid wastes, since they contain toxic substances.
- Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices.
- Many electronics retailers now recycle batteries and other electronic devices at no charge. Check to see which ones in your area do so.

Informational Note for Customers in EU Only

Information for users on collection and disposal of old equipment and used batteries



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste. For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation.

By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling. For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

These symbols are only valid in the European Union. For countries outside the European Union:
If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

Note for the battery symbol (bottom two symbol examples): This symbol might be used in combination with a chemical symbol, in this case it complies with the requirement set by the EU Battery Directive for the chemical involved.



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Declaration of Conformity with regard to the RE Directive 2014/53/EU · RoHS Directive 2011/65/EU



Hereby, BONX, Inc. declares that the BN2-MBK1 is in compliance with Directive 2014/53/EU and RoHS Directive 2011/65/EU. The full text of the EU declaration of conformity is available on our website.

Maximum radio-frequency power transmitted in the frequency band(s) 2 400 - 2 483,5 MHz : 6,91 dBm

保証規定

1. 弊社が定める保証期間（本製品ご購入日から起算されます）内に、適切な使用環境（安全上の注意にかかれた内容ないし使用目的での使用）で発生した本製品の故障に限り、無償で本製品を修理または交換いたします。

無償保証範囲

2. 以下の場合には、保証対象外となります。（1）保証書及び故障した本製品をご提出いただけない場合。（2）販売店や EC サイトなどで発行される、ご購入日が確認できる証明書（レシート・納品書など）などをご提示いただけない場合。（3）保証書に偽造・改変などが認められた場合。（4）弊社および弊社が指定する機関以外の第三者ならびにお客様による改造、分解、修理により故障した場合。（5）安全上の注意に記載されている内容や使用目的に沿わない使用方法、または弊社が定める機器以外に接続、または組み込んで使用し、故障または破損した場合。（6）本製品を購入いただいた後の輸送中に発生した衝撃、落下等により故障した場合。（7）地震、火災、落雷、風水害、その他の天変地異、公害、異常電圧などの外的要因により故障した場合。（8）その他、無償修理または交換が認められない理由が発見された場合。
3. 本製品の無償保証対象は、日本および米国内で購入された製品に限りです。その他の地域での保証状況につきましては、最新の情報を本保証書に記載されている製品サポートページでご確認ください。

修理・交換

4. 修理のご依頼は、本保証書、ご購入日が確認できる証明書（レシート・納品書など）をご準備の上、弊社サポートまでお問い合わせください。
5. 弊社までご送付いただく場合は送料はお客様のご負担となります。尚、弊社は運送中の製品の破損、紛失については一切の責任を負いかねます。
6. 修理のご依頼をされる際の送付先は、お客様のご購入国によって異なります。詳細につきましては、弊社サポートまでお問い合わせください。

免責事項

7. 本製品の故障について、弊社に故意または重大な過失がある場合を除き、弊社の債務不履行および不法行為等の損害賠償責任は本製品の購入代金を上限とさせていただきます。
8. 本製品の故障に起因する派生的、付随的、間接的および精神的損害、逸失利益、ならびにデータ損害の補償等につきましては、弊社は一切責任を負いかねます。
9. 本保証書は再発行いたしませんので、大切に保管してください。

Warranty Regulations

1. Within the warranty period set by BONX Inc. (calculated from the product purchase date), as long as the failure of this product occurred while being used appropriately (used according to safety precautions and the correct intended use), the product will be repaired or replaced free of charge.

Warranty Range

2. The following are not covered by the warranty:(1) If you do not submit the warranty and the broken product,(2) If you do not submit proof of purchase (receipt, delivery slip, etc.) showing the purchase date issued by the retailer or online store,(3) If the warranty is proven to have been forged or altered,(4) If the product has been altered, taken apart, or damaged by repairs carried out by a third party not specified by BONX Inc. or the customer,(5) If the product is used in violation of the safety precautions or intended purpose of use, or if the product is connected to equipment other than that specified by BONX Inc., or if incorporated and used in such equipment resulting in damage or product failure,(6) If the product receives shock or is dropped and damaged while in transit after purchase,(7) If the product breaks due to external factors such as earthquakes, fires, lightning, wind and flood damage, other natural disasters, pollution, or voltage abnormalities,(8) If other reasons are found that violate free repairs or product replacement,3. The warranty for this product covers only products purchased in Japan and the United States. As for other countries, please refer to the product support page on our website which lists the latest information regarding warranties.

Repairs / Replace

4. To request repairs, send the warranty card and proof of purchase date (receipt, delivery slip, etc.) together with the product to our office.
5. The customer is responsible for any shipping fees incurred when shipping to our office. Also, we assume no responsibility if the product is damaged or lost while in transit,6. The address for sending in your product for repairs will vary depending on what country you purchased the product in. Please refer to our support page and contact us for details.

Disclaimer

7. For product failures, unless there is intent or gross negligence by BONX Inc., liability for damages, such as our defaulting on debt or illegal actions, will be the upper limit of the purchase price of this product,8. We will assume no responsibilities for consequential, incidental, indirect, and mental damages, lost profits, or compensation for data loss caused by the failure of the product,9. The warranty card will not be reissued. Keep it somewhere safe and secure.

製品保証書

製品名	: BONX *****	お名前 /Name
型番	: BN2-MBK1	ご住所 /Address
保証期間	: ご購入から 1 年間	電話番号 /TEL. No.
		メールアドレス /E-mail
		販売店 /Retailer
修理・交換時の製品のご送付先については、 弊社 HP をご確認ください。 Please refer to our website for the return address when sending in products for repair or exchange https://bonx.co/ja/contact/		購入日 /Purchased date



BONX Stick

QUICK START GUIDE
PRODUCT WARRANTY CARD

第 1 版 2411-1

このたびは本製品をお買い上げいただき、まことにありがとうございます。ご使用の前に本書を最後までよくお読みの上、「安全上の注意」に記されている点に十分ご注意ください。お読みになったあとは、大切に保管してください。

⚠ 注意

操作マニュアルについて

当製品には操作マニュアルが付属しておりません。
組み立て方法や装着方法など詳しい内容をご覧になりたい場合は、
右の QR コードより弊社 HP にアクセスしご確認ください。



操作マニュアル
について

ファームウェア・アップデートについて

BONX イヤフォンのファームウェアを最新にアップデートすることで
不具合が改善されるため、ご使用前に最新のファームウェアになって
いるかご確認ください。推奨しております。
ファームウェア・アップデートには専用のアプリが必要です。
右の QR コードより弊社サイトにアクセスしアプリをダウンロードし
ご利用ください。



ファームウェア
アップデートについて



⚠ 警告

本製品は Intro Knot と同時に使うことを想定した製品です。そのため、本製品の音声出力は通常の製品よりも大きくなっております。Intro Knot 以外のイヤホンで最大音量にて長時間使用する場合には以下の点に注意をし、適切な音量を設定するようにしてください。

- ・ 難聴の原因となります。
- ・ イヤホンの故障の原因となります。

This product is designed to be used with Intro Knot. Therefore, the audio output of this product is louder than that of standard products. When using earphones other than Intro Knot at maximum volume for extended periods, please be aware of the the following risks and set an appropriate volume:

- ・ It may cause hearing loss.
- ・ It may lead to earphone damage.

STEP 01 アプリのダウンロード Download app   ビジネス向けアプリについて ビジネスシーンでご利用されるお客様は別途サービスの契約が必要となります。詳細は右記リンクからご確認ください。  bonx2app STEP 02 電源をONにする Power On  ここを長押し 本体上部の  部分を長押しすると電源が入ります ※初回接続時は電源ON後に自動でペアリングモードに入ります Press and hold the logo button to turn it on.	を接触させたり、急速充電器等を用いることにより過充電させたり、過放電等をすると、間違っ取り扱うと火災や化学火傷を引き起こす可能性があります。損傷したバッテリーは熱を帯びることで、爆発する危険があります。● 本製品のバッテリーは他のバッテリーに交換して使用することを前提とした構造となっていないため、本製品のバッテリーを取り外したり、交換することは禁じられています。バッテリーを取り外したり、交換することは危険で、製品を破損するおそれがあります。● バッテリーを廃棄する際は地域の条例等の法令に従ってください。できるだけリサイクルを心がけ、バッテリーを家庭ごみとして捨てたり、燃やさないでください。爆発の恐れがあります。● 本製品には、眠に詰まったり窒息したりする恐れのある小さな部品やコードが含まれています。お子様の手の届かないところに保管してください。お子様が触ったり使用したりすると、死亡や重傷の原因となる恐れがあります。● 製品本体に過度に強い衝撃を与えないでください。故障、破損の原因となります。● 製品が故障、破損した時は使用しないでください。故障、または破損した状態で製品を使用した場合、当社は一切の責任を負いかねます。● 「安全上の注意」に書かれている内容を守らず、または「安全上の注意」に書かれている使用目的や交通法規等の法令を逸脱して本製品を使用され、何らかの事故が生じた場合、当社では一切の責任を負いかねます。● 充電式電池が内蔵されている製品の充電は、0～45℃を超える温度環境では行わないで下さい。● 充電式電池が内蔵されている製品は、60℃を超える温度にならないようにして下さい。● 充電式電池が内蔵されている製品に明らかな欠陥が見られた場合は、製品を充電しないで下さい。 注意 ● 記載している条件下での電池の使用及び取扱いはしないで下さい。(過度の高温又は低温環境下での電池の使用、保管又は輸送、電池の火もしくは熱した炉への廃棄、機械的な押し潰し又は切断、電池の過度の高温周囲環境への放置、電池の過度の低気圧環境への放置) 以上のような条件下での取扱いにより、バッテリーの液漏れや、極端な場合には爆発、発熱、出火、煙やガスの発生を引き起こすおそれがあります。● 本製品の使用目的は、弊社開発のスマートフォン用アプリケーションと連携して、スキー・スノーボードなどのスポーツシーン、または小売店舗におけるスタッフ間ややり取りなどの業務シーンなどの場面におけるグループ通話を行うものです。加えて本製品は、弊社開発のスマートフォン用アプリケーションと同時に使用する前提で開発・設計されています。弊社指定のスマートフォンにおける弊社開発のスマートフォンアプリケーション以外での使用方法については、弊社ではサポートしておりません。予めご了承ください。● 暖房機との近く、高温やほこりの多い場所、直接日光のあたる場所、水のかかる場所にはおかないでください。故障の原因となります。● BONX ヘッドセットの外装の汚れは、柔らかい布でお拭きください。汚れがひどいときは、薄めた中性洗剤でしめした布で拭いてください。シンナー、ベンジン、アルコールなどは表面の仕上げを痛めますので、絶対に使わないでください。● 使った後は乾いた布で汚れを拭き取ってから保管してください。● 汗などの汚れが付いた場合は、すぐに乾いた布で拭き取ってください。腐食の原因となります。● 本製品の使用周波数等では、産業・科学・医療機器等他、工場の製造ライン等で使用されている移動体識別用の構内無線局（免許を要する無線局）及び特定小電力無線局（免許を要しない無線局）が運用されています。本製品を使用する前に近くでこれらの無線局が運用されていないことをご確認ください。万、本製品からこれらの無線局に対して電波干渉の事例が発生した場合には、使用を控える、場所を変えるなど速やかに対処してください。本製品は 2.4GHz 帯高度化データ通信システムが内蔵されている無線設備です。変調方式は FH-SS を使用しています。● Bluetooth の製品名およびロゴマークは、Bluetooth® SIG,Inc. の登録商標です。株式会社 BONX はすべてのこれら商標をライセンスをもとに使用しています。● BONX® および BONX® ロゴマークは、株式会社 BONX の登録商標です。● 本マニュアルに記載されている全てのブランドは、保護されそれぞれの所有者に帰属します。● 本製品のデザインや仕様、及びマニュアルに記載されている内容は予告無く変更になることがあります。	・テレビにノイズが出た場合、Bluetooth機能搭載機器や本機（および本機対応製品）がテレビ、ビデオ、BSチューナー、CSチューナーなどのアンテナ入力端子に影響を及ぼしている可能性があります。 Bluetooth機能搭載機器（および本機対応製品）をアンテナ入力端子から離して設置してください。 ■電波法に基づく認証について 本製品は、電波法に基づく小電力データ通信の無線設備として認証を受けています。したがって、本製品を使用するときに無線局の許可は必要ありません。 ただし、以下の行為をすると法律で罰せられることがあります。 ・本機を分解/改造すること。 ・本機に印刷されている証明番号を消すこと。 ■周波数について 周波数表示の見かた(個装箱裏面に表示) ① 1 ——— 想定される干渉距離 (約10 m) を表します ② 「FH」 ——— 変調方式を表します ③ 「2.4」 ——— GHz帯を使用する無線設備を表します ■使用範囲について 通信の環境により伝送距離が短くなることがあります。 次のような場合、電波状態が悪くなったり電波が届かなくなることが原因で、音声が途切れたり停止したりします。 ・鉄筋コンクリートや金属の使われている壁や床を通して使用する場合。 ・大型の金属製家具の近くなど。
STEP 03 スマートフォンとBluetooth®接続 Connect via Bluetooth®  BN2A000000 Bluetooth®の設定画面でBOOSTのシリアルナンバー(BN2*****)を選択 ※シリアルナンバーはイヤフォンの裏面に刻印されています Select your device's serial number on Bluetooth® setting	STEP 04 グルーブトークをはじめよう Begin group-talk via the BONX app  サービスサイト オンラインマニュアル 通常の通話や音楽も楽しめます 詳しい機能については上記ウェブリンクから確認できます Regular voice call and music are also available Find more functions of the app here.	・人混みの中や、建物障害物の近くなど。 ・2.4 GHzを利用する無線LAN、または電子レンジなどの機器の磁場、静電気、電波障害が発生するところ。 ・集合住宅(アパート・マンションなど)にお住まいで、お隣で使用している電子レンジ設置場所が本機に近い場合。なお、電子レンジは使用していなければ電波干渉はおきません。 ■電波の反射について 本機が通信する電波には、直接届く電波（直接波）と、壁や家具、建物などに反射して様々な方向から届く電波（反射波）があります。これにより、障害物と反射物とのさまざまな反射波が発生し、電波状態の良い位置と悪い位置が生じ、音声がかうまく受信できなくなることがあります。このような時は、Bluetooth 機能搭載機器 の場所を少し動かしてみてください。Bluetooth 機能搭載機器と本機の間を人間が横切ったり、近づいたりすることによっても、反射波の影響で音が途切れたりすることがあります。
安全上の注意 警告 ● ご使用の際は、周囲の人の迷惑にならないようご注意ください。● 周囲の音が聞こえないと危険な場所では使用しないでください。集中力を必要とする作業を行っているときに使用する際は、十分に注意を払ってください。● ご使用の際には、交通状況や人の往来など周囲の状況に十分注意し、道路交通法や条例等の交通法規（以下、「交通法規」といいます。）を守って使用してください。交通事故の原因となる恐れがあります。● 自動車、自転車、オートバイの運転中のヘッドセットの使用は、地域の法令等の交通法規で規制されている場合があります。お住まいの地域の自治体にご確認ください。● 使用時には、イヤークリップがはずれないよう、製品本体にしっかりと取り付けられていることを確認してください。● 万一、イヤークリップがはずれて耳の中に残った場合は、無理に取り出さず医師の診察を受け、医師の指示に従ってください。● 接続された機器の音量を上げすぎないようにご注意ください。耳を刺激するような大きな音量で長時間続けて聞くと、耳を痛め聴覚に障害をきたす恐れがあります。耳に当てて使用する際には、音量を確認の上ご使用ください。● お使いの製品には充電式バッテリーが使用されています。新しいバッテリーは、完全充電と完全放電が2～3回繰り返されてから充電容量が最大になります。フル充電されたバッテリーを充電器に接続したままにしないでください。過充電はバッテリーの寿命を短くします。● 長期間通電をされないと過放電により充電が不能になる場合がございます。定期的に通電をしていただけますようお願い致します。● バッテリーは、0℃～45℃の場所においてください。夏場や冬場に当該温度の範囲から外れた、温度の極端に高い、あるいは低い場所（例えば、直射日光の強い場所や炎天下の車内など）においておくと、漏液、発熱、破裂、放電し、またバッテリーの寿命が短くなったり、完全充電されていても製品が一時的に動作しなくなる場合があります。● 本製品に使用されているバッテリーは、過度に強い衝撃を与えたり、バッテリーの電極に通電材料	電波に関するご注意 本製品は、2.4 GHzの周波数等の電波を利用しています。この周波数の電波は、下記 ① に示すようにいるいるな機器で使用しています。また、お客様に存在がわかりにくい機器として下記 ② に示すような機器もあります。 ● 2.4 GHz を使用する主な機器の例 ・コードレスフォン・コードレスファクシミリ・電子レンジ・無線LAN機器 ・ワイヤレスAV機器・ゲーム機のワイヤレスコントローラー・マイクロ波治療機器類 ● 存在がわかりにくい 2.4 GHz を使用する主な機器の例 ・万引き防止システム・アマチュア無線局・工場や倉庫などの物流管理システム ・鉄道車両や緊急車両の識別システム これらの機器と本機を同時に使用すると、電波の干渉により、音が途切れて雑音のように聞こえたり、音がなくなることがあります。 受信状況の改善方法としては以下の方法があります。 ・電波が発生している相手機器の電源を切る ・干渉している機器の距離を離して設置する 次の場所では本製品を使用しないでください。ノイズが出たり、送信/受信ができなくなる場合があります。 ・2.4 GHzを利用する無線LAN、または電子レンジなどの機器の磁場、静電気、電波障害が発生するところ。(環境により電波が届かない場合があります) ・ラジオから離してお使いください。(ノイズが出る場合があります)	電池についての安全上のご注意 電池は使用形態や使用環境、保存状態などによって、液漏れ・破裂・発熱・発火などで、けがや機器故障の原因となることがあります。下記の注意事項を必ずお守りください。本製品では以下の電池を内蔵しています。 ・充電式電池 専用充電式リチウムイオン電池 充電式の電池の液が漏れたときは… 危険 ・素手で液を触らない ・液が目に入ったときは目をこすらず、すぐに水道水などのきれいな水で十分に洗い、ただちに医師の治療を受けてください。 ・液が身体や衣服についたときは、すぐにきれいな水で十分に洗い流してください。 皮膚の炎症やけがの症状があるときは医師に相談してください。 充電式電池について 危険 ・火の中に入れない。分解、加熱しない。 ・火のそばや直射日光の当たるところ・炎天下の車中など、高温になる場所で使用・保管・放置しない。 ・ショートさせない。 ・液漏れした電池は使わない。  Li-ion00 使用済み充電式リチウムイオン電池はリサイクル可能な貴重な資源です。本製品を廃棄する場合は充電電池の取り外しをお客様自身で行わず、お買い上げの販売店へご相談ください。