

RC302F user manual




Figure 1 button of remote

Product Name: REMOTE CONTROL

Model: RC302F

Input: 3 x Battery AAA 1.5V

Manufacturer: Keeson Technology Corporation Limited

Manufacturing country: China

1.1 Head up

Press and hold HEAD UP button of remote, head actuator moves out, stop when released;

1.2 Head down

Press and hold HEAD DOWN button of remote, head actuator moves in, stop when released;

1.3 Foot up

Pressa and hold FOOT UP button of remote, foot actuator moves out, stop when released;

1.4 Foot down

Press and hold FOOT DOWN button of remote, foot actuator moves in , stop when released;

1.5 Lumbar up

Pressa and hold LUMBAR UP button of remote, lumbar actuator moves out, stop when released;

1.6 Lumbar down

Press and hold LUMBAR DOWN button of remote, lumbar actuator moves in , stop when released;

1.7 Tilt up

Pressa and hold TILT UP button of remote, head tilt actuator moves out, stop when released;

1.8 Tilt down

Press and hold TILT DOWN button of remote, head tilt actuator moves in , stop when released;

1.9 UBB

Click the Underbed light button to open or shut the light under the bed.

1.10 Message head +

Click MESSAGE HEAD button, head message motor switches message intensity, message intensity switches among 0-1-2-3;

1.11 Message foot +

Click MESSAGE Foot button, head message motor switches message intensity, message intensity switches among 0-1-2-3;

1.12 Message head -

Clicking will cause the intensity of the head message to gradually decrease, with a total of 3 levels.;

1.13 Message foot -

Clicking will cause the foot message intensity to cycle and decrease gradually, with a total of 3 levels.;

1.14 Message timer

If the message motors do not work, the button is invalid, if the message motors work, click the button to switch the message time, when message time switch to 0, turn off the message;

1.15 Flat

Click FLAT button, the bed goes flat, stop when click any button during the process of going flat;

1.16 ZG button

Click the ZG button, the actuator moves to ZG position, stop when click any button during the movement;

1.17 Memory position

Click memory position to move the actuator to the memory position.

FCC:**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.