



BATTERY INSTALLATION VEHICLE (DHTRC10217G)



USE 4 X 1.5V "AA" BATTERIES (NOT INCLUDED)

Important: Ensure you seal the battery compartment completely by properly closing the battery cover and fastening it with the screw. Always ensure a tight fit.

BATTERY INSTALLATION VEHICLE (DHTRC10217GB)



USE 1 X 3.7V 500MAH LI-POLY BATTERY (INCLUDED)


Recharge cable included (Micro USB cable)



Take the micro USB cable that is included with this product. Connect the USB plug to the USB port of the device that is powered ON. (For example, a laptop or a computer) Connect the micro USB cable plug to the side port of the battery pack as illustrated. The charge indicator light will light up red when charging.

TECHNICAL DATA

Charge Time	120 minutes (approx.)
Run Time	25 minutes (approx.)
Operation Distance	35 metres
Run Environment	Indoor / Outdoor




The charge indicator light of the battery pack would turn off after charging is complete. Disconnect the micro USB cable from the battery pack and the device. Keep the micro USB cable in a safe place until the next recharge.



Replace the battery pack. Ensure that the Battery is installed according to the correct direction as illustrated. Ensure a tight fit.

BATTERY INSTALLATION TRANSMITTER AND HOW TO OPERATE



USE 2 X 1.5V "AA" BATTERIES (NOT INCLUDED)

Forward	Press both control sticks forward.
Backward	Press both control sticks backward.
Spin/Steer	Spin/Steer the vehicle by pressing and holding the control sticks in opposite directions.

PAIRING

Before each play session, the vehicle must be paired with the transmitter. To pair the vehicle with the transmitter, follow these steps:

1. Ensure that both the vehicle and transmitter are OFF.
2. Switch ON the vehicle and place it on a flat surface. Stand behind the vehicle with the tail of the vehicle pointing towards you. The light on the vehicle would light up.
3. Point the antenna of the transmitter towards vehicle. Power ON the transmitter. The power indicator light would flash.
4. The power indicator light would turn off showing that pairing is successful.
5. You are now ready to play. Gently push the throttle stick/ trigger to move the vehicle.

TIP: If the power indicator light of the transmitter is flashing and you have no control of the vehicle that is powered ON, the transmitter and the vehicle are not paired. Ensure batteries are new or fully charged for normal performance. Repeat the above procedures if required. Electronic equipment or other radio control devices may affect the performance of your vehicle. Find an area free of such interferences to enjoy the play session.

CUSTOMER INFORMATION

- Packaging has to be kept since it contains important information.
- **WARNING!** Not suitable for children under 36 months. **CHOKING HAZARD**
- Where applicable, remove all packaging before giving this item to your child.
- Contents may vary in style, colour, shape and decoration from images shown on package or in advertising.
- The toy is to be operated in water only when fully assembled in accordance with the instructions.

⚠ WARNING:

1. Rechargeable batteries are to be removed from the toy before being charged.
2. Rechargeable batteries are only to be charged under adult supervision.
3. Non-rechargeable batteries are not to be recharged.
4. Different types of batteries or new and used batteries are not to be mixed.
5. Only batteries of the same or equivalent type as recommended are to be used.
6. Batteries are to be inserted with the correct polarity.
7. Exhausted batteries are to be removed from the toy.
8. The supply terminals are not to be short-circuited.
9. Do not touch wheels or tires when they are in motion.
10. Do not collide with humans or any animals to avoid accident from occurring.



محذورات لعب
وهو التحذير من الحوادث الناتجة عن ابتلاع
الأجزاء الصغيرة غير مناسبة للأطفال
تحت سن 3 سنوات



MADE IN CHINA



DHTRC10217G--

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user ' s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.