



Puck 2 Overview

For full, up-to-date instructions visit flair.co/get-started-puck2



QUICK START GUIDE

1

INSTALL THE FLAIR APP

Flair has mobile and web apps.
Available for iOS, Android and Chrome.



flair.co/ios



flair.co/android




my.flair.co

UNBOXING TIP - we recommend unboxing and beginning your set up with all Flair devices together in a room where you get strong Wi-Fi coverage.

QUICK START GUIDE - CONTINUED

2



RUN THE SETUP

The Flair App will guide you through step-by-step instructions to connect your devices and complete setup.

NEED ASSISTANCE? WE'RE HERE TO HELP.

If you have any questions or encounter any issues as you set up your Flair home, please contact us:




AI & Live Chat at flair.co



Email at support@flair.co

WHAT'S IN THE BOX?




1 x Flair Puck 2

For Wire-Free Power:
2 x AAA Batteries

For Wired Power:
1 x USB-A to USB-C Cable
1 x Power Adapter


For Wall Mounting:
2 x Screws
1 x Mounting Adhesive



CONTROLLING YOUR SYSTEM

Your Flair system can be controlled with the App or Pucks. Controlling the Puck is simple.



You can **push** the front surface or **rotate** the inner collar.



PUCK DOOR

The Puck door has two sides. For wall mounting, the Flair logo (**side A**) should face you.


To open the Puck door, **press** on the round dimple.



WALL MOUNTING


ADHESIVE

Attach adhesive to the hard plastic side (**side B**) of the Puck door.



SCREWS

Press & rotate the screws through the small holes in the soft side (**side A**) of the Puck door.




POWER

WIRE-FREE

Pucks operate on 2 x AAA batteries (included).

Battery life ~1-year.




WIRED

Pucks can be powered using AC power.

1 x USB-A to USB-C cable, and

1 x power adapter included.



FCC COMPLIANCE STATEMENT

FCC ID: 2AK78PUCK2

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ACCESSING FCC & IC ID ON THE PUCK

1

Open the Settings App

2

Click 'Certs'

3

FCC & IC ID Shown (FCC: 2AK78PUCK2 / IC: 22464-PUCK2)

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Canada Statement

This device complies with Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Ce matériel est conforme aux limites de dose d'exposition aux rayonnements, FCC / IC RSS-102 énoncée dans un autre environnement. Ce matériel devrait être installé et exploité avec distance minimale de 20 cm entre le radiateur et votre corps.