

Diagram illustrating the components of the sensor system:

- Sensor:** A cylindrical device with a **Networking Hole** and an **LED Indicator**.
- Installation Bas:** A circular base component.

1

2

- 3

- 4

Bedroom
 Bathroom
 Bedroom
 Bedroom
 Livingroom
 Kitchen
 Garage
 Basement

◆ Minimum recommended area
 ◆ Additional recommended area

5

- 6

- 7

According to APP prompt, press networking hole for 2 seconds

- 8

- 9

Status	LED Indicator	Alarm
Test	Red LED flash 4 times in 10 seconds	"Di" four times
Warm up	LED flash alternately in three colors and then go out	"Di" one time when power on
Fault	Yellow LED flash twice	"Di" twice in 10 seconds
Low Power	Yellow LED flash one time	"Di" one time every 10 seconds
Super Low Power	Yellow LED keeps on	"Di" one time every 10 seconds
Usage Expiration Date	Yellow LED flash twice	"Di" twice every 10 seconds

-

Please take following advices for reference if sensors can not work normally

1. Replace battery in time, if voltage too low and reach effective life span. (Check table 1 for status reference)
2. Please clean sensor if the fault resulted from dust or oil stain (Check table 1 for status reference).
3. Make sure sensors screw into the base correctly.

-

-

11

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.