

Instruction manual

4500



The health and safety instructions, translations of the EC Declaration of Conformity are set out in the document supplied with your printer, as well as in PDF format on your DVD.

Printer and Interface Overview

Starting up / Shutting down the Printer

Printing a job

Editing and Previewing a job

Printer Maintenance

Ink Bottle Replacement


Troubleshooting Information



markem·image


a **DOVER** company

Printer overview



1. Printhead
2. Control Unit (display: 5.7"/144.8mm diagonal)
3. Enclosed Ink system
4. Ink bottle (1.0 or 0.5 liter)
5. Enclosed power supply
6. Disconnectable power cable
7. Support beam
8. Nozzle plate
9. Photocells (Product sensors)
10. Manufacturer's plate





1. Printer information bar; colored background
2. Shut down icon
3. Start/pause printing icon
4. Printing status; colored background
5. Ink level indicator
6. Purge button
7. Printing status LED
8. Start/pause printing button
9. Printer status LED
10. Start up/shut down button
11. Menu bar
12. Job preview window



Presentation of the menus

