


Quick Guide

Deco mini7W V2 Drawing Tablet

1. Product Overview



1.Power Button

2. USB-C Port

3.Indicator Light 1

- a. Flashing: the stylus is in the active area but not touching the tablet.
- b. Steady On:the stylus is in contact with the active area.
- c. Off:the stylus is beyond the active area.

4.Shortcut keys

5.Indicator Light2

Blue Light:

- a. Slow flash: Bluetooth is not connected
- b. Fast flash: Bluetooth is waiting for pairing (press and hold the first shortcut key in the upper left corner for 3 seconds).
- c. Steady On: Bluetooth connected and paired successfully

Red Light:

- a. Flashing: Low battery power ($\leq 20\%$)
- b. Steady on: Charging status
- c. Off: Charging complete or automatic shutdown due to extremely low battery

Purple Light: The red light and the blue light are on simultaneously.

6.Active area

2.Accessories

- Drawing Tablet× 1
- Stylus× 1
- Pen Nibs× 10
- Pen Clip× 1
- USB-A to USB-CCable× 1
- OTGAdapter× 1
- Quick Guide× 1
- Warranty Card× 1
- Trendy Sticker Sheet× 1


*Pictures and lists are for reference only. Please refer to the actual product.

3. Connection

3.1.Wired Connection


1) Computer Connection

Connect the USB-A to USB-C cable to a USB port on your computer and to the USB-C port on the drawing tablet.



2) Android Phone or Tablet Connection


First, connect the drawing tablet to the USB OTG adapter using the USB-A to USB-C cable. Then, connect the adapter to your Android phone or tablet.



3.2. Bluetooth Wireless Connection

1) Computer Connection

Turn on the drawing tablet by holding the power button for 3 seconds. Then hold the first shortcut key in the upper-left corner for 3 seconds to enter pairing mode (Indicator 2 blinks blue rapidly). Turn on your computer's Bluetooth, search for "Deco mini7W V2", and select it to pair. When successfully connected, Indicator 2 will glow solid blue.



2) Phone or Tablet Connection

With the drawing tablet in pairing mode, enable Bluetooth on your mobile device, search for the device named "Deco mini7W V2", and select it to complete pairing.

4. Driver Installation

1. Ensure your drawing tablet is connected to the computer.
2. Visit the official website: <https://www.xp-pen.com>
3. Navigate to the "Driver" section, search for "Deco mini7W V2" , then click to enter the download page, download and install the driver that matches your operating system.
4. Open the driver, configure parameters, and test the product functionality.

Pre-Installation Notes:

- Disable antivirus and graphic software.
- Uninstall drivers from other drawing display/tablet brands.

- Restart the computer after installation.

*It is recommended to use the latest driver version for optimal performance.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ISED Statement

English: This device complies with Innovation, Science and Economic Development Canada's license-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

- French: Le présent appareil est conforme aux CNR d'Innovation, sciences et développement économique Canada applicables aux appareils

radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.