


MONDO



SPEAKER SMALL

OWN YOUR SOUND



Copyright © Designed by a Star AB
Hölländargatan 22, 113 59
Stockholm Sweden

mondosound.com

 [mondo_sound](https://www.instagram.com/mondo_sound)

 [mondosound](https://www.tiktok.com/mondosound)





FCC ID:2AKFED240 / Manufactured in China

SMALL BUT MIGHTY

Crafted with care from durable aluminum, the MONDO Speaker Small delivers big sound in a compact design. Its powerful dual drivers provide clear, full-bodied audio that punches well above its size. Clip it to your backpack and take it anywhere — from the slopes, the trails, to the beach. The best part? You can pair an unlimited number of MONDO speakers with each other, to create the block party of the year.

Customize your sound with precision using the MONDO app's EQ settings, and listen to your favorite tracks exactly the way you like them.



MONDO SPEAKER SMALL

Welcome to MONDO. Start off by reading this manual and you'll be listening to your sound of choice in no time.

WHAT'S INCLUDED


- Mondo Speaker Small
- Carbine hook and strap included
- Type C-C Charging Cable
- User Manual

PLEASE NOTE!

The volume affects the capacity of the battery. Just so you know – if you play your music with lower volume, the battery will last even longer between charging.


TECHNICAL SPECIFICATIONS

- Bluetooth 5.3
- AuraCast capability
- Type C-C high power charging cable
- Battery capacity: 3200mAh 18650*2/7.4V
- Charging time: 2-3H
- Play time at 60% volume: 10-12H
- Standby Time: 120 Day
- Dual drivers, (3"+0.75")
- Output Power:25W (15W+10W)
- Rated Power Woofer 15W+1* tweeter 8W*1
- THD+N: <=1%/S/N Ratio: >=80dB A-weighted filter(1KHz/0dB)
- Frequency response: 50Hz-20KHz @ -6db
- ADC sampling rate: 24bit/96KHz
- Weight: 611 G
- Water Proof IPX5
- Carbine hook and strap included
- App for personalized eq-settings and more
- Built-in microphone: 1
- Phonell function: Yes



CONTROL FUNCTIONS

- 1.**Volume + button: Short press to increase volume. Long press for next track
- 2.**Volume - button: Short press to decrease volume. Long press for previous track
- 3.**Play/Pause button: Press once to pause and/or play audio and answer your call, long press to reject the call
- 4.**Auracast broadcast button: one short press to turn on/off the broadcast mode. Long press 3 seconds to disconnect existing Bluetooth connection. Long press 6s to clear all previous paired list.
- 5.**Power button: Press for 3 seconds to power on/off. Short press to switch input mode: Bluetooth or USB_Audio
- 6.**Microphone
- 7.**LED light: After power is on, the white light flashes to indicate that Bluetooth is waiting to connect. When connected the white light stays on. The red light indicates USB Audio input. Flashing green light indicates Auracast broadcast mode. When connected the green light stays on.



- 1.**Type-C Port for:Charging DC5V/2A (no fast charging) USB_Audio Input
- 2.**Battery LED light: Red light indicates low power, white light indicates the speaker is fully charged. When the white light gradually changes to red it indicates that the

power gradually decreases. When charging the color changes from red (low power) to white (to fully powered).

GET STARTED

Start by downloading the MONDO app where you find your apps (App Store & Google Play). Add your device, then use your app to choose equalizer settings, use the presets, or create your own personalized settings. You can also use your MONDO Speaker Small Speaker without the MONDO app and enjoy the product with the default audio settings to fit all music genres. Make sure the speaker is fully charged. Press button 5 for 3 seconds to start the speaker, it will automatically start searching for a pairing device. When the Bluetooth icon flashes (button 5), turn on the Bluetooth connection on your device. Select "MONDO BT SPEAKER SMALL" in the Bluetooth list to pair the speaker with your device. When the Bluetooth icon is lit the device is paired and ready to play. Use button 1 for volume up and long press to change for next track. Use button 2 for volume down and to change to previous track.

DISCONNECT THE SPEAKER

Click Auracast button (see image 4) to unpair the speaker. It will be ready to pair to another device immediately.

CONNECT MULTIPLE SPEAKERS WITH AURACAST

If you have 2 or more MONDO speakers in proximity of each other you can pair them together to play the same sound through Auracast. One of the speakers will be the master and broadcast to the other speaker(s). Pair the first speaker by pressing the auracast button (4). When the green light is flashing it is ready and searching for a pairing. Press the Auracast button to enter receiver mode. The speakers will connect automatically. To connect additional speakers make sure to disconnect from previous

Bluetooth devices. Repeat the steps for unlimited number of devices. If you turn the speaker off during Auracast connection, the speaker will still be in master/receiving mode when turned on again. Leave Auracast by pressing the Auracast button again.

HOW TO USE AURACAST

When the receiver and the master are paired successfully, the receiver sends out a prompt tone. When connected, the master controls the receiver and the controls on the receiver will not work. Press the Auracast button (4) on the back of the speaker to leave Auracast mode.

MONDO APP

Simply download the MONDO app and you will get help with the settings and instructions in the app. You can use the app for EQ-settings and as a remote for your speaker among other features.

CHARGE THE SPEAKER

Plug the USB C-C charging cable with the USB-C port on the speaker. This product comes with a high power USB-C cable and requires at least 25W power adapter to charge.

WARNING!

- Do not attempt to repair the speaker. A faulty repair may lead to fire, electronic breakdown or a damaged product.
- Do not use the speaker in an environment where the temperature is below 0°C or above 45°C
- Avoid using a device indicator light near the eyes of children and animals.
- Do not use the speaker in thunderstorm weather to avoid abnormal speaker behavior and the risk of shock.
- Do not wipe the speaker with oil or other volatile liquids.
- Do not wet the speaker

TWO YEAR WARRANTY

MONDO products are designed and manufactured to meet high standards. We offer a two-year warranty from the date of purchase against manufacturer defects according to current EU warranty legislation.

HOW IT WORKS

If you experience a defect within the warranty period, return the product to your authorized dealer with the original proof of purchase. If a manufacturing defect is identified, the dealer will replace the product. If the same product or color is unavailable, MONDO will provide a new product. This warranty does not cover abuse, misuse, ordinary wear and tear, incorrect connection, force majeure, or unauthorized repair

Additional Information: Spare parts and repairs will be available at a reasonable price post-warranty period where applicable.

You have the right to a replacement with a refurbished product if repair is not possible. This warranty does not affect your legal rights under applicable laws.

Environmental Responsibility: Do not dispose of this product as household waste. Use designated collection points for recycling electronic equipment.

This product was produced after 1st of June 2024.

COMPLIANCE WITH FCC REGULATIONS

Caution! The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may

cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE SPECIFICATION AND EXTERNAL APPEARANCE OF THE SPEAKER MAY BE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

If at any time in future you should need to dispose of this product, please note that waste electrical products should not be disposed of household waste. Please recycle where facility exist. Check with your local authority or retailer for recycling advice.

EU DECLARATION OF CONFORMITY

Design by a Star AB hereby declares that MONDO Speaker Small complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity:

<https://defunc.com/documents/>

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

MONDOSOUND.COM  MONDO_SOUND  MONDOSOUND