



LEDVANCE LLC
181 Ballardvale Street
Suite 203.
Wilmington, MA 01887

NAED

Multi

PART NUMBER

4395560

ZNP/ZN2

ZNP 4384239

A REV

FINISH

MATTE VARNISH

NUMBER OF COLORS

5

LITHO

DATE

12.1.25

STRUCTURE NUMBER

XXXXXX

This electronic file and derivations of this file
are property of LEDVANCE LLC

GRAPHIC ARTIST

Carlos

LAM DOCUMENT

WCTXXX

An APPROVED proof must be obtained from
Corporate Packaging prior to production

SPOT COLORS



PANTONE ORANGE 021

PROCESS COLORS



OUTSIDE

12.5 X 4.5

1 Installer


Insérer la lampe dans un luminaire.



2 Mode de synchronisation

Mettre la lampe dans le mode de synchronisation en commutant la lampe 5 fois de MARCHE à ARRÊT.

La lampe clignotera quatre fois puis s'atténuera de MARCHE à ARRÊT pendant environ 45 secondes.



ACTIVER
L'INTERRUPTEUR
MURAL 5 FOIS.


3 Synchronisation avec télécommande.



Synchronisez la lampe avec la télécommande incluse en choisissant un groupe (ex. : « Groupe 1 ») pendant environ 5 secondes. La lampe clignotera deux fois pour indiquer qu'elle est synchronisée.

Si vous avez manqué le créneau de synchronisation de 45 secondes, retournez à l'étape 2.

4 Synchronisez d'autres lampes.




Ajoutez une autre lampe en suivant les étapes 1-2.

Vous pouvez synchroniser la lampe dans le même groupe ou dans un autre groupe.

5 Télécommande

Vous pouvez désormais contrôler vos lampes avec votre télécommande. Vous pouvez maintenant changer les couleurs, atténuer ou commuter entre différentes températures de couleur ou encore éteindre ou allumer vos lampes.



GROUPE/
SYNCHRONISATION

ATTÉNUER ET
TEMPÉRATURE
DE COULEUR (TCP)

EFFETS

COULEURS RVB
(16 COULEURS)

TEMPÉRATURE DE COULEUR (TCP)



2700K OPALE
3000K BLANC
3500K BLANC NEUTRE
4000K BLANC FROID
5000K LUMIÈRE DU JOUR
6500K LUMIÈRE DU JOUR DE LUXE

SYLVANIA

QUICKSYNC
POWER. SYNC. CONTROL.



NO WIFI OR
APP NEEDED
WIFI OU APPLICATION
NON REQUIS

QUICK START GUIDE
GUIDE DE DÉMARRAGE RAPIDE

INSIDE

12.5 X 4.5

1 Install


Insert the lamp in a fixture.



2 Syncing Mode

Bring lamp into syncing mode by powering the lamp ON and OFF 5 times

Lamp will blink four times, then fade ON and OFF for about 45 seconds.



TOGGLE
WALL SWITCH
5 TIMES


3 Sync with Remote



Sync the lamp using the included remote by selecting a group (i.e 'Group 1') for roughly five seconds. The lamp will then blink twice indicating it has been synced.

If you missed the 45 second sync window, return to step 2.

4 Sync more Lamps



Add another lamp by following steps 1-2.


You can sync the lamp to the same group, or to another group.



Symbol meaning: Warning: Contains coin battery.
Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate. Even used batteries may cause severe injury or death.
Call a local poison control center for treatment information.
Battery Type: CR2025, Nominal Voltage: 3.0 Volts.
Non-rechargeable batteries are not to be recharged.
Do not force discharge, recharge, disassemble, heat above 60°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
Ensure the batteries are installed correctly according to polarity (+ and -).
Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.
PK-00112708-2

5 Remote Control

You are ready to control your lamps with your remote. You can now change colors, dim or switch between various color temperatures, as well as turning your lamps ON or OFF.



GROUP/SYNC

DIM & COLOR
TEMPERATURE
(CCT)

EFFECTS

RGB COLORS
(16 COLORS)

COLOR TEMPERATURE (CCT)



2700K SOFT WHITE,
3000K WHITE
3500K NEUTRAL WHITE
4000K COOL WHITE
5000K DAYLIGHT
6500K DAYLIGHT DELUXE



4395560

Scan for Complete Installation instructions and Warning Details.
Balayer pour obtenir les directives d'installation complètes et les détails sur les avertissements.

WARNING / AVERTISSEMENT

• **INGESTION HAZARD:** This product contains a button cell or coin battery.
• **DEATH** or serious injury can occur if ingested.
• A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
• **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**
• **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

• **DANGER D'INGESTION :** ce produit renferme une pile bouton ou une pile plate
• **LE DÉCÈS** ou des blessures sévères peuvent survenir en cas d'ingestion
• Avaler une pile bouton ou une pile plate peut entraîner des **brûlures chimiques internes** dans les **2 heures** suivant l'ingestion
• **GARDEZ** les piles, neuves et usagées, **HORS DE LA PORTÉE DES ENFANTS**
• **Consulter immédiatement un médecin** si vous croyez qu'une pile a été avalée ou insérée dans n'importe quelle partie du corps.



FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.