

Wireless LED Speaker & Microphone

Model: 28YX03

PRODUCT GUIDE

FCC ID: 2AKI8-BLTMK (Speaker)
FCC ID: 2AKI8-BLTMKMC(Microphone)

Ver.01

In the Box

Wireless Microphone x 1

Wireless Speaker x 1

USB C Charging Cable (11.8in/30cm) x 1

User Manual x 1

Specification

Bluetooth Version: 5.3
Bluetooth Profiles: A2DP/AVRCP/AVDTP/HSP/HFP
Microphone Size: 133.1mm(H) x 37.1mm(W)
Speaker Size: 88.0mm(H) x 95.0mm(L) x 68.1mm(W)
Speaker Driver: 67mm
Operating Range: 10m (unobstructed)
Speaker Battery Capacity: 1200mAh
Microphone Battery Capacity: 500mAh
Speaker Working Time: Approx. 5 hours
Microphone Working Time: Approx. 4 hours
Charging Time: Approx. 3 hours

Warning: Risk of fire, burns, and explosion. Do not open, crush, heat above 45°C, or incinerate the device.

FCC Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Produced for Walmart inc.
Bentoville. AR72716
1-888-516-2630
Website: <https://www.walmart.com/>

Power On/Off

Speaker: Press and hold button for 3 seconds until you hear the "Power on, Bluetooth mode" prompt.
To power off, press and hold button for 3 seconds until you hear the "Power off" prompt.

Microphone: Press and hold button for 3 seconds until the LED indicator lights up blue.
To power off, press and hold button for 3 seconds until the LED turns off.

Bluetooth Pairing

Power on the speaker, it will enter pairing mode automatically.
Enable Bluetooth on your audio device and select "mini karaoke" from the list.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by SHENZHEN SHI JIAHUA LI DIAN ZI YOU XIAN CONG SI. is under license.
Other trademarks and trade names are those of their respective owners.

Button Controls (Speaker)

Volume + / -: Short press.

Play/Pause: Short press.

Volume - Volume +

Next/Previous Song: Press and hold the Volume + or - button for 1 second.

Voice Removal

When connected, short press to toggle original vocals on/off.

LED Light Control

Short press to cycle through 7 colorful LED light modes

Wireless / Wired Mode Switching

Connect 3.5mm AUX cable

Short press M button to toggle between Bluetooth/AUX modes

Voice prompt confirms current mode ("Bluetooth" or "AUX").

*M button is inactive without AUX connection

Button Controls (Microphone)

Next /Previous song:
Press and hold the Volume + or - button for 1 second.

Previous song Next song

* Place microphone gently on hard surface to avoid impact noise.

Voice Effects Switch

Press and hold button to cycle through 6 different voice effects (e.g., KTV, Male to Female, Female to Male, Novelty, Magic, Professional).

Charging

Battery Type: Built-in lithium-ion

First Use: Fully charge before initial use

Charging Method:
Connect USB-C cable between charging adapter or computer

Charging Indicator:
Red LED = Charging
LED off = Fully charged

*Laptop/desktop charging may take longer (5-6 hours)

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, these limits are designed to provide reasonable protection against harmful interference in a residential installation, this equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. May cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warning:
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Troubleshooting

No Power
Charge device for 30 minutes (battery may be drained)

No Sound
Increase volume on speaker/smartphone
Reconnect Bluetooth if disconnected

Intermittent Disconnections
Check battery level (low power may cause drops)
Stay within 10m operating range

Charging Issues
Check cable connection
Try a different cable (current one may be damaged)

Bluetooth Not Found
Ensure pairing mode is active
Remove device from paired list and retry
Restart both devices if issue persists