








<p>Introduction: Thanks for choosing Axilspot Dorado Access Point product. The Quick Installation Guide is designed to guide you through installation and includes warranty terms. For more information please visit Axilspot website: http://www.axilspot.com</p> <p>Statement: ©2016 Axilspot Communication Co., Ltd. All rights reserved. No unit or individual shall extract or copy the contents of this guide or disseminate in any form without the company's written permission.</p> <p>"AXILSPOT" is registered trademark of Shenzhen Axilspot Communication Co., Ltd. Unless otherwise agreed, this manual is used only as a guide, all statements in this manual, information and recommendations do not constitute any express or implied warranty.</p> <p>Contents of this manual are subject to change without prior notice.</p> <p>Axilspot Communication Co., Ltd. Oriental Science and technology building, Nanshan Dist., Shenzhen, CHINA 518000 support@axilspot.com www.axilspot.com</p>	<p>Product Warranty</p> <p>Thank you for purchasing AXILSPOT products. In order to protect your rights, please read the following terms.</p> <ul style="list-style-type: none"> Axilspot warrants that starting from the date of shipment by Axilspot to the original purchaser ("customer"), the purchase price includes a one-year limited warranty for the hardware components. If we determine that the hardware components of a Product do not conform to this Product Warranty during the applicable warranty period we will, at our option, repair or replace the Product, or refund the original purchase price of the Product. Any repaired or replacement products will be warranted for the remainder of the original Warranty Period or Ninety (90) days after receipt of the repaired or replacement product(s), whichever is longer. If the hardware product is purchased from an Axilspot reseller, the reseller will handle and be responsible for the warranty return process for its end users. If the hardware product was purchased directly from Axilspot, the end user will be responsible for the warranty return process. This warranty is provided only to the original end user, and is not transferrable. The warranty ends upon transfer of the hardware product to a new owner. 	<p>Warranty Exclusions</p> <p>This product warranty will not apply if the hardware has been:</p> <ul style="list-style-type: none"> Altered or disassembled by anyone other than us or as authorized by us. Subjected to abnormal physical or electrical stress or misuse. Rebranded, painted for physically modified. Improperly installed or not used according to product operation instruction. Damaged by using third party firmware. Not received by us within 30 days of insurance of the RMA. <p>RMA and Software Upgrade Service Please log on Axilspot website http://www.axilspot.com for detailed RMA process, product information and download the latest software.</p> <p>Special Announcement This service commitment applies to Axilspot products sold out of mainland China. After-sales service provisions agreed separately shall be subject to contract.</p> <p>Note: Axilspot company interpretation and amendments shall prevail within the limits of national laws and regulations.</p>	<p>CE</p> <p>CE Mark Warning This is a Class B Product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures. This device complies with EU 1999/5/EC.</p> <p>NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radio interference, it is recommended to use a shielded RJ45 cable.</p> <p>FC</p> <p>Federal Communication Commission Interference Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio-frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by</p>	<p>turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.</p> <p>IMPORTANT NOTE: FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.</p>	<p>AXILSPOT</p>  <p>Quick Installation Guide 300M Multiservice In-Wall Access Point Model: ASW3U</p>
--	--	--	---	---	--

<p>Package Contents</p> <ol style="list-style-type: none"> 300M Multiservice In-Wall Access Point 1PCS Quick Installation Guide 1PCS KA3 Screw 4PCS PM4 Screw 2PCS <p>115.00 mm</p>	<p>Product Overview</p>  <p>LED Status</p> <ul style="list-style-type: none"> Solid: The device is connected to power Blinking: The device is functioning correctly Off: Power is not supplied to the device or the device is malfunctioning 	<p>Installation Steps</p> <ol style="list-style-type: none"> Unclench the coverplate with a straight screwdriver  <p>Unclench here</p> <p>Split the device into two parts</p>  <p>Main Body Cover Plate</p>	<ol style="list-style-type: none"> Connect the telephone wire and Ethernet cable  <p>Telephone wire Telephone wire interface PoE connector PoE interface</p>	<ol style="list-style-type: none"> Put the device into the outlet box and fix it with screws  <p>Install Method 1 Install Method 2</p>	<ol style="list-style-type: none"> Put on the coverplate  <p>Installation Complete</p> <p>72.00 mm</p>
--	--	---	--	--	--