




Front of EUT

Label Location

**The label will be visible to the users
as they install the SIM card.**