

SPECIFICATIONS


MODEL	OGT-6BT
Woofer Type	6.5" Polypropylene Cone
Tweeter Type	0.75" Mylar Dome
RMS Power	50W
Frequency Response(± 3 dB)	65Hz - 20kHz
Bluetooth Version	V4.1
Bluetooth Distance	10m
Power Supply	DC 24V/2.5A
IP Level	IP 56
Product Dimension(mm)	340*250*260

CARE AND MAINTENANCE

Make sure to turn all equipment off before cleaning. The cabinet only needs occasional dusting. Please do not touch the drive units. Do not clean the speaker with chemical solvents as this may damage the paint surface. Clean with a dry cloth.

BLUETOOTH GARDEN ROCK SPEAKER

OGT-6BT




SAFETY INSTRUCTIONS

- 1 Read the instructions carefully before installation and use. And keep the manual safe for future reference.
- 2 When the speakers are installed outdoor, ensure the environment is reliable and that the speaker is firmly attached. Do not use the product submerged in water.
- 3 Do not touch or bump the woofer and tweeter. If these are damaged, the sound will be distorted.
- 4 Protect the power cable from being damaged, do not over stretch cable.
- 5 Do not listen to sound at a very high level when you are changing the input source (for example, to tune FM / CD). Installation or removal of cables should make sure that the power amp / amplifier device radio is turned off.
- 6 Turn off the power to the speaker when unused for long periods of time.

PACKING LIST

Please check to ensure all the parts shown below are included. If any parts of the speaker appear damaged, please contact your local distributor for assistance.




CONNECTIONS


Setup and Pairing

Note: Ensure the Bluetooth speaker is connected to the power supply and turned on.


1. Open the setting menu and select Bluetooth



2. Turn on Bluetooth and search devices



3. Click "Rock BT Speaker" and pair the Bluetooth speaker with your device



Connecting Devices

If other devices (such as laptops, tablets, phones, etc.) want to play through the Bluetooth speaker, please follow the setups below:

1. First Connection: if Device A connects and controls to Bluetooth, Device B cannot search or control the Bluetooth speaker. Device A MUST no longer be connected, then Device B can connect and control.

2. Additional Devices: If additional devices want to connect to Bluetooth speaker, a maximum of 2 devices can connect at any one time, only the 1st device to connect controls the speaker. Please ensure devices A or B are disconnected before trying to connect additional devices C, D, E, etc.

Note: If your connection to speaker is lost, the device maybe be out of range (>10m). To reconnect simply go to setting menu on the home screen on your device and reconnect to Bluetooth speaker.

Troubleshooting

If a problem arises, please try the troubleshooting frequently asked guide below.

Q: Speaker has not been found during setup

A: Please check power cord is correctly connected to speaker and transformer. Before commencing any electrical work ensure the supply is switched OFF at the mains.

Q: Speaker has failed to connect to Bluetooth

A: Please retry setup and pairing process, follow setup steps 1 - 3 to connect device. Ensure the device is within 10m range.

Q: Device is connected to Bluetooth speaker but no sound

A: Ensure your device volume is NOT muted, increase the volume.

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.