



Security. Made Pro.

Quick Start Guide

(EN)


annke.com

Welcome to ANNKE!


Your security is our priority.
If you have any questions, please contact us
anytime, we'll get back to you in 24 hours.

 support@annke.com
 <http://help.annke.com>


1. What's in the Box



Battery Camera



Solar Panels



Solar Panels Bracket




Type-C Power Cable



Quick Start Guide




Surveillance Sign



Screw Pack

Note: The packing list is for reference only, please refer to the actual product.

2. Product Description



3. Download and install the APP


Download and install the free " **Annke Sight** " from the Google Play Store or App Store, create an account and login.

Note: Please allow the APP to obtain relevant permissions, such as Location, Bluetooth, Storage, Notification, Microphone, Speaker, etc. Otherwise, the device cannot be added normally, affecting your user experience.






4. Added camera to APP

Before adding a device:

1. Make sure your wireless router has DHCP enabled and has no restrictions on new devices accessing it.
2. The WiFi password should be no less than 8 characters, no more than 20 characters and no special characters..
3. Turn on the camera power switch, wait for the camera to start, the red indicator light starts flashing and a configure prompt sound is heard.




Click the " **Add smart Device** " or " **+** " icon, operate according to the prompts on the APP interface and complete adding the camera.






Note: If the camera fails to be added, please check the WiFi information and status, and reset the camera to restart and try again.

5. Micro SD card settings

1. Turn off the camera, open the waterproof cover at the bottom of the camera, find the Micro SD card slot, and insert the Micro SD card into the slot in the correct direction.





2. Turn on the camera, enter the APP preview interface, and enter the camera settings. You can check the micro SD card status and formatting in the storage settings.



6. Added camera to Wireless NVR

Before adding a new camera, please make sure that the NVR has a free channel. Turn on the camera power switch and wait for the startup to complete.

Right-click the mouse and click **[Camera]**, click **[+]** to make sure the new camera has been started normally, click **[Continue]** to enter the camera adding interface, the NVR will automatically search for and add the new camera nearby, and after it shows that it has been added successfully, click **[Continue]** to enter the Preview interface, and click **[Continue]** to exit.





Note: If the camera cannot be found, reset the camera and try again.

7. Added camera to Touch Screen NVR

Before adding a new camera, please make sure that the NVR has a free channel. Turn on the camera power switch and wait for the startup to complete.

Press  - [Match Code] - [Match Code], the system automatically searches for and adds new cameras.


Note: If no video is displayed on the screen, please reset the camera and try again.



For more connection methods, please contact support@annke.com


8. Installation the Camera

- A. Confirm that the surface of the object on which the camera is mounted can withstand three times the weight of the camera and the bracket.
- B. Confirm that the WiFi signal at the camera location is stable.
- C. Choose a position 2 to 3 meters from the ground.
- D. Fix bracket to installation position.
- E. Mount the camera on the bracket.



9. Installing and connecting solar panels

- A. Find a location that receives enough sunlight and is not shaded and at a suitable distance from the camera. (This distance depends on the length of the solar panel wire)
- B. Confirm that the surface of the mounting object can withstand 3 times the weight of the solar panels and brackets.
- C. Install the solar panel bracket and fix the solar panel to the bracket at a certain angle. The ideal angle between the solar panel and the horizontal direction is 45° . (The installation angle is the actual environment prevails)
- D. Remove the waterproof rubber plug from the camera's Type-C Power Port and plug the solar panel cable into the camera's Type-C Port.
- E. Please confirm that the solar panel is powering the camera. Launch APP. A charging icon can be seen on the APP when the solar panel is charging the camera.
- F. Maximize the charging efficiency of the solar panel. Regularly wipe the surface of the solar panel with a soft cloth to avoid the influence of dust and other coverings.



About this guide

Thank you for purchasing this device! This guide is designed for the installation and operation of this product. You can get more information about the features and functions of this product in details. Please read this manual carefully before using. The information contained in the guide is subject to change, without notice, due to firmware updates or other reasons. If you have any questions, please feel free to contact us at support@annke.com.

LEGAL DISCLAIMER

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. OUR COMPANY SHALL NOT TAKE ANY RESPONSIBILITY FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, OUR COMPANY WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS THE APPLICABLE LAW. OUR COMPANY SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES. IN THE EVENT OF ANY CONFLICTS BETWEEN THIS GUIDE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Regulatory Information

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Warning Statements:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.

EU/UK Compliance Statement



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2014/30/EU, the LVD Directive 2014/35/EU, the RoHS Directive 2011/65/EU, Wi-Fi device: the RE Directive 2014/53/EU.



This product and - if applicable - the supplied accessories too are marked with "UKCA" and comply therefore with the following directives: Electromagnetic Compatibility Regulations 2016, Electrical Equipment (Safety) Regulations 2016, the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012, Wi-Fi device: Radio Equipment Regulations 2017.



Directive 2012/19/EU (WEEE Directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.

According to the Waste Electrical and Electronic Equipment Regulations 2013: Products marked with this symbol cannot be disposed of as unsorted municipal waste in the United Kingdom. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.



Directive 2006/66/EC and its amendment 2013/56/EU (Battery Directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info.

According to the Batteries and Accumulators (Placing on the Market) Regulations 2008 and the Waste Batteries and Accumulators Regulations 2009: This product contains a battery that cannot be disposed of as unsorted municipal waste in the United Kingdom. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info.

Warnings and Cautions

Safety Instruction: These instructions are intended to ensure that the user can use the product correctly to avoid danger or property loss.

Laws and Regulations: The device should be used in compliance with local laws, electrical safety regulations, and fire prevention regulations.

Electricity: In the use of the product, you must be in strict 10 compliance with the electrical safety regulations of the nation and region. The equipment shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the equipment.

Fire Prevention: No naked flame sources, such as lighted candles, should be placed on the equipment.

Emergency: If smoke, odor, or noise arises from the device, immediately turn off the power, unplug the power cable, and contact the service center.

Power Supply: Device powered by Safety Extra-Low Voltage(SELV): The power source should meet limited power source or PS2 requirements according to IEC 60950-1 or IEC 62368-1 standard. Device powered by AC mains supply voltage: The equipment must be connected to an earthed mains socket-outlet.

White Light Illuminator (If supported): Possibly hazardous optical radiation emitted from this product. DO NOT stare at operating light source. May be harmful to the eyes. Wear appropriate eye protection or DO NOT turn on the white light when you assemble, install or maintain the camera.

Using Environment: DO NOT place the camera in extremely hot, cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.

Installation: Install the equipment according to the instructions in this manual.

Transportation: Keep the device in original or similar packaging while transporting it.

System Security: The installer and user are responsible for password and security configuration.

Maintenance: If the product does not work properly, please contact your dealer or the nearest service center. We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.

Cleaning: Please use a soft and dry cloth when clean inside and outside surfaces of the product cover. Do not use alkaline detergents.

Reflection: Make sure that no reflective surface is too close to the device lens. The IR light from the device may reflect back into the lens causing reflection.



Manufacturer: Shenzhen Kean Digital Co., Ltd

Address: Room 1001, Rujun Building, No. 105, Zhongxing Road, Ma'antang
Community, Bantian Street, Longgang District, Shenzhen, 518129, China.

Email: support@annke.com

Help Center: help.annke.com



Made in China