



LED SIGNALLING

BLUE LED = HEADLAMP INTENSITY LEVEL



LED SIGNALLING

BACKSIDE LED = DEVICE IN CHARGE



LED SIGNALLING

GREEN LED = BATTERY LEVEL



LED SIGNALLING

RED LED = HEADLAMP UNCONNECTED
OR FAULT