

titancore6^{BASIC}

SIMPLE MANUAL




titancore6^{BASIC}

SIMPLE MANUAL




Installation instructions Step 1

1 How to use as a router




It is possible to connect with your existing router.
Connect the router and TiTAN Core with a LAN cable as shown in the figure.

2 How to use it with a wired Internet




Another way is to connect the wired Internet jack directly to the TiTAN Core.
Please choose one of the above methods depending on your preference.

2 Installation instructions Step 2




Connect HDMI (①) to TiTAN Core HDMI port and connect the other end to the TV (②)

3 Select Source



After turning on the TV, select the external input device that you connected.

3 Remote Control Info.



4 Product Warranty

Warranty period is 1 year

Product name	titancore6BASIC		
--------------	-----------------	--	--

Model	CWO-300		
-------	---------	--	--

Purchase date	20	year	month	date
---------------	----	------	-------	------

Customer name				
---------------	--	--	--	--

- For product repair, you must present warranty card with the date of purchase to get full service,
- If there is no warranty, the warranty period will be based on dispute resolution standards based on the month or date of production.
- Please note that the warranty will not be reissued so keep it safe.

1. This product is manufactured through strict quality control and inspection process .
2. If any defects or natural defects occur during the warranty period, we will repair the product free of charge.
3. Warranty period is 1 year.
4. Be sure to present this product warranty when applying for repair.
5. You will be asked to pay expenses for the following cases.
 - ① If the warranty has expired
 - ② Even during the warranty period if the malfunction occurs due to user's carelessness
 - ③ If you do not provide a warranty or can not verify your product due to missing key details
 - ④ If the product malfunctions due to natural disaster
 - ⑤ If the warranty period is specified for each part
 - ⑥ If the product malfunctions as a result of modifying the product
 - ⑦ If consumable parts run out

5 Troubleshooting

Q TiTAN Core does not respond to the Remote Control

- A**
- Aim the remote control directly at the sensor on the front of the TiTAN Core.
 - Reduce the distance to the TiTAN Core.
 - Replace the batteries in the remote control.

Q Player does not respond to some operating commands during playback

- A**
- Operations may not be permitted. Refer to the user manual.
 - Possibility of system halted, re-insert with power adaptor to restart.

Q The contents of the USB flash drive cannot be read

- A**
- The USB flash drive format is not compatible with the TiTAN Core.
 - If one of the USB can not be read, Please turn off the TiTAN Core for 30seconds and restart TiTAN Core.

Q Slow operation of the USB flash drive

- A**
- Big file size or high resolutios USB flash drive takes longer time to read and display on the TV screen.

Q No sound with HDMI connection

- A**
- Check the connection between the TV and the HDMI jack of TiTAN Core.
 - Check your TV system setup.
 - Check the volume.

Q The TV screen is blank and the player LED is blinking

- A**
- Turn off your TiTAN Core, wait 30 seconds, turn it on again.
 - If under HDMI status, check if HDMI connection is correct or change HDMI cable set the output resolution of this TiTAN Core into 720p.

Specification

OS: Android 7.1

Wifi: 802.11 b/g/n 2.4GHz

Bluetooth: Bluetooth 4.0

Resolution: Maximum resolution is 4K @ 60fps

Power : DC5V / 2A

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

The product should be installed to provide a separation distance of at least 20 cm from all persons.