

240mm

60mm

44.8mm



Bluetooth selfie stick

Step1

Press on the button for 3 seconds until the blue light flashes, and the device will enter bluetooth pairing mode.



Step2

Turn on the bluetooth on your mobile. It will turn up “Gelish” after starting bluetooth searching. The mobile and monopod will match automatically by clicking “Gelish”.




Step3

Rotate the mobile clip for 270 degrees and then hold the two sides of the monopod to stretch slowly step by step.




Step4

Put the mobile into the clip and turn on the camera function on mobile to take picture by pressing the camera button on monopod.



Step5

Rotate the mobile clip back, then hold the bottom of extension holder and press it with your thumb. Take the other side of the holder up to the hard part, then draw it back slowly.



Specification

Battery Parameters:

Battery Capacity-----60 MAH

Standby time-----72 H

Working time-----20 H

Charging Voltage-----5V

Charging current-----120 MA

Charging time-----0.5 H

Product Parameters:

Total Weight-----150 G

Length-----80 CM

LE D and the function

Material-----Stainless steel

Packing dimension-----250*60*40 MM

LED1 Charge idicator

Red light appears when recharging, and disappears when recharging finished.

LED2 Bluetooth matching

Blue light flashes when bluetooth searching and matching. Blue light will be off when bluetooth matched.

LED3 Photo indicating lamp

The light blinks blue when taking pictures.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.