材质工艺：80g哑粉纸，单黑，骑马钉
成品尺寸：70*120mm

SMART GLASSES

GJ03A

User’s Manual

Please read this manual carefully before using the product and keep it safe.

Product Introduction

This smart glasses is a glasses-shaped smart audio device that provides you with a comfortable all-day audio experience and supports call and on-the-spot recording functions.

Package includes



Instructions for use

Pairing preparation

1. Turn on the glasses and con□m that the white indicator light□flashing.
a. Press and hold the independent button on the right temple for 3 seconds to turn on, and wait for the glasses to turn on.
b. Double-click the button - Record. The white indicator light on the glasses will □ash, and you can proceed to pair them.
2. After the glasses are turned on, the white indicator light des not □ash, press and hold the independent button on the right temple for 10 seconds to reset the glasses, and the white indicator light of the glasses□ashes, you can pair them.

Paired connection

1. When the glasses are worn (not charging), after completing the pairing preparation, close to the phone.
2. Turn on Bluetooth on your device (e.g. mobile phone), search for and select "FancyView Y1".
3. After successful connection, a corresponding beep will sound in the glasses.

Charge

To ensure proper charging, please connect the charging cable as shown in the picture below, please note that the charging area at the tail of the left temple is in the correct direction and close to the charging head, and the charging cable is connected to the power supply.
a. Charging - red light.
a. Charging - orange light responds all the time.
b. Glasses are fully charged - the indicator light goes o□.
c. Low battery: Less than 20% of the glasses broadcast a prompt tone, and the APP will pop up a prompt window. Below 10% of the glasses play a prompt tone again, and the APP pops up a prompt window.

Factory reset

When the glasses are powered on, press and hold the button on the right temple for 10 seconds, and the glasses will be restored to factory settings after hearing the prompt sound and the white indicator light □ashing.

Control glasses

1. Trackpad gestures
① Media Control (Music Playback): One-□finger double-tap to con□ play/pause.



② Media Control: Double-click the trackpad with two □ngers to play the next song.



③ Media control: Swipe forward and backward with one □nger to□adjust the volume (swipe forward in the touch area to increase the volume; Swipe back on the touch area to reduce the volume.)



④ Call Control (Inbound Calls): One-□finger double tap - answer.



⑤ Call Control (Inbound Calls): Press and hold with one □nger-Refuse to listen.

⑥ Call Control (Call Status): One-□finger double tap - hang up.



⑦ AI Control (AI Wake): One-□finger long press - AI wake up voice□assistant.

2. Button gestures
a. The glasses are powered on
b. Short press - take a photo
b. Double-click the button - Record
c. Long press for 10 seconds - factory reset
① Glasses are turned o□
a. Press and hold for 3 seconds - Power on



*You can customize some of the above gestures.

Download the App

Scan the QR code below to download and install the app to get interop settings and more features in the app.

Scan to download the app
(Requires Android 8.0 or iOS 13.0 and above)

Function usage

Photo album (photo/videography)

To import photos and videos to the mobile app album, you need to connect the glasses Bluetooth "FancyView Y1" and the WLAN "GJ03A_xxx"

AI voice assistant

1. Wake up AI voice assistant
a. Voice Activation: Say "Hi CoCo" to wake up the AI voice assistant.
b. Trackpad Wake-Up: Long press the trackpad with one □nger to□wake up the AI voice assistant.

2. Control devices with voice assistants
a. What is there to do in Beijing?
b. How the weather like today?
c. What's in front of me?

3. □ □ One voice commands
a. Control music: play music, continue playing, previous/next, increase volume, decrease volume
b. Call control: answer the phone, hang up the phone;
c. Shooting: Open the photo and start recording;

Basic parameters

Product weight: 45g
Wireless Connectivity: BLE 5.4 + BT 3.0
RAM: 16Gb
Camera: 800Wpx (photo) / 1080p (videography)
Battery capacity: 200mAh
Waterproof rating: IP65

Safety precautions

- To prevent possible hearing damage, do not use high volume for long periods of time.
- This device cannot be used for direct observation of the sun; it cannot be used to protect against artificial light sources, such as sunbathing injuries. It cannot be used to protect the eyes from mechanical damage.
- Do not use this product when exercising strenuously to avoid accidental injury.
- Sunglasses are not suitable for driving and walking in low light;
- Sunglasses, please use them with caution in tunnels, dark places and other special environments that affect vision; It is not suitable for driving and driving in dim light.
- Comply with the relevant regulations of your region or country, and use this device with caution when driving.
- It is not recommended to wear the display lens for a long time, it is recommended that you replace the lenses or □ce lenses suitable for your wearing power in time after purchasing glasses;
- If you need to replace the lenses, it is recommended to go to a professional store for replacement, and do not try to disassemble and assemble the lenses by yourself, which may cause damage to the device due to improper operation;
- If you need to adjust the nose pad, please go to a professional optical store for adjustment, improper adjustment of the nose pad may cause damage to the nose pad;
- Do not clean lenses with warm or hot water;
- Please avoid storing it with metal items that are prone to scratching;
- Plastic materials and lenses are not heat-resistant, please avoid using, them in high temperatures (such as saunas, etc.) or storing them (such as on the dashboard of vehicles) to avoid deformation or cracking;
- Do not use near heat sources such as radiators, heaters, □ame□ other heat-generating equipment, or in environments with too high or too low temperatures;
- Please use this device within a temperature range of 0°C to 45°C, and store the device and its accessories within a temperature range of -20°C to 45°C. Exposure to extreme temperatures may cause the frame to deform or the device to malfunction;
- Do not block the speaker hole and microphone hole, follow the instructions for use;
- This product is equipped with a built-in battery that is not removable, and there is a risk of explosion if the battery is not replaced properly, so please do not disassemble the device by yourself;
- Do not disassemble, impact, squeeze, or cut the battery, as this may result in an explosion; The battery must not be exposed to excessive heat such as sunlight, □re-roasting, or similar overheating;
- Do not place the battery under very low air pressure, as this may cause the battery to explode or leak □flammable liquids and gases;
- If the battery is severely swollen, do not continue to use;
- If you think the battery may have been swallowed or placed anywhere on your body, seek medical attention immediately;
- Please do not throw the battery into household garbage for disposal, and please abide by the corresponding national regulations to safely dispose of the used battery;
- Please do not disassemble or modify the equipment (including replacing the built-in battery) and accessories without authorization, otherwise the equipment and accessories will no longer be within the scope of the warranty. If necessary, please contact after-sales service when the equipment fails;
- If you feel skin discomfort or allergic reactions when wearing due to individual di□erences, please stop wearing it immediately and□consult a doctor;
- Do not use other chemical solvents or detergents to clean this product;
- If you need to adjust the nose pad, please go to a professional optical store for adjustment, improper adjustment of the nose pad may cause damage to the nose pad;
- Avoid storing with metal items that can cause scratches;
- If this device and its accessories are accidentally touched with water, please wipe them as soon as possible and place them in a ventilated and cool place to wait for drying, and do not use or charge them again until they are completely dry;
- The charging cable is not waterproof, pay attention to cleaning the charging contact point of the temple and the metal head of the charging cable before charging, and wipe it in time if there is any moisture residue to avoid short circuit;
- This device does not support rinsing, do not rinse the temples directly or perform ultrasonic cleaning;
- The product and its accessories may contain small parts, so keep the product and accessories out of the reach of children to avoid a□ocation or other hazards or damage to children.

The name and content of harmful substances in the product

Part name	Hazardous substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Mainboard	×	○	○	○	○	○
Plastic housing	○	○	○	○	○	○
Built-in metal parts	×	○	○	○	○	○
Magnetic charging cable	○	○	○	○	○	○
Battery components	○	○	○	○	○	○

This form is prepared in accordance with SJ/T 11364.
○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements stipulated in GB/T 26572.
×: Indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements specified in GB/T 26572.

The numbers in this logo indicate that the battery has an environmental protection period of 10 years under normal use.

The numbers in this logo indicate the environmental protection service of 5 years under normal use.

The eco-friendly service life mark on the part takes precedence over any environmental service life mark on the product that con□icts with it or di□ers from it. All environmental protection periods of this product refer to the safe period during which the user can safely use the product without leakage of toxic and harmful substances.

Product warranty description

Warranty Regulations

The after-sales service for the smart audio glasses is strictly implemented according to the "Consumer Rights Protection Law of the People's Republic of China" and the "Product Quality Law of the People's Republic of China". The specific terms are as follows:
1. Within 7 days from the day after you sign for receipt, the performance failure listed in the "Product Performance Fault Table" of this product will be tested and determined by the after-sales service center, and you can enjoy free return or exchange service;
2. Within 15 days from the day after you sign for the product, the performance failure listed in the "Product Performance Fault Table" of this product will be tested and determined by the after-sales service center, and you can enjoy free return or exchange service;
3. Within 12 months from the day after you sign for the product, the performance failure listed in the "Product Performance Fault Table" of this product will be tested and determined by the after-sales service center, and you can enjoy free maintenance services.

Non-warranty regulations

1. Unauthorized repair, misuse, collision, negligence, abuse, liquid ingestion, and damage caused by force majeure are not covered by the warranty;
2. The validity period of the three guarantees has passed;
3. Damage caused by force majeure;
4. Due to human reasons, the product and its accessories cause performance failures listed in the "Product Performance Fault□Table";
5. Other non-product performance failures listed in the "Product Performance Fault Table".

Prompt

Since the packaging box is needed to ensure the safety of the product during transportation, it is recommended that you keep the packaging box for at least 30 days from the date of receipt.

Product performance failure table

Name	Performance failures
Smart AI glasses	The functions listed in the manual are invalid. The microphone or the speaker is silent, and the touch function has failed. Damage to the main body due to structural or material factors.

Disclaimer:

The illustrations of products, accessories, user interfaces and other illustrations in the instruction manual are for illustrative purposes only and there may be slight di□erences between the reference diagrams and the actual product, please refer to the actual product. The instruction manual is updated from time to time, and the company reserves the right and may make necessary changes to typographical errors, inaccurate information, or improvements to procedures or equipment in this instruction manual at any time without notice, however, such changes will be incorporated into new versions of this instruction.

Warning:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiates radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.
FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device and its antenna must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Warning:
To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
To completely disconnect this apparatus from the AC Mains, disconnect the power supply cord plug from the AC receptacle.
The mains plug of the power supply cord shall remain readily operable.
The device has no intended maximum period of exposure requirement. The device can be used in portable exposure condition without restriction.

使用产品前请仔细阅读本说明书，并妥善保管

产品介绍

这款智能眼镜是一款眼镜形态的智能音频设备，能够为您提供舒适的全天候的音频体验，并支持通话、现场录制功能。



包装内含



使用

配对准备

1. 将眼镜开机并确认白色指示灯闪烁
a. 长按右眼镜上的独立按键3秒开机，等待眼镜开机完成
b. 开机完成后，眼镜白色指示灯闪烁后，可进行配对。
2. 眼镜开机后白色指示灯未□闪烁，长按右眼镜上的独立按键10秒，将眼镜复位，眼镜白色指示灯闪烁后，可进行配对。

配对连接

1. 眼镜处于佩戴（非充电）状态下，完成配对准备后，轻点手机；
2. 开启设备(如手机）蓝牙，搜索并连接 "FancyView Y1" ；
3. 连接成功后，眼镜中响起相应提示音。

充电

为确保充电正常，请按照下图所示连接充电线，请注意左侧镜腿尾部充电区域与充电头方向正确，紧密贴合，且充电线已连接至电源。工作指示灯状态：
a. 正在充电中 - 橙色指示灯一直响应；
b. 眼镜电量充满 - 指示灯熄灭；
c. 电量不足：低于20%眼镜播报一次提示音，APP并弹出提示窗口。低于10%眼镜再次播放提示音，APP弹出提示窗口。

恢复出厂设置

眼镜开机状态下，长按右侧镜腿上按键10秒，听到提示音且白色指示灯闪烁后眼镜即恢复出厂设置。

控制眼镜

1. 触控板手势
① 媒体控制（音乐播放）：单指双击控制播放/暂停

② 媒体控制（音乐播放）：单指三击可播放下一首

③ 媒体控制：单指前后滑动可调整音量（触控区域往前滑动，加音量；触控区域往后滑动，减音量。）

④ 通话控制（电话呼入）：单指双击 - 接听

⑤ 通话控制（电话呼入）：单指长按 - 拒听

⑥ 通话控制（通话状态）：单指双击 - 挂断

⑦ AI控制(AI唤醒)：单指长按 - AI唤醒语音助手

2. 按键手势
① 眼镜开机状态
a. 短按 - 拍照
b. 双击按键 - 录像
c. 长按10秒 - 恢复出厂设置
② 眼镜关机状态
a. 长按3秒 - 开机



*可对以上部分手势进行自定义设置。

下载App

扫描下方二维码，下载并安装App，可在App中获取交互操作设置等更多功能。

扫描下载App
（需要Android 8.0或iOS 13.0及以上版本的操作系统）

功能使用事项

相册（拍照/摄像）

将照片和视频导入到手机App相册，需要连接眼镜蓝牙 "FancyView Y1" 和WLAN "GJ03A_xxx"

AI语音助手

1. 唤醒AI语音助手
a. 语音激活：说出 "Hi CoCo" ，唤醒AI语音助手；
b. 触控板唤醒：单指长按触控板，即可唤醒AI语音助手。

2. 使用语音助手控制设备
a. 北京有什么好玩的地方？
b. 今天天气怎么样？
c. 我前面是什么？

3. 离线语音指令
a. 控制音乐：播放音乐、继续播放、上一首/下一首、增大音量、减小音量；

基本参数

产品重量：45g
无线连接：BLE5.4+BT3.0
内存：16Gb
摄像头：800Wpx（拍照）/ 1080p（摄像）
电池容量：200mAh
防水等级：IP65

安全注意事项

- 为了防止可能的听力损伤，请勿长时间使用高音量；
- 本设备不能用于直接观测太阳;不能用于防护人造光源，如日光浴的伤害;不能用于防护眼睛免受机械性伤害。
- 进行剧烈运动时，请勿使用本产品，以免因意外带来人身伤害;
- 墨镜镜不适合光线昏暗时驾驶和灯照明;
- 墨镜后，在隧道里，黑暗处及光线等影响视觉的环境中，请谨慎使用;不适合光线昏暗时驾驶和灯照明;
- 请于所在地区或国家的相关规定，驾车时谨慎使用本设备;
- 产品标配透明镜片为偏示片，没有度数，仅起到出现时的镜时保护作用，不建议长期佩戴展示片，建议您购买眼镜后，及时更换适合您佩戴度数的镜片或镜片;
- 如需更换镜片，建议到专业的眼镜店进行替换，如自行拆装镜片可能由于操作不当导致设备损坏;
- 如需调整鼻托，请到专业眼镜店进行调整，不当调整鼻托可能造成 鼻托的损坏;
- 请勿用温热水清洁镜片;
- 请避免和易造成划擦的金属用品一起存放;
- 请避免和易造成划擦的金属用品一起存放;
- 本设备及其配件如不慎沾水，请尽快擦拭后放置于通风将原处等待干燥;来完全干燥之前，请勿再次使用或充电;
- 充电线不防水，充电前注意清洁镜座充电接触点与充电线金属头，如有水分残留请及时擦拭，以免造成短路;
- 本设备不支持冲洗，请勿直接冲洗镜腿或进行超声波清洗等;
- 产品及其配件可能包含小零件，为了避免儿童意外或其他危险或损坏请将产品及配件放在儿童接触不到的地方。

产品中有害物质的名称及含量

部件名称	有害物质					
	铅（Pb）	汞（Hg）	镉（Cd）	六价铬（Cr(VI)）	多溴联苯（PBB）	多溴二苯醚（PBDE）
主板	×	○	○	○	○	○
塑胶外壳	○	○	○	○	○	○
内置金属件	×	○	○	○	○	○
磁吸充电线	○	○	○	○	○	○
电池组件	○	○	○	○	○	○

本表格依据SJ/T 11364 的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量在GB/T 26572规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

本设备及其配件可回收利用，请勿将其作为生活垃圾处理，请按照当地政府的相关规定进行处理。

产品保修说明

保修条例

智能音频眼镜产品售后服务严格依据《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行售后三包服务，服务内容如下：
1. 自您签收之日起7日内，本产品出现《产品性能故障表》所列性能故障的情况，经由售后服务中心检测确定，可免费享受退货及保修。
2. 自您签收之日起8日-15日内，本产品出现《产品性能故障表》所列性能故障的情况，经由售后服务中心检测确定，可免费享受换货或者维修服务。
3. 自您签收之日起12个月内，本产品出现《产品性能故障表》所列性能故障的情况，经由售后服务中心检测确定，可免费享受维修服务。

非保修条例

1. 未经授权的维修、误用、碰撞、疏忽、滥用、进液、事故、改动或损毁，因发妇幼、防伪标记；
2. 已超过三包有效期；
3. 因不可抗力造成的损坏；
4. 因人为原因导致产品及其配件产生《产品性能故障表》所列性能故障。
5. 不符合《产品性能故障表》所列性能故障的情况。

提示

因运输过程中需使用包装盒保证产品运输安全，建议您自签收之日起至少保留包装盒 30 天；

产品性能故障表

名 称	性能故障
智能音频眼镜	说明书所列功能失效 喇叭无声、麦克风无声、触控功能失效 因结构或材料因素造成的主体破损

免责声明：

使用说明书中的产品、配件、用户界面等插图均为说明参考示意图，与产品实物可能略有差异，请以实物为准。使用说明书由深圳智探护眼前公司出版，可能随时对本说明书中的印刷错误、不准确的信息更改，或对程序或设备进行改进，不做另行通知。但是，此类更改将纳入到本说明的新版本中。

警告：
本设备符合 FCC 相关第 15 部分的规定。操作须符合以下两个条件：(1) 本设备不得造成有害干扰，(2) 本设备必须接受任何收到的干扰，包括可能导致意外操作的干扰。

对任何未明确地由一方明确批准的更改或修改可能会导致用户操作设备的权限失效。

注意：本设备经测试符合 FCC 相关第 15 部分关于 B 类数字设备的限制。这些限制是为了在安装时提供合理的保护，防止有害干扰。本设备会产生、使用并能射频能量，如果未按照说明进行安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。

如果此设备确实对无线电或电视接收造成有害干扰（可通过关闭和开启设备来确定），建议用户尝试通过以下一项或多项措施来消除干扰：

– 调整接收天线的方向或位置。
– 增加设备与接收器之间的距离。
– 将所设备连接到与接收器所连接的电路不同的电路上的插座。
– 请咨询经销商或经验丰富的无线电/电视技术人员获得帮助。

注意：本设备及其天线不得与任何其他天线或发射器共置或同工作。

本设备已通过评估，符合一般射频暴露要求。本设备可在便携式暴露条件下使用，不受任何限制。

SHENZHEN SMART CARE TECHNOLOGY CO., LTD.

Building 2, Anda Electronic Industrial Park, Heping Community, FuhaiSub-district, Bao'an District, Shenzhen.
fancyviewai.com