

140mm

3mm

85mm




Please read this manual carefully before using the product, and keep it in a safe place

Populele Instruction Manual



Populele Accessories



USB Cable comes together with Populele

Product Specifications

Model: Populele U1
Specifications: 23-inch Ukulele
Panel: Grade A Spruce Panel+ Imported European Maple Dorsal Panel
String: Italy Aquila imported nylon string
Fretboard: ABS
Nob: Black matte metal fully enclosed nob
Nut: Cattle Bone
Bridge: Rosewood
Bluetooth: Bluetooth 4.0 BLE
Battery capacity: 800mAh Lithium Battery
Charging time: about 2.5 hours
Full bright time: about 10 hours
Charging interface: Micro USB
Supporting devices: Andriod systems above 4.3 (support for bluetooth 4.0BLE)
iPhone 4S
iTouch and above (IOS 8.0 above)
Net Weight: 0.5kg
Packing: Kraft paper box

Product Precautions

1. Do not place your Populele in a damp or dry place.
Such as set next to a stove, or exposure to the sun
Humidity or dryness can cause the neck of Poputar to be deformed or cracked.
2. Do not freely display your Populele directly against the wall to avoid accidental damage to the Poputar.
3. Do not disassemble the charging device to prevent damage to the Populele circuit.

I'm fun, and you?

How to charge Populele

1. Connect the USB charging cable to Populele and plug the adapter to the power outlet
2. Once the battery fully charged, the led lights on the fretboard of your Populele will flash constantly



Application for Populele

scan the QR code and choose the APP for your IOS or Android devices




Populele customers will have three months VIP membership for free

Games in the APP are free of use permanently

If there is any change, please refer to the latest version

Connect Populele with APP

1. make sure your bluetooth is on before connect Populele to your device
2. Push and hold the power button for 5 seconds on the side of your Populele
3. Login the APP enter the Bluetooth interface> select your populele device>wait for Bluetooth connection> connection is success.



5. Flashing of the led light on the lower left side of the fretboard indicates low battery and bluetooth is not available at this situation. Charge the battery immediately.

Please refer to the latest version

Warranty Description

This warranty covers the populele sold in mainland China (excluding Hong Kong, Macau and Taiwan)

7 days from the first date of purchase, you will be able to ask for exchange refund or repair if there is any performance issues associate with your populele.

Name	Warranty Period	Performance Failure
Populele	1year	1.The functions listed in the manual are malfunction 2.LED lights on the fretboard partially or completely malfunction 3. Unable to turn on the device, can not properly connect the populele with the phone 4.Damage to the body of your populele due to the structure design and material. 5. Battery malfunction

Warranty Exceptions: (Under the following circumstances, the product will not be in the scope of services within the warranty coverage)

Warranty expired

Issues caused by inappropriate using of the product.

Failure to follow the "product manual" requirements of use, installation, maintenance, damage caused by maintenance.

Improper use, misuse, collision, abuse, ingress, accident, alteration, tearing, alteration, or inability to identify product labels, seals and serial numbers (IMEI)

Damage due to force majeure such as floods, fires, lightning strikes.

Guitar malfunctions or accidents caused by the use of non-genuine accessories or improper use of the accessories.

Certification of Warranty

Customer Information

Name _____ Contact Phone _____

Address _____

Zipcode _____ Email _____

Product Information

Populele model identification (product serial number can been located in the internal identification card)

Sellers

Name _____ Contact Number _____

Date of Sale _____ Invoice Number _____

Repaire Record/ Contact Method

Repaire Date	Cause of Defect	Name and Type	Diagnostic Date	Signature of Technician

Please store your warranty certificate in a safe place

Customer Service: 010-56287722

Official We-Chat: popular2016

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.