


User Manual



Touch Lamp portable Speaker

Playing time after fully charged:

10 hours music playing for normal 70% volume, 20 hours lighting lamp on highest brightness

Power switch button:

Push the switch button to "ON/OFF" which is to turn on / off the device. The speaker will first enter Bluetooth Mode. After the boot, light will be on by soft touch. Bluetooth Mode will instantly switch when click the Mode button icon (TF Card Music Playing will automatically switch when inserted TF card). Voice prompts will sound before bluetooth pairing and TF card music playing.

Button icon:

1, Mode icon:

achieve bluetooth mode and TF Card music playing, lighting mode changing freely

2, Bluetooth music mode:

Short press "▶▶ + " to play the next song and long press to volume up.

Short press "▶▶ - " to play the previous song and long press to volume down.

3, Hands free calling:

Answer and hang up the phone:

There will be an alert sound from the speaker when there is a phone call. Click "▶▶ + " to answer the call, and click "▶▶ - " again to hang up.

4, TF card music playing:

Enter TF card music playing mode automatically when TF card inserted.

Short press "▶▶ + " to play the next song and long press to volume up.

Short press "▶▶ - " to play the previous song and long press to volume down.

Music playing or pause by click

Bluetooth mode will switch by click the MODE button when on TF card music playing mode.

5, AUX IN audio input mode:

Inserting the 3.5 mm aux in cable, the speaker can be an external audio when connected with a mobile phone, PC, tablet, mp3.

In Aux in audio input mode, "▶▶ + " to volume up 2, "▶▶ - " to volume down, "▶▶ + " For the mute button.

In any mode, when inserted 3.5 mm audio in cable, the speaker self-identified and automatically switch to audio input mode.

Indicator light:

1, Bluetooth indicator:

automatically once it is turned on.

2. If the speaker has not been connected with Bluetooth devices before, it will enter pairing mode, click connecting is achievable.

3. Other phones or tablets can not be connected with the Bluetooth speaker when the speaker is being connected with a phone or tablet.

4. The phone or tablet can not be connected with the Bluetooth speaker if it is connected with other Bluetooth devices. You should turn off your Bluetooth connection and connect your phone with the Bluetooth speaker again.

Lamp function

Long Press the switch of the speaker on the bottom. Turn on the light by tap the mesh on the top, and the lamp will light on in the dimmest grade one. The brightness can be adjusted by tap the top mesh, and there are 3 brightness grades: low brightness, intermediate brightness, and high brightness. Tapping the top mesh when in high brightness, the light will be off. In any mode, change loudspeaker, can switch between the warm light and modes of lights, lights mode point horn network are red, green, blue, orange, indigo, purple, breathing lamp, rhythm of the lamp. Can follow music rhythm beating rhythm, etc.


Frequently Asked Questions

Questions	Solutions
Unsuccessful pairing and connection repeatedly	1. Check the speaker and make sure it is in the searching state or reboot the speaker. 2. Connection is difficult when there are too many Bluetooth devices nearby. Turn off other Bluetooth devices. 3. Turn off the Bluetooth device that was connected with the Bluetooth speaker last time, and reconnect the speaker.
Muted or distorted sound	1. Check the volume of your phone or the speaker, and adjust the volume. 2. The battery is low. Please charge it.
Choppy music play	1. Check if the device is beyond the effective connection distance. 2. Check if there is any obstacle between the speaker and your device.
The indicator not shining in Bluetooth mode	1. The battery is low. Please charge it. 2. Please reboot the speaker.
Low power continuous beep	1, please recharge the speakers.

User Manual

Thank you for choosing us. Please read this user manual before using the speaker.

Operation Image:



Material	ABS+METAL
Lamp Power	1.6w
Lumen	160lm
Color	Warm white
LED Size	2835
Battery Li-Ion	3.7V
Speaker output power	3W
Driver Unit	Ø 52mm, 40mm, 3W
Frequency Response	50HZ-20KHZ
Transmission Range	10 meter
Product dimension	Ø 95mm*122mm
Audio Input	3.5mm jack cable
frequency	2.4 GHz-2.48GHz
Input power	Input DC5V/500mA

The Bluetooth indicator light will flash rapidly when in pairing state, the blue light flash slowly means bluetooth connected, the speaker enter bluetooth music playing.

2, TF card music playing indicator:

The speaker enter TF card music playing when blue indicator light flash in TF card playing mode.

3, Charging:

1. Please make sure the speaker is fully charged in first use. Charge the speaker with the provided USB cable which is compatible with any computer or cell phone 5V output charger. The charge indicator light will be red while charging, then when the battery is fully charged it will turn off.

2. Charge time: about 4 hours

Bluetooth mode:

1, Bluetooth connection:

This speaker supports the bluetooth device with A2DP function. Slide the power switch first, then enter bluetooth mode, bluetooth indicator blue flicker alternately, together with voice prompts, the speaker is in pairing state at this moment, and only in the state bluetooth can be paired and connected successfully.

2, Mobile phone connection:

Step 1: Open the Bluetooth setting on your phone or tablet and click "search device". iPhones will search for Bluetooth devices automatically.

Step 2: you have found the Bluetooth speaker when the screen displays the character "JBL 07", click on it in your device to pair the connection.

Step 3: Enter "0000" and click OK if there is a prompt that requires you to enter a password.

Step 4: The phone or tablet will indicate when the pairing is successful. The character on the display of the speaker will stop flickering.

3, Computer connection:

Activate the bluetooth function first if the computer has bluetooth device. It's necessary to install the bluetooth driver and plug in the bluetooth adapter when there is no bluetooth available.

Step 1: Click the bluetooth icon at the lower right of the computer by mouse right button, choose "device adding".

Step 2: Bluetooth adapter will search for the speaker automatically, and the screen displays the character "JBL 07".

Step 3: The computer will install the driver automatically after double click the character "JBL 07", and display driver install successfully.

Step 4: Double click the bluetooth icon, the speaker connects the computer successfully and be in use. Please check the computer audio device has switched to bluetooth mode or connected well if the speaker still can not play music successfully.

Bluetooth pairing and connection

1. If the speaker has been connected with Bluetooth devices before, it will connect with the last Bluetooth device.

Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.