[illegible]

1. Turn the power switch button to "ON" position.
2. Use the remote control to control the car forward, backward, turn left, turn right

1. The rechargeable battery can only be charged under the adult guardianship.
2. Rechargeable batteries are to be removed before being charged.
3. Exhausted batteries are to be removed before being recharged.
4. Make sure the power is off before installing and recharging the battery.
5. Batteries are to be inserted with correct polarity.
6. Non-rechargeable batteries are not to be recharged.
7. The supply terminals are not to be short-circuited.
8. Always remove batteries from the product when it is not being used for a long period of time.
9. Do not use the battery near a heat source such as fire or heater; it may cause battery explosion and battery leakage.
10. Do not mix old and new batteries. Do not mix alkaline, standard(carbon-zinc) or rechargeable(nickel-cadmium) batteries.
11. Only batteries of the same or equivalent type as recommended are to be used.
12. Please check the battery regularly.
13. Please keep this instruction manual for future reference, it contains important information of the product.

1. Do not submerge the product into water that can damage the electronic assemblies. (If for Amphibious car it can run on the water.)
2. Keep wire and plug away from water.
3. Wipe the product gently with a clean wet cloth.
4. Keep the product away from direct heat and wet.
5. Always remove batteries from the product when it is not being used for a long period of time.

•Warning! Do not touch the running car. Keep hands away from moving parts to avoid injury.

2. Batteries are to be inserted with correct polarity as shown in figure.

3. Please put the rechargeable battery in the battery compartment with correct connection. (Car only)


4. Please lock the battery cover with four plastic parts as shown in figure.

5. The rechargeable battery can only be charged under the adult guardianship.

WARNING

1. Please play the product after closing the battery cover.

2. Please keep battery, and the product plug away from water.



Model B: Alkaline battery

Remote control

The diagram shows the internal battery compartment of Model B. It contains two rows of three AA batteries each. The top row is labeled 1.50VAC, JPAS-1, 1.50VAC, JPAS-1, 1.50VAC. The bottom row is labeled 1.50VAC, JPAS-1, 1.50VAC, JPAS-1, 1.50VAC.

1. Turn the power switch button to "ON" position.
2. Use the remote control to control the car forward, backward, turn left, turn right.

4. Always switch the car and the remote control off when not operating.

BATTERY WARNING

1. The rechargeable battery can only be charged under the adult guardianship.
2. Rechargeable batteries are to be removed before being charged.
3. Exhausted batteries are not to be removed from the product.
4. Make sure the power is off before install and recharging the battery.
5. Batteries are to be inserted with correct polarity.
6. Non-rechargeable batteries are not to be recharged.
7. The supply terminals are not to be short-circuited.
8. Always remove batteries from the product when it is not being used for a long period of time.
9. Do not use or leave the battery near a heat source such as fire or heater, it may cause battery explosion or battery leakage.
10. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
11. Only batteries of the same or equivalent type as recommended are to be used.
12. Please check the battery regularly to avoid battery leakage.

CARE AND MAINTENANCE

5. Always remove batteries from the product when it is not being used for a long period of time.


On/Off button

Throttle trigger (forward/backward)

BATTERY INSTALLATION AND CHARGING

1. Insert the batteries in the battery compartment with correct polarity.
2. Batteries are to be inserted with polarity as shown in figure.
3. Please put the rechargeable battery in the battery compartment with correct connection. (Car only)
4. Please look the battery cover with four plastic parts as shown in figure.

Model A: Rechargeable battery



1. Turn the power switch button to "ON" position.

4. Always switch the car and the remote control off when not operating.

BATTERY WARNING

1. The rechargeable battery can only be charged under the adult guardianship.
Rechargeable batteries are to be removed before being charged.
2. Exhausted batteries are to be removed from the product.
3. Make sure the power is off before install and recharging the battery.
5. Batteries are to be inserted with correct polarity.
Non-rechargeable batteries are not to be recharged.
7. The supply terminals are not to be short-circuited.
Do not connect the batteries from the power source to the load for a long period of time.
8. Do not use or leave the battery near a heat source such as fire or heater, it may cause battery explosion or battery leakage.
9. Do not mix old and new batteries. Do not mix alkaline, standard(carbon-zinc) or rechargeable(nickel-cadmium) batteries.
10. Only the batteries of the same or equivalent type as recommended are to be used.
Please check the battery notices.

CARE AND MAINTENANCE

3. Wipe the product gently with a clean wet cloth.
4. Keep the product away from direct heat and wet.
5. Always remove batteries from the product when it is not being used for a long period of time.

BATTERY INSTALLATION AND CHARGING

1. Insert the batteries in the battery compartment with correct polarity.
2. Batteries are to be inserted with correct polarity as show in figure.
3. Please put the rechargeable battery in the battery compartment with correct connection. (Carry only)
4. Please lock the battery cover with four plastic parts as shown in figure.


Model A: Rechargeable battery

On/Off button

Throttle trigger (forward/backward)

On/Off button

7.3V



Model B: Alkaline battery

Remote control

1. Turn the power switch button to "ON" position.

4. Always switch the car and the remote control off when not operating.

BATTERY WARNING

1. The rechargeable battery can only be charged under the adult guardianship.
2. Rechargeable batteries are to be removed before being charged.
3. Exhausted batteries are to be removed from the product.
4. Make sure the power is off before install and recharging the battery.
5. Batteries are to be inserted with correct polarity.
6. Non-rechargeable batteries are not to be recharged.
7. The supply terminals are not to be short-circuited.
8. Always remove batteries from the product when it is not being used for a long period of time.
9. Do not use or leave the battery near a heat source such as fire or heater, it may cause battery explosion or battery leakage.
10. Do not mix old and new batteries. Do not mix alkaline, standard(carbon-zinc) or rechargeable(nickel-cadmium) batteries.
11. Only batteries of the same or equivalent type as recommended are to be used.

For details, check the battery, recharge and disposal instructions.

CARE AND MAINTENANCE

3. Wipe the product gently with a clean wet cloth.
4. Keep the product away from direct heat and wet.
5. Always remove batteries from the product when it is not being used for a long period of time.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.