

Smart Watch

U8

User Manual

FCC Warning
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there are no guarantees that the use of this equipment in a particular installation will not cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
a) Reorient or relocate the receiving antenna.
b) Increase the separation between the equipment and other equipment.
c) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
d) Consult the dealer or an experienced radio/TV technician for help.
Any changes or modifications to this device not expressly approved by the manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. The device is subject to the following conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including that which may cause undesired operation.

Thank you for choosing our sport healthy intelligent Bluetooth watch. You can read this manual and fully understand the use of the device. In fact, with a taste of the functions and simple method of operation.
This equipment is mainly used brand of intelligent machines is designed to use, machine operation. This device has the following features: support for Bluetooth phone, Bluetooth message push (SMS, micro letter, QQ, etc., need Android to install smart machine above the Bluetooth notification APP), Bluetooth music player, calendar, pedometer, sleep monitoring, anti-lost, remote camera and so on.

Before you start using this device, the first smartphone to install the "Bluetooth notice" (BTNotification) application (support Android version, Apple does not currently support) and run. Bluetooth Smart Watch will be able to automatically synchronize with the time and date of smart phones, and the watch will receive signals from the phone and will be able to receive messages or send reminders, including SMS alerts, chat and QQ, micro letters and other messages and reminders.
Use the "Bluetooth notice" need to open the "Bluetooth notification" service in the smart phone "Accessibility settings", and then in the option "Bluetooth notification" to turn on the service. After the service is turned on, the watch will receive messages or send reminders, including SMS alerts, chat and QQ, micro letters and other messages and reminders.

Use the "Bluetooth notice" need to open the "Bluetooth notification" service in the smart phone "Accessibility settings", and then in the option "Bluetooth notification" to turn on the service. After the service is turned on, the watch will receive messages or send reminders, including SMS alerts, chat and QQ, micro letters and other messages and reminders.
Use the "Bluetooth notice" need to open the "Bluetooth notification" service in the smart phone "Accessibility settings", and then in the option "Bluetooth notification" to turn on the service. After the service is turned on, the watch will receive messages or send reminders, including SMS alerts, chat and QQ, micro letters and other messages and reminders.
Use the "Bluetooth notice" need to open the "Bluetooth notification" service in the smart phone "Accessibility settings", and then in the option "Bluetooth notification" to turn on the service. After the service is turned on, the watch will receive messages or send reminders, including SMS alerts, chat and QQ, micro letters and other messages and reminders.

By registering overseas can log on Google Play, then scan the QR code, or visit the link to download the APK.
<https://play.google.com/store/apps/details?id=com.xiaomi.bluetooth&hl=zh-CN>

The company reserves the right without prior notice to the contents of this manual to make changes.
(1) How to Wear and operate:
Wear this Bluetooth smart watch in the correct direction, the power button should be on the watch when worn on the right side, then touch buttons located beneath the mirror.



- on / off button, exit button: Press on / off, after power in the operating menu short press buttons, refundable clock interface. The clock in the standby screen, press the button lights on and off the backlight.
- touch key at lower left corner: Menu / Enter key: The standby clock interface to access the main menu, as a confirmation key menu operation.
- middle touch key, dial line / flip key: The standby clock interface can enter dial interface, menu operation as the next flip key. Bluetooth when playing music and calls can enter volume adjustment.
- lower right corner of the touch keys, return / hang up button: standby as other, as the return menu operation keys, call hang up button.

In addition, the sliding finger touch can achieve the following functions:
• slide your finger upward the touch screen menu page;
• finger from the top of the screen enter the menu;
• finger down from the top of the screen vertical slider: Exit menu.

(2) Bluetooth devices to connect, disconnect, and confirmed even connection key: watch initiate pairing Bluetooth connection information, confirm the connection, and disconnect the connection. After a successful connection of Bluetooth Smart Watch will automatically send a request requires reading smart phone, phonebook and call log (involving personal privacy, some intelligent machines do not open this feature) Please confirm the smart phone or else the watch can not be synchronized to the phone book and call history will affect its normal use.

If the distance between the watch and smart phones more than 10 meters (middle case no obstructions such as walls, or else shortened distance) will be automatically disconnected within five minutes if the disconnect between the two can be connected also to achieve the distance, the watch will automatically and smart phones continued even otherwise need to manually connect continued.

Watches and smart phones are ringing off the connection is successful and prompt.

- Bluetooth search for Bluetooth devices, connection, disconnection and other operations.

- Dial clock interface point in the middle of the dial at the bottom of the screen to enter the key or menu option to enter dial dial numbers can also be selected via the menu "Call log".

* Do not block the speaker or microphone position during a call.
information can be viewed smartphone received a text message.

- phone book synchronization of the phone book.

- synchronize phone call records of the "missed call", "Failed", "Received Calls", "all talk" and other 30 records.

- Bluetooth smartphone push notifications can view the QQ, micro letters and other information.

- Bluetooth music can play music on your smartphone via Bluetooth.
Some intelligent machines will need to open the music player software to run properly. Because of the screen on the player interface points into the middle of the screen, the watch will automatically stop playing music when the screen is locked. After a successful connection of Bluetooth Smart Watch will automatically send a request requires reading smart phone, phonebook and call log (involving personal privacy, some intelligent machines do not open this feature) Please confirm the smart phone or else the watch can not be synchronized to the phone book and call history will affect its normal use.

- remote camera control via Bluetooth smartphone camera to take pictures. Need the phone off the screen and not in the non-locked state, some smart phones are not finished.

- pedometer
Pedometer designed specifically for those concerned about the health, recommends the use of chess stride gradually state of motion, the magnitude of the normal walking arm, enabling a more accurate count to the number of steps. Top pedometer interface display for time, as the number of steps for the left.

- Window, the top right window distance (meters) below the display of calorie consumption, the middle square button to start / stop switch. The upper right corner of pedometer option, you can set parameters pedometer, reset, view records. Pedometer can run in the background.
to avoid this count, during the initial steps for each user will not show up to start after the show, but also the number of the previous steps counted.
Number steps pedometer steps number displayed window is automatically cleared once a day, in the middle and then stop start pedometer, steps number continues to accumulate, not cleared. For clearing the "Reset pedometer" by selecting the Options menu.
- altimeter displays the current altitude (optional)
- barometer shows the current ambient air pressure and temperature (optional)
- Anti-lost alarm when between Bluetooth Smart watches and smart phones connected over a certain distance, the watch will sound an alarm.
- power saving mode
- setting the clock, the time mode, volume, language, display settings, view battery power, as well as Bluetooth settings and restore the factory settings. Bluetooth smart watch can connect a standard USB data cable, via computer (USB / SDCARD) to transfer data.

The USB port can also be used to exchange data with PC or charge.