


Bluetooth Receiver

User Manual

Contents:

• Receiver Overview -----	2
• Power On/off -----	3
• Pairing-----	3
Get paired-----	3
Connect two Bluetooth Devices at the same time---	3
• Charge-----	4
• The Basics-----	5
Make/Take/End Calls-----	5
Play or pause streaming audio-----	5
• Voice alerts-----	6
• Specifications-----	7

Receiver Overview



Power On/off the receiver

Power On: Press the multifunction button about 3 seconds until the blue and red indicator lights start flashing alternately.

Power Off: Press the multifunction button about 3 seconds until the indicator light goes off.

Pairing

Get Paired The first time you power on your headset, it begins the pairing process.

Press the multifunction button for about 3 seconds until the blue and red lights start flashing alternately.

Turn on the Bluetooth function of your phone.

Search for the Bluetooth devices and select "EasyGo 7"

Enter code "0000" if need.

If pairing is successful, the blue indicator light flash slowly.

Connect two Bluetooth Devices at the same time

Pair the Bluetooth receiver to the first phone.

After paired successfully, turn off the Bluetooth function of the first paired phone.

Power off the Bluetooth receiver and power on again to re-enter pairing mode.

Pair the Bluetooth receiver to the second phone.

Turn on the Bluetooth function of the first phone, select the "EasyGo 7" and click "connect".

Two phones will be connected to the Bluetooth receiver at the same time.

Charge

Low Voltage alert:

When the alert tone sounds every minute and light turns into red, it indicates that the battery has run out and need to be charged as soon as possible.

Charging the receiver:

Charger output voltage used should be not higher than 5V. You must charge the receiver fully before using the receiver for the first time.

Connect the USB charging cable to the USB charge port of the receiver.

The light indicator will turn into red when charging.

The full charge takes about 1.5 hours.

The red light indicator goes out and color changes to blue when charging completed.

The Basics

Answer a call

Tap the multifunction button to answer call.

Answer a second call

First, tap the multifunction button to end current call, then tap the multifunction button to answer new call.

End a call

Tap the multifunction button to end current call.

Reject a call

Press the multifunction button until you hear the sound "toot" and then release.

Call back last Call

Double-tap the multifunction button

Play or pause streaming audio

Play/pause: tap the multifunction button.

Next song: tap the button ">>|"

Previous song: tap the button "|<<"

Volume up: tap the button "+"

Volume down: tap the button "-"

Voice Alerts

This receiver speaks in English.

Voice alerts list:

Specifications

Bluetooth Version: V4.1

Frequency Range: 2.4GHz

Operating Distance (range):Up to 33 feet(10meters), Class II

Charge connector: Micro USB cable

Power requirements: 5V DC-130mA

Bluetooth Profiles: Supports Advanced Audio Distribution(A2DP), Wideband Hands-free v1.6(HFP), Headset v1.2(HSP)

Charge time: 1.5 hours for full.

Talk time: up to 3~4 hours

Music play time: up to 6~8hours

Standby time: up to 100~ 120 hours

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.