添加FCC认证警示语

D333英日说明书

六折页（风琴折）80*100mm

Pantone Grey 432 C

Pantone 199C

C:0 M:0 Y:0 K:15

THOMSON

COMPUTER SPEAKERS

User Manual



English/Japanese QYTM-D333

EN101

Sound installation mode

• Keep the product dry and do not place it in humid places to avoid affecting the internal circuit of the product.

• Do not place the product in a place exposed to sunlight or high temperatures. High temperatures shorten the life of electronic components and distort some plastic parts.

• Do not put the product in too cold a place, so as not to damage the internal circuit board

• Do not attempt to disassemble the product, especially for non-professionals, which may damage the product.

• Do not drop, strong vibration hits the product with a hard body to avoid damage to the internal circuitry.


• Do not use strong chemicals or cleaner to clean the speaker

• Do not scratch the product surface with a sharp to avoid damage to the shell and affect the appearance.

• Do not use a power supply with a high voltage to avoid damage to the product or possible danger, And automatically terminate product warranty service.

Connection Method


1. PC Connection Method



Tips: All lines need to be connected at the same time to use, connected to the back of the computer sound quality is better (not recommended to insert the host in front)

EN102

Cell phone/MP3/MP4/Tablet Connection Method



Tip: Must use 5V 600 mA or higher-charging head

Consumers who use the power adapter for power supply should purchase one that meets the CCC certification and the standard requirements.

Power Supply (this machine has no internal batteries and needs to be plugged in to use)

Insert the USB plug of this machine into the USB socket of the computer or the USB socket of the mobile phone charger (DC5V ⎓ 600mA or higher) (1000mA or higher sound quality is better).

Turn On

After power on, the speaker will automatically turn on, after that the speaker will sound "Audio input mode" beep, the light on the speaker will light up.

• Microphone hole: In AUX mode, it can be plugged into a microphone (the red audio head on speaker needs to be plugged into the red hole of the computer).

• Audio output hole: In AUX mode, it can be plugged into audio devices, such as headphones, speakers, etc. (the green audio head on the speaker needs to be plugged into the green hole on the computer).

• Multi-function knob: Clockwise rotation to increase the volume, counterclockwise rotation to reduce the volume, short press the knob to switch between AUX line input and Bluetooth, long press for power on / off.

• Indicator light: Light up after power on, After entering Bluetooth mode, it is fast flashing when waiting for Bluetooth connection, and slow flashing when Bluetooth connection is successful.

EN103

Bluetooth Connection Method

1, After the "Audio input mode" beep, press the knob to switch to Bluetooth mode, open the phone/tablet and other Bluetooth devices can be connected to the speaker at any time. Cellphone connection method: open the phone Bluetooth settings (different phone brands, Bluetooth open in different ways) into the search, match the device "D333", After the connection pairing, the initial pairing password is "0000", After a successful connection, the speaker will emit a "Bluetooth connection success" beep.

2, Due to different brands of cellphones, the Bluetooth version is not the same, Therefore, the search and pairing time will be different. It takes about a minute under normal circumstances.

AUX(AUX in)

This machine has the function of amplifying the output of external audio sources (such as cell phones, computers, tablets, MP3 players, CD players, Walkman, radio, etc.). Insert the 3.5 audio plug (round) of this large speaker into the headphone output socket of the computer, cellphone, or tablet, and then insert the USB power supply plug of this machine into the USB socket(1000mA or higher with better sound quality) of the computer or cell phone charger (DC5V ⎓ 600mA or higher). After power on, the speaker will sound "source input mode" beep, and it can be played.

Solutions to Common Problems

1, Multiple connection pairing is unsuccessful: (1) Restart and pairing. (2) Turn off other Bluetooth devices because their interference causes searching difficulty.

2, Sound is low or distorted: (1) Charger current is insufficient, replace another charger. (2) Source volume is small, adjust the volume to appropriate.

3, Music in Bluetooth mode is interrupted: Check if the effective connection distance of the speaker is exceeded, or if there is an obstacle between the speaker and the mobile phone.

Note: This machine does not have a Bluetooth calling function. When playing music with Bluetooth on your mobile phone, you can answer a call directly with your mobile phone.

EN104

Product Specifications

Bluetooth Version	BLUETOOTH 5.0
Output Power	2*3W
Effective Distance	≤10m
Power Supply Voltage	DC5V⎓600mA

Note: for the different paring devices and using situations, the connection distance is different.

This product has been manufactured and sold under the responsibility of MAXTALENT INDUSTRIAL Limited.

Thomson and the Thomson logo are trademarks used under license by MAXTALENT INDUSTRIAL Limited.

Further information at www.maxtdigital.com/THOMSON.

Any other product, service, company, trade or product name and logo referenced herein are the property of their respective owners.

Manufacture: Shenzhen Qiuyu Electronic Co., Ltd
Website: www.maxtdigital.com/THOMSON
Support: service@maxtdigital.com
Made in China
V1.0

THOMSON

サウンドインストールモード

・製品の内部回路に影響を与えないように、製品を乾いた状態に保ち、湿気の多い場所に置かないでください。

・直射日光の当たる場所や高温になる場所に置かないでください。高温は、電子部品の寿命を縮め、特定のプラスチック部品を変形させる可能性があります。

・内部回路基板の損傷を防ぐため、製品を寒い場所に置かないでください。

・専門家以外の方が、製品を分解や改造をしますと、破損したり、故障の原因となりますのでご注意下さい。

・内部回路が破損しないように、製品を落下させたり、強い力や衝撃、振動を与えないでください。


・スピーカーの清掃に刺激性のある化学品、洗剤や強力なクリーナーを使用しない。

・シェルの損傷や外観への影響を避けるために、研削なものを使用して製品の表面を傷つけないでください。

・製品が破損したり、劣化にさらされたりしないように、異常圧縮は使用しないでください。そして、製品保証サービスを自動的に終了するものとします

接続方法

1. PC接続方法



ヒント：使用するには、すべての回線を同時に接続する必要があります。コンピューターの後ろに接続すると、音質が向上します（前にホストをさすことはお勧めしません）。

JP101

携帯電話/MP3/MP4/タブレットの接続方法



ヒント：5V600mA以上の充電ヘッドを使用する必要があります。

消費者は、パワーアダプタを使用して電力を供給するには、CCC認証および標準要件を満たすアダプタを購入する必要があります。

パワーサプライ（このマシンには内蔵されているバッテリーがないため、使用するにはプラグを差し込む必要があります）

本機のUSBプラグをパソコンのUSBソケットまたは携帯電話の充電器のUSBソケット（DC5V⎓600mA以上）に差し込んでください（1000mA以上の音質がより良い）。

オンにする

パワーを入れると、スピーカーが自動的にオンになり、その後、スピーカーから「オーディオインプットモード」のビープ音が鳴り、スピーカーのランプが点灯します。

・マイクホール：AUXモードでマイクに接続できます（スピーカーのレッドオーディオヘッドをコンピューターのレッドホールに接続する必要があります）。

・オーディオアウトプットホール：AUXモードでは、ヘッドホン、スピーカーなどのオーディオデバイスに接続できます（スピーカーのグリーンオーディオヘッドをコンピューターのグリーンホールに接続する必要があります）。

・マルチファンクションノブ：時計回りに回すと音量が大きくなり、反時計回りに回すと音量が小さくなり、ノブを短く押すとAUXラインインプットとブルートゥースが切り替わり、長押しするとパワーのオン/オフが切り替わります。

・インジケーターランプ：パワーを入れてから点灯し、ブルートゥースモードに入った後ブルートゥース接続を待機しているときは速く点滅し、ブルートゥース接続が成功するとゆっくり点滅します。

JP102

ブルートゥース接続方法

1.「オーディオインプットモード」のビープ音が鳴ったら、ノブを押してブルートゥースモードに切り替え、携帯電話/タブレットを置くと、他のブルートゥースデバイスをいつでもスピーカーに接続できます。携帯電話の接続方法：電話のブルートゥース設定（電話ブランドによりブルートゥースの開き方が違い）を開けて検索に入って、デバイス「D333」にマッチします、ペアリングを接続すると、初期ペアリングパスワードは「0000」になります。接続に成功すると、スピーカーから「Bluetooth connection success」のビープ音が鳴ります。

2. 携帯電話のブランドブランドによってブルートゥースのバージョンが違うため、接続とペアリングの時間が異なり、通常は1分程度かかります。

AUX（AUX入力）

このマシンは、外部オーディオソース（携帯電話、コンピューター、タブレット、MP3プレーヤー、CDプレーヤー、ウォークマン、ラジオなど）のアウトプットを増幅する機能を備えており、この大型スピーカーの3.5オーディオプラグ（ラウンド）をパソコン、携帯電話、タブレットのヘッドホンアウトプットソケットに差し込んでから、このマシンのUSB/パワープラグをコンピューターまたは携帯電話の充電器（DC5V⎓600mA以上）のUSBソケット（1000mA以上音質がより良い）に接続します。電源を入れると、スピーカーから「ソース入力モード」のビープ音が鳴り、再生できるようになります。

よくある問題のソリューション

1.マルチコネクションペアリングが失敗する場合には：（1）ペアリングを再起動し、（2）他のブルートゥースデバイスの干渉により検索が困難になるため、それらのデバイスの電源を切ります。

2.音がかさい、またはディストーションしている場合には：（1）充電器の電流が不足している場合は、別の充電器を交換してください。（2）ソースの音量がかさい場合は、音量を適切に調整してください。

3.ブルートゥースモードで音楽が途切れる場合には：スピーカーの有効接続距離を超えているか、スピーカーと携帯電話の間に障害物がないかを確認してください。

ノート：本機にはブルートゥース通話機能がありません。携帯電話のブルートゥースで音楽を再生するときは、携帯電話で直接電話に出ることができます。

JP103

製品仕様

ブルートゥースバージョン	BLUETOOTH 5.0
アウトプットパワー	2*3W
有効距離	≤10m
パワーサプライボルテージ	DC5V⎓600mA

ノート：ペアリングデバイスや使用状況により接続距離も異なります。

本製品は、MAXTALENT INDUSTRIAL Limitedにより製造および販売されています。

Thomsonと Thomsonロゴは、MAXTALENT INDUSTRIAL Limitedからのライセンスに基づき使用されています。

詳細については、www.maxtdigital.com/THOMSONをご覧ください。

ここで参照されるその他の製品、サービス、会社、商社、または製品名、ロゴは、すべてそれぞれの所有者の財産です。

メーカー：深セン秋前電子株式会社
ウェブサイト：www.maxtdigital.com/THOMSON
サービスメールボックス：service@maxtdigital.com
Made in China
V1.0

JP104

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.