


Quick Installation Guide

Wireless Adapter

Version: 1.0

1. Hardware Connection



Insert the wireless adapter into the computer of USB port

2. Driver installation

Scan & View Guide Video




1. Download the driver (<http://www.lb-link.com/support/downloads/>)
2. Run and install the driver



Before installing the driver, disable the firewall or other security protection software to prevent installation.

3. Wireless reception

Click the icon [] in the lower right corner of the desktop to select the wireless network name, and click Connect. If Connected is displayed, the network is connected successfully.



Troubleshooting

If you have problems during the installation, please refer to the following online FAQs.

1. If you can't install the driver successfully, disable the antivirus software and firewall, then try again.
2. Try another USB port.
3. Confirm whether the computer has installed similar driver. If so, please delete the installed driver and re-install the correct driver.
4. Avoid using the extension line to connect the USB Adapter, which may cause insufficient power supply of the USB Adapter and make the computer unable to recognize the USB Adapter.



For more information, please visit our website
<http://www.lb-link.com>

Shenzhen Bilian Electronic Limited

LB-LINK is the registered trademark of Shenzhen Bilian Electronic Limited. All the products and product names mentioned here are the trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice. Copyright © 2024 LB-LINK All Rights Reserved.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC ID: 2AL6KBL-WN151