


Portable mobile Bluetooth audio system



User manual

Please read all instructions carefully and retain for future use


K-29



- 1 Long press to turn on/off; Short press to play/pause;
- 2 Short press to reduce volume; Long press for previous song ;
- 3 Short press to increase volume; Long press for next song;
- 4 Short press mode switching, long press light switching;
Double click to disconnect Bluetooth and pair Bluetooth.

Shutdown: When the speaker is not in use, press and hold the "  " button to shut down to prevent power loss. Low battery alarm and automatic shutdown function: When the battery level is below 10%, the speaker will emit a prompt sound. At this time, the speaker should be charged in a timely manner. When the battery level is below 3%, the machine will automatically shut down.

Back Interface Description



- 1 AUX audio input ports, insert a 3.5mm cable to automatically enter AUX mode.
- 2 DC5V Type-C charging port.
- 3 TF card socket, insert TF card to automatically play music (supports TF card playback, up to 256G (supports MP3, WAV music formats).

Microphone operation instructions

- + Short press the microphone to increase the volume; Long press and reverb.
- Short press the microphone to reduce the volume; Long press to reduce reverb.

Long press the power button to turn on/off; Short press the power button to select three sound effects modes: KTV mode, shout mode, and professional mode. (Double click to cancel the original sound).

Long press to switch between six magic sound modes: female to male, male to female, doll sound, monster sound, machine sound, and original sound.

Operation Instruction

1. Bluetooth mode

(1) Bluetooth connection: When turned on, the default setting is Bluetooth. Enter Bluetooth mode or press the "  " button to switch to Bluetooth mode. Open the Bluetooth setting on your phone, search for "K2" and click pairing. After successful connection, there will be a prompt sound indicating that Bluetooth is connected.

(2) Play music: Open Bluetooth on your phone or other device,download and play your favorite songs.

(3) After connecting the machine to the phone once, Bluetooth has a memory function, which can be automatically or manually connected when turned on; If you need to disconnect, you can use your mobile Bluetooth device to disconnect or double-click the "  " button to forcibly disconnect Bluetooth.

2. TF card mode

(1) Insert the TF card, and the machine will automatically perform a priority playback with a prompt sound. When all TF cards are inserted, you can switch by briefly pressing the "  " button.

3. AUX (external audio input) mode

(1) Insert the AUX external audio cable, and the audio system will automatically play back with priority and a prompt tone.

(2) When both AUX and TF cards are inserted simultaneously, you can switch by briefly pressing the "  ".

4. Four indicator light states

(1) Charging indicator: The charging red light is on, and the fully charged red light is off.

5. Music Lamp Description

(1) This product has six music light modes, namely: color running, gradient breathing (alternating red, blue, and green gradient breathing), red breathing, blue breathing, green breathing, and turn off the light effect; press and hold the "  " button once to switch between one light effect.

6. Wireless microphone usage

(1) The speaker and microphone are turned on simultaneously, and the 2.4G wireless signal is automatically paired. At this point, users can start shouting and adjust the buttons to their preferred style according to their preferences.

Products specifications

BT Name : k2
BT version : V5.3
Transmission distance: ≥ 10m
Maximum Power Rate: 9W
Rated input : 5V 1A
Battery capacity : 1800mAh
Playing time : About 2-3 hours
Charging time : About 2-3 hours
Signal-to-noise ratio: ≥ 85dB
Distortion rate: ≤ 1%
Frequency response: 120Hz~18KHz
File format: support MP3, WAV
External audio source: 3.5mm audio input

Packing list

Speaker x 1
Manual x 1
Single/dual Microphone (optional)
Charging Cable x 1

Warranty statement

Disclaimer

This user manual does not have any form of guarantee, position expression or other implication. The mentioned products, specifications and information are only for reference, and the content will also be updated on the webpage at any time, without additional notification.

Precautions for product use

- (1) Don't attempt to disassemble the unit and change any part, except there is operation method mentioned in the manual.
- (2) Don't expose the unit to liquid, moisture or humidity, since it is not a waterproof product.
- (3) Disconnect the unit with your Bluetooth device and move it to the safe area if the liquid get inside the unit.
- (4) Don't assemble or disassemble the unit to avoid electric shock, if there is water on your hands.
- (5) Don't expose the unit to extremely high temperature or dispose of the unit in fire as it will result in an explosion.
- (6) Don't place the unit in an electromagnetic interference environment to avoid malfunction.

FCC Caution.

(1)§ 15.19 Labelling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirem nt. The device can be used in portable exposure condition without restriction. According to §15.247(e)(i) and §1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.