SWAROVSKI

English

INSTRUCTION MANUAL
Bluetooth Earplug

Parts:
1 - Micro USB Type B female socket (charging port)
2 - LED indicators (constant red LED means charging and constant blue LED means end of charging; flash red and blue LED means Bluetooth pairing and flash blue LED means end of pairing)
3 - Volume Down "-" Key: Volume down (short press), Previous Song (long press)
4 - Play Key: Play/Pause/Hand-free (short press), Power on/off (long press for about 3 seconds)
5 - Volume Up "+" Key: Volume up (short press), Next Song (long press),
6 - Microphone

Accessories:
USB Charging Cable x 1pc
Silicone Earbud 3 sets (large, medium and small size)

Specifications:
Weight: 20 g
Speaker: 10 mm, 32 ohms +/- 15%
Frequency Response: 20 ~ 20KHz
Sensitivity: 90 dB +/- 3 dB
Cord length: 800 mm

Battery Parameters:
Capacity: 60 mAh, 3.7 V, Li-polymer Battery
Music Playback Time: about 3 hours at 70% Volume
Charging Standard: DC 5 V, 500 mAh
Charging Time: about 1 hour

Bluetooth Parameters:
Operation Frequency: 2.402 GHz - 2.480 GHz
Power Output (Peak): 8 dBm
Received Sensitivity: -89 dBm
Operating Range: Around 10 m



Operation with mobile:
1 . Turn on the power of the earplug.
2 . Activate Bluetooth in mobile.
3 . Search for Bluetooth device named "Swarovski BT Earplug".
4 . Connect and play music.
5 . Red LED always flashing means battery capacity is low.

Security and Precaution:
1 . Please do not strike the product with any blunt or sharp article. To avoid damage, do not throw or drop this product.
2 . Please use adapter with output 5.0V-5.5V to charge this product.
3 . It must be used with the correct voltage to avoid damage to the product and associated equipment.
4 . The suppliers assume no responsibility for any damages that may happen due to the improper operation of this product.
5 . If there is no power output from the product, simply recharge it.
6 . Keep this product in a dry place. Never place or use the product in wet or dirty conditions.
7 . Keep away from fire.
8 . Never let children play with it, especially the accessories.
9 . Please do not disassemble and refit our products to change the protection system, as it may cause a fire or explosion.
10. Please stop using this product if any abnormalities occur, such as abnormal smell, temperature, color, or shape.
11 . To avoid damage to your socket and device, please be careful not to use excessive force when connecting the product.
12. It is normal that the product will become hot after long periods of use.
13. After charging your devices, please remove the charging cable to avoid consuming the capacity of this product.
14. This product has a built-in lithium battery, please use carefully.
15. All accessories and adapter (if necessary) can only be used for this product.
16. The designer of this product has the final judgment and the right to amend all mentioned above.

Compatibility:
For use with most Bluetooth devices.

Troubleshooting:
1 . Bluetooth is a bidirectional transmitting protocol; transmitting distance is highly related to the audio player.
2 . When the product cannot be connected, please delete the other Bluetooth devices listed on the user´s computer / mobile phone. Then, follow the steps in the operation instructions.
3 . The sound performance could also be affected by poor signal or low battery capacity. Please move the product to an environment with strong signal or charge the product.

Caution:
Please note that this product is not a toy. It is not suitable for children under 15, as small and/or broken parts may present a CHOKING HAZARD.



Front
Model no.: SW0039 / SW0040
SIZE: 195x630mm
DATE:2017-05-25

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1)this device may not cause interference, and(2) this device must accept any interference, includinginterference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables auxappareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :(1) l'appareil ne doit pas produire de brouillage, et(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre lefonctionnement.

Back
Model no.: SW0039 / SW0040
SIZE: 195x360mm
DATE:2017-05-25