

Aroma Diffuser

(Blue tooth Audio)



User Manual

Thanks for buying the aroma diffuser (blue tooth audio). This item combines aromatherapy, humidifier and atmosphere light together. Aromatherapy will pleasant your body, atmosphere light makes you relax and the humidifier will serve you a comfortable environment. Let' s start the tour into relax, comfortable and pleasant –world.

Contents

Structure	1
Main index	2
Usage	2
Connect the diffuser	2
Start to use	3
Play the music	3
Cleaning	4
Attention	5
Trouble shooting	6

Structure



Main Index

Name: Aroma Diffuser	Timer: 1\3\5hour
Mist volume: 20±5ml/hour	Power: 12W
Capacity: 200ml	Voltage: DC24V $\approx$ 0.65A

Usage

Please check all the parts are completed.

Connect the diffuser

- 1.Place the diffuser at a stable horizontal position.Connect the adapter to the DC port at the bottom (Very important: do not connect the adapter to the AC power source at this moment) and
- 2.Remove the outer cover and the water tank cover
- 3.Add the purified water into the water tank. The water level is 50ml (min) ~ 200ml (max),The water level should not pass the rated bar inside the water tank. For best misting function , please fill the water to the level 5MM lower than the rating bar .
- 4.Put the aroma into the water tank. It is suggested to put 5~8 drops for 200ml water.
- 5.Replace the water tank cover and outer cover.
- 6.Connect adapter to the AC power source and start it.

Start to use

1. Press “”, the diffuser is in standby mode, the LED under the power button will be on.
2. Press “”, the diffuser start to mist continuously ,the LED “” will be in blue; press this button again, the diffuser will mist intermittently, the LED “” will be in blue; press the button again , it will stop misting.
3. Press “”, the atmosphere light is on, the colors change in series; press the button again, the atmosphere will stay in current color; press the button again, the atmosphere light will be off.
4. While the diffuser is misting, press “”, the timer will start, and the LED “1h” will be on. The default timer is 1 hour, which the diffuser will be power off in one hour; press the button again, the timer is set to 3 hours, press the button again, it will be set to 5 hours; press the button again, the timer will stop working.

Note: There would be some condenser water blocked the mist-outlet after long time use; Please clean the mist-outlet and continue to use.

Attention: DO NOT open the outer cover or fill water/aroma while misting. It must be power off when you fill the water and aroma.

Play the music

Start the blue-tooth function on mobile phone or computer to play the Music

1. Press the “” key to start the blue-tooth, the LED “” will shine.
2. Start the blue-tooth function on the mobile phone or computer, find the name “Aroma Diffuser” , click it . Devices will match successfully with a response sound and the LED light will be on.
3. Play the music on your mobile phone or computer, the music will be played through the diffuser audio at the same time.

Cleaning

For safety, it is suggested to clean the diffuser regularly. Cleaning interval is 9~10 times of usage or 5~6 days. The clean procedures are as follow:

1. Disconnect the adaptor from the AC power source or turn off the power sources.
2. Place the diffuser on a flat and stable place such as table. Remove the outer cover and the water tank cover. Assure that the place is flat and stable to avoid the water leakage.
3. When pouring out the water, keep the air-outlet up. Don't let any water flow inside the PCB.
4. Clean the ultrasonic vibration plate at the bottom of the water tank with the cotton bud; clean the outer cover with cloth or cotton bud.
5. It is suggested to run sterilization every 2~3 days
6. When there is dirt like aroma or oil at the cover of the diffuser or the water tank, please clean it by the dried cloth with kitchen diluents and warm water.
7. After complete the cleaning, please add the purified water into water tank, then power on the diffuser for 30 minutes, drain the water out and dry the water tank. You can storage the diffuser after it is dried out.
8. When there is dirt on the mist-outlet, please remove the outer cover, clean it with the neutral detergent. After it is dried, you can use diffuser again.

Note: When there is no feedback function or the diffuser is crash, please disconnect the adapter from the power source for a while. Then reconnect the adapter and restart the diffuser.

Attention: You must use the neutral detergent to clean. Any detergent of chlorine, acid, enzyme left inside the tank would produce hazard material and harmful to human;

Attention

Please read the following important notes, and keep this for future usage

1. Use the diffuser strictly according to the instruction manual. Place it onto a stable and flat position to avoid any fall down to cause the damage on diffuser and human. Don't place it on a leaned place or any high and unstable place such as shelf etc.

2. Don't use the diffuser in a humid environment. Keep it out of the place from water-drop and spraying, such as fountain, or any place of water, such as vase and fish tank etc;

3. Keep the diffuser out of the heat source (heater, radiation, oven and fire etc,)

4. Don't touch the adapter with wet hand, it would cause electric shock.

5. Don't place the adapter nearby any heat sources; don't twist or destroy the wires.

6. Don't use the diffuser when the adapter is found damaged, loose or the breakage on the wire, otherwise it would cause electric shock or fire

7. Don't use the diffuser when the adapter is overheated, smell or noise, otherwise it would cause accident like electric shock or fire;

8. Please plug off the adapter while in filling water or cleaning the diffuser, otherwise it would cause accident like electric shock;

9. Please don't block the mist outlet or the air inlet, as it will cause malfunction, damages or even fires

10. Please don't put any foreign matters into the air inlet, as it would cause accident like electric shock or fire. For the smooth air flow, please keep the area 15cm (6 inch) around the diffuser unblocked;

11. All the repair works must be handled by the qualified staff. Please call for repair in case of malfunction, or flooded by water, rain or other liquid, damped, fallen down etc.

12. Please don't disassemble or reform the diffuser. Otherwise it would cause malfunction, fire, electric shock or injury etc,

13. While in moving the diffuser, please turn it off and plug out the adapter. Otherwise it would cause malfunction, fire, electric shock or injury etc.

14. While the diffuser is working, please don't remove the outer cover, add water or the aroma. Otherwise it would cause malfunction, fire, electric shock or injury etc.

15. Don't use the diffuser in car

16. The diffuser is not a toy. Keep it out of the children to avoid any accident.

17. Don't remove the outer cover while the diffuser is working, it would cause damage or malfunction.

18. Plug off the adapter when you don't use the diffuser. Otherwise it would cause the accident of electric leakage, shock or fires because of the aging of insulation outer cover.

19. Please clean the adapter regularly. The dust on the adapter would cause poor insulation, electric leakage, shock or fire;

Trouble shooting

Malfunction	Reasons	Solution
Diffuser can't start up.	The connector not plug in or not connect well	Check the connector is well connected.
	Main switch not connected well	Check the switch
	Main body damaged	Send to the service point for maintenance
Diffuser can't stop working	Switch not connected well	Check the switch button
	Main body damaged	Send to the service point for maintenance
	PCB damaged	Send to the service point for maintenance
Mist become less or no mist	Lack of water	Add water
Indicator light is off	Indicator light damaged	Send to the service point for maintenance

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- -

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.