

正面

Do Not Return Card

IMPORTANT

PLEASE DO NOT RETURN TO STORE

If You're Having Trouble, We're Here to Help!

STOP

Call us 24/7 at 1-855-292-4087

E-mail us at alsupport@sakar.com or visit us at alteclansing.com

ALTEC LANSING

WELCOME

Thank you for purchasing an Altec Lansing product. Download our App to unlock all the features our products have to offer!

ALTEC LANSING

JUST LISTEN.

MZX3007-WHTSIL

Boost Wireless Headphone

QUICK START GUIDE

FCCID: 2AL9B-MZX3007

In the Box

Boost Wireless Headphone

AUX Cable

USB-C Cable

A Closer Look

1. Volume + / Next Track

2. Volume - / Previous Track

3. Accept / End / Reject Calls / Voice Assistant

4. Power On/Off , Play / Pause Music

5. LED Indicator

6. AUX port

7. Charging Port

8. Mic

Charging

Connect the USB-C cable into the charging port to charge the headphone. The headphone's indicator will turn red while charging and turn off when it is fully charged.

● Charging (continuous red light)

● Fully charged (continuous blue light)

Powering On

To turn on the headphones, press and hold the power button. The LED flashing Blue and Red alternately indicates that the headphones have entered Bluetooth pairing mode.

Pairing Mode
Red & Blue flashing LED

背面

REGISTER YOUR PRODUCT

To receive news, exclusive deals, OTA or firmware updates, warranty information and more please register your product at alteclansingsupport.com

ALTEC LANSING

FOLLOW US ON

#myalteclansing

alteclansing.com

12 Month Limited Warranty

All Altec Lansing products come with 12 month limited warranty from the date of its original purchase

24 Hour Customer Support

We love our customers, and we care about your experience with Altec Lansing. If you need assistance, please call us at 1.855.292.4087 or e-mail alsupport@sakar.com or www.alteclansing.com

Altec Lansing Edison, NJ 08817

Bluetooth Pairing

Once the headphone is on, look up for 'AL Boost' in your smart device's Bluetooth pairing list. Once pairing is successful, the headphone LED indicator will intermittently blink blue.

Controls

Function	Required action
Power ON/OFF	Press and hold the Power button for 2-3s
Play/Pause Music	When playing music, press the multi-function button to pause the music. Press again to resume playing the music.
Accept/End/Reject Call	When receive an incoming call, press the multi-function button to accept call, press again to end call. Press and hold the button to reject the incoming call.
Voice Assistant	Press and hold the multi-function button for about 1s to activate your smart device's voice assistant.
Volume control	Tap the "+" button to increase the volume, Tap the "-" button to decrease the volume.
Next / Previous track	Press and hold the "+" button to advance to the next track. Press and hold the "-" button to return to the previous track.

Notes

**To use voice assistant, you must have a phone that is equipped with a voice assistant.*

**You must be within Bluetooth range to use voice assistant via your headphone.*

Your headphone's voice assistant feature will not work if a voice assistant is not first enabled within the settings on the phone. For more information, see your phone's user manual.

For additional user materials and warranty information, please visit alteclansing.com

Notes

FCCID: 2AL9B-MZX3007

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in the portable exposure condition without restriction.

FOLLOW US ON

#myalteclansing

67. 62*9. 66CM 128G铜版纸/正反四色印刷/风琴折/折后尺寸9. 66*9. 66CM