


SHRP-BTS12 - Wireless speaker with wireless charger

User Manual - Black and White Printing



WARNING

Do not expose this product to direct sunlight or immerse it in water. If the device becomes wet, dry it thoroughly before use. Keep the product away from strong magnetic fields and avoid dropping or subjecting it to heavy impacts. Do not disassemble or modify the unit. Clean the exterior with a soft, dry cloth only, and avoid using chemical cleaners or solvents. If the product will not be used for an extended period, recharge the battery every six months to help maintain battery performance. Use and store the product in environments between 0°C and 45°C (32°F and 113°F).

WARRANTY

This product has a 1 year warranty against defects in manufacturing under regular consumer use. For instructions about how to obtain warranty service for your product, please contact Customer Service: info@primebrandsgroup.com.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov



©2026 Prime Brands Group. All rights reserved. All trade names are registered trademarks of the respective manufactures listed. Made in China.
Prime Brands Group • Brooklyn, NY 11232 • SHOPSOAR.COM

Sharper Image® name and logo (Including the 77 logo) are trademarks or registered trademarks. Distributed by ©2026 Prime Brands Group, INC. Brooklyn, NY 11232. All rights reserved. For Technical Support, Please visit www.shopsoar.com. Colors and styles may vary. Before use, read all warnings found in the included instruction manual or refer to our website www.primebrandsgroup.com for more information.


SHARP IMAGE®

Thank you for choosing the Sharper Image® AuraDock. This versatile 4-in-1 bedside speaker combines a 15W wireless charger, digital alarm clock, LED ambient lighting, and rich stereo sound in one stylish retro-inspired design. Enjoy your favorite music wirelessly or from USB, TF card, AUX, or FM radio, while keeping your phone charged and your bedside organized. We hope you enjoy the convenience and performance of your new AuraDock.

Includes: AuraDock LED Wireless Charging Alarm Clock Speaker, USB-C Charging Cable, User Manual

PRODUCT KEY

- 15W Wireless Charging Pad
- Control Panel
- RGB Ambient Light
- LED Digital Clock Display
- On / Off Button
- LED Light Button
- Alarm Button
- Mode Button
- Previous Track / Volume Down Button
- Play / Pause Button
- Next Track / Volume Up Button
- USB-C Power Input Port
- TF (MicroSD) Card Slot
- USB Playback Port
- AUX Input



FRONT



CONTROL PANEL

SPECIFICATIONS

Bluetooth® Version: 5.3
Speaker Drivers: 57 mm x 2
Speaker Output: 5W x 2
Wireless Charging Output: Up to 15 W
Battery: Built-in 1200 mAh Lithium-Ion
Charging Port: USB-C
Charging Time: Approximately 2 hours
Play Time: Up to 3-4 hours (at 70% volume)
Supported Audio Sources: Bluetooth®, FM Radio, USB Drive, TF Card, AUX Input



BACK

CHARGING

Connect the included USB-C cable to the USB-C Power Input (12) and a compatible USB (5V=3A or 9V=2A) power adapter. The charging indicator lights red while charging and turns off when the battery is fully charged. When the battery is low, the speaker will sound a low battery voice prompt.

BUTTON FUNCTION

- On / Off Button (5) :** Press and hold On / Off (5) for 3 seconds to power the speaker on or off.
- LED Light Button (6) :** Press LED Light (6) to cycle through the available RGB lighting modes. Press and hold for 2 seconds to turn the ambient light on or off.
- Alarm Button (7) :** Press Alarm (7) to adjust the dock settings, including the 12/24-hour time format and current time. Press and hold to enter the alarm setup menu.
- Mode Button (8) :** Press Mode (8) to switch between Bluetooth®, FM Radio, USB Drive, TF (microSD) Card, and AUX input modes.
- Previous Track / Volume Down Button (9) :** Press Previous Track / Volume Down (9) to skip to the previous track in Bluetooth®, USB, or TF Card mode, or to select the previous preset station in FM mode. Press and hold to decrease the volume. During dock or alarm setup, use this button to decrease the selected value.
- Play / Pause Button (10) :** Press Play / Pause (10) to play or pause audio in Bluetooth®, USB, or TF Card mode. During an incoming Bluetooth® call, press to answer or end the call. In FM mode, press and hold to automatically scan and save available stations, or press briefly to mute the radio.
- Next Track / Volume Up Button (11) :** Press Next Track / Volume Up (11) to skip to the next track in Bluetooth®, USB, or TF Card mode, or to select the next preset station in FM mode. Press and hold to increase the volume. During dock or alarm setup, use this button to increase the selected value.

PAIRING

Press Mode (8) to select Bluetooth® mode. The Bluetooth® icon on the LED Display (4) will flash while the speaker is ready to pair. Enable Bluetooth® on your device, select SHRP-BTS12, and confirm the connection. Once paired, the Bluetooth® icon remains solid. During an incoming call, press Play / Pause (10) to answer or end the call using the built-in microphone.

FM RADIO

Press Mode (8) to select FM Radio mode. Press and hold Play / Pause (10) to automatically scan and save available stations. Use Previous (9) and Next (11) to change saved stations, or press and hold either button to adjust the volume. Press Play / Pause (10) to mute or unmute the radio.

USB DRIVE / TF CARD / AUX AUDIO

Insert a USB drive (14) or TF (microSD) card (13) to automatically play supported audio files. Use Play / Pause (10) to play or pause music. Previous (9) and Next (11) to change tracks, and press and hold Previous (9) or Next (11) to adjust the volume. Connect an external audio device to the AUX Input (15) using a 3.5 mm audio cable to play audio through the speaker; volume can be adjusted using Previous (9) and Next (11).

CLOCK & ALARM

Press Alarm (7) to set the time. Select the 12/24-hour format, then adjust the hour and minute using Previous (9) and Next (11). Press Alarm (7) to confirm each setting. When connected via Bluetooth®, the clock will automatically synchronize with your mobile device.

Press and hold Alarm (7) to set the alarm. Adjust the hour and minute using Previous (9) and Next (11), then select ON or OFF to enable or disable the alarm. When the alarm sounds, press any button to stop it. If left unattended, the alarm will sound for approximately 10 minutes before stopping automatically.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement for BT

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

Radiation Exposure Statement for WPT

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm from your body.