



Package Includes:
1 BLUETOOTH® Speaker
1 USB to Micro USB Cable

Owners Guide

**IMPORTANT
PLEASE READ
BEFORE USING
THIS PRODUCT**

MBS14101



Caution: Please make sure silicone Micro USB port cover is closed before using in wet environment.

IMPORTANT SPLASH PROOF/SAFETY INFORMATION

IMPORTANT: DO NOT submerge the MobileSpec® BLUETOOTH® Speaker in water. This device is not intended to function properly after being under water.

- Before using the MobileSpec BLUETOOTH Speaker in a wet environment, make sure the silicone cover over the charging ports on the back of the speaker is fully closed and secured. If water gets into either port, the speaker may not function properly.
- MobileSpec BLUETOOTH Speaker is rated IPX6, which means the speaker can be heavily splashed with water or left in the rain (but not submerged in water) for a limited time.
- If the MobileSpec BLUETOOTH Speaker gets wet, it is recommended that you dry the speaker completely before using it again.
- All actions done with the MobileSpec BLUETOOTH Speaker are done at your own risk. While the speaker is splash-proof and has a silicone cover, it is not guarantee for complete damage protection.

CHARGING

- 1) Make sure the speaker is dry and open the small silicone door at the side of the speaker.
- 2) Connect one side of the included charging cable to the speaker and the other side to any USB charger or computer port.
- 3) The LED Light will turn red to indicate the speaker is charging.
- 4) When charging is complete the LED light will turn off.

POWER AND PAIRING

- 1) Press the power button for 1-2 seconds to power on the speaker.
- 2) The speaker will sound a tone and the Blue LED light will flash quickly.
- 3) On your BLUETOOTH®-enabled smartphone, tablet or media player, navigate to the BLUETOOTH menu.
- 4) Enable the BLUETOOTH feature and search for new devices
- 5) After a few seoncds you will see "MBS14101" - tap to select.
- 6) The speaker will sound another tone and the Blue LED light will become steady and then flash slowly.
- 7) You are now paired, connected and ready to play!
- 8) Press and hold the power button for 2-3 seconds to power off the speaker.

PLAY

- Play:**
- Connect your device to the MobileSpec® BLUEOOTH® Speaker via BLUETOOTH (see "Power and Pairing").
 - Open your favorite music app and press play.
 - Control the music, track & volume from your device, or control them from the on-body controls on the MobileSpec BLUETOOTH Speaker. Press the pause button once to play/pause music. Pres the phone button once to answer/end calls, and press it twice to re-dial the last call you made.
 - Press either of the volume/track buttons once to change tracks. Press and hold to adjust volume. Note: Volume on your device and on the speaker is controlled separately.
 - All audio, including music, games, videos, and notifications will be routed through the MobileSpec BLUETOOTH Speaker.

RECONNECTING TO BLUETOOTH®

- Reconnect to BLUETOOTH:**
- You only need to pair your BLUETOOTH device with the MobileSpec BLUETOOTH Speaker once.
 - With your previously paired BLUETOOTH device turned on and in range, power on the MobileSpec BLUETOOTH Speaker.
 - The speaker will power on and will automatically reconnect to the last BLUETOOTH device they were connected to.
 - If you have a previously paired device that does not auto-reconnect, navigate to the BLUETOOTH settings menu on your device, turn on the BLUETOOTH feature, and select "MBS14101" from your list of paired BLUETOOTH devices.
- Features:**
- Connect & play music wirelessly in the shwer while your device is safe from water up to 33 ft. away.
 - Rechargeable battery provides up to 5 hours of playback.
 - Extra strong suction cup grips to tiled or smooth surfaces.

PRODUCT DIAGRAM

PRODUCT DIAGRAM

SPECIFICATIONS

TROUBLESHOOTING

FCC Statement

- Specifications:**
Product size: 80xH60mm
Weight: 110g
Loudspeaker: 40mm
Interface: Micro USB
- BLUETOOTH® Information:**
Operation frequency: 2.402ghz-2.480ghz
Power output (peak): class 2
Receiving sensitivity: -91db, @0.1%BER
Operation range: up to 10m
- Battery Information:**
Capacity: 400ma, 3.7v. poltmer li-ion battery
Music playback time: 5-7 hours* at 70% volume
Charging time: 2-3 hours
- *Approximate playback time, Battery life depends on individual use and may be slighly more or less than the time specified.

- No Power:**
- Recharge your speaker using the included charging cable.
 - Try using a different Micro USB cable.
- Music is Not Playing Over BLUETOOTH®:**
- Make sure your BLUETOOTH device has A2DP profile.
 - Check if both devices are paired and connected.
 - Restart the speaker to reconnect your BLUETOOTH device.
- BLUETOOTH Device Will Not Reconnect with the Speaker:**
- Navigate to your BLUETOOTH settings menu on your BLUETOOTH device, tap "MBS14101" and select "Forget." Now follow the steps to pair your device again.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection gainst harmful interference in a residential installation. This equip-ment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which thereceiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user’ s authority to operate thisequipment. (Example- use only shielded interface cables when connecting tocomputer or peripheral devices). This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference thatmay cause undesired operation.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.