




Instructions

Before first use, please make sure to fully charge the speaker.

Charge the speaker

Insert the small connector that comes with the charging cable into the Type-C charging port on the back of the speaker.

Insert the large connector into a USB power source, such as a USB port on a computer, or plug in a compatible 5V USB adapter and plug it into a wall socket.

When charging, the LED indicator light will light up in red and turn off when fully charged.

Pair and connect new devices

Press and hold the [O] button for 3 seconds to turn on the device. The LED indicator light will flash blue, indicating that the speaker is in pairing mode.

Open the Bluetooth menu on your smart device and search for a new device.

When you see 'Mahogany' listed, click on it to connect. The LED indicator light will remain on after successful pairing.

The previously paired speakers will automatically pair after booting up.

Press and hold the [O] button to turn off the speaker.

Attention: After the device is disconnected, the speaker will automatically turn off after 3 minutes.

Play and call

Press the [O] button to play/pause audio.

Press the [>] button to increase the volume;

Press and hold the [>] button to jump to the next track.

Press the [<] button to decrease the volume;

Press and hold the [<] button to jump to the previous track.

When there is a call, press the [0] button once to answer the call, and press it again to end the call.

Reset Speaker

If you encounter problems pairing your speakers, please forget the pairing name "Mahogany" from the list of connected devices and turn off Bluetooth.

Follow the instructions for pairing and connecting with a new device to pair with the speaker again.

Wireless Charging Instructions

Insert the provided charging cable into the Type-C USB input port on the back of the wireless charger.

Insert the other end of the charging cable into a USB output port with at least 2A output, such as a computer's USB port or a certified USB adapter, and then plug it into a wall socket.

The wireless charging LED indicator will flash and then turn blue, indicating that the wireless charger is in standby mode and ready to start charging.

Place a mobile device that supports wireless charging on the wireless charging surface, and the device will automatically start charging.

The wireless charging indicator light will turn red to indicate that the device is charging correctly.

If your device has not started charging, please try repositioning the device on the wireless charging pad.

You may need to remove the protective case of the device for normal charging.

When the device is fully charged, please remove it from the wireless charging surface.

Attention: *If the wireless charging indicator light flashes when the wireless charger is in use, it may be due to the device not turning on the wireless charging function, or there being obstacles between the device and the charging pad that interfere with the charging process.*

Explanation on Safety Features:

When the wireless charging surface overheats, or when metal objects such as coins are placed on the wireless charging surface, the wireless charging will automatically shut down.

The wireless charging indicator light will flash blue to indicate automatic shutdown.

Tech Specifications

Speaker Output	5W
Impedance	4 ohm
Frequency Response	20Hz-20KHz
S/N Ratio	>80dB
Connection Range	33 feet
Continuous Play Time	Up to 6 hours (max volume)
Battery Capacity	1200mAh/3.7V 4.44Wh
Charging Time	3 hours (from 0-100%)

Power Input	DC 5V/2A
Wireless Charging Output	5W/7.5W/10W/15W
Working Temperature	32°F~122°F (0°C~50°C)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction