

(Fold Inward) — — — — ➡

(Back Cover)

(Front Cover)

Compliance Information FCC Information This device complies with Part 15 of the FCC Rules. Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Radiation Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. WARNING Li-Ion Battery Inside This product is fitted with a Li-Ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F). Rating Label Definitions Direct current symbol. This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health. This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency. This symbol signifies that this is a wireless device powered by Bluetooth technology. This symbol represents FCC Declaration of Conformity and compliance.

Before You Begin... READ CAREFULLY AND KEEP THIS MANUAL ⚠ Caution To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies. THIS DEVICE IS NOT A TOY, keep away from children and pets. - Do not disassemble, modify, or repair the device. - Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions. - Do not submerge in water. - Low power may cause poor Bluetooth connection or sound distortion. - Do not overcharge battery. - If using with a USB adapter, make sure the adapter is not damaged. - Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders, etc. - The speaker contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device. Questions and Customer Support For questions, troubleshooting, or any other assistance, please visit our customer support portal at www.customersupport123.com, and click "Support." In the Box - HKCTSORN25 Hello Kity Bluetooth Speaker (x1) - Type-C USB Charging Cable (x1) - User Manual (x1)	Location of Controls Power Button LED Indicator Charging Port	Getting Started Charging the Speaker Insert the small connector of the supplied Type-C USB charging cable into the Charging Port on the speaker. Insert the large connector into a USB power source such as the USB port on a computer, or into a 5V USB adapter (not included), and plug into a wall socket. The LED indicator will turn SOLID RED while charging, and will turn OFF once charging is complete. Note – the speaker will sound a tone when it is low on power. Powering the Speaker ON/OFF Press and hold the Power Button to power the speaker ON/OFF. Bluetooth Pairing - Power the speaker ON. It will automatically enter Bluetooth Pairing Mode, and the LED indicator will FLASH BLUE. - Set your mobile device to search for Bluetooth devices. When it appears, select "HKCTSORN25" from the list of found devices. - Once successfully paired to your device, a tone will sound, and the LED indicator will turn SOLID BLUE. Note: - When playing music, the LED indicator will PULSE BLUE. - When powered ON, the speaker will automatically pair to any previously connected devices that are within range. - The speaker will automatically power itself OFF after 5 minutes if not paired with a device. Controlling Playback While the speaker is connected to a device, playback can be controlled through your paired device, or with the controls on the speaker. 1x press the Power Button to PAUSE/RESUME media. Changing to FM Mode - Power the speaker ON, and 2x press the Power Button to switch to FM Mode. The LED indicator will PULSE GREEN. - While in FM Mode, 1x press the Power Button to CHANGE CHANNELS.	True Wireless (TWS) Pairing If you have two HKCTSORN25 speakers, you can make a True Wireless (TWS) Pairing between them by following the below steps: - Place the two speakers near each other, and power them both ON. - The speakers should pair to each other automatically on Bluetooth Pairing Mode. - Follow the instructions in the section in this manual titled "Bluetooth Pairing" to connect your device to the pair of speakers. - When you are finished using both speakers together, 3x press the Power Button on either speaker to DISCONNECT the two speakers (speakers must be unpaired from your device first for this function to work properly). Note – if you have previously paired your device to one of the speakers, you may need to turn its Bluetooth OFF while you pair the speakers to each other.
---	---	--	--