




EEMEET OfficeCore M3

ET1101



PMN: OfficeCore M3


User Manual / 使用说明书
English | 日本語 | Deutsch | Italiano | Français | Русский | 繁體中文 | 简体中文

English	01
日本語	08
Deutsch	15
Italiano	22
Español	29
Français	36
Русский	43
繁體中文	50
简体中文	57

Table of Contents


Overview	01
Power on/off	02
Daisy Chain Cable	03
Lock Port Setting	04
Charging	05
Bluetooth Dongle Connection	06
Headset Connection	07
Bluetooth pairing	08
Bluetooth Connection	09
Volume+/Volume- Button	10
Answer/End Phone Call Button	11
Mute Button	12
MIC Mute Button	13
Download Application	14
Product Parameters	15
Contact Us	16

Overview



- Mute button
- Volume down
- Volume up
- Answer/End phone call
- MIC hole
- Reset button
- Bluetooth button
- LOCK port
- Daisy Chain jack
- Headset output jack
- Bluetooth adapter
- Status indicator
- Power button
- Type-C port


Power on/off



- Press and hold the power button – power on/off


Check battery level

- Short press the power button when powered on – the LED ring-indicator indicates the battery level.




Low battery warning

- In power-on state, the LED ring-indicator turns red.




VoiceA Button

- VoiceA is a noise-cancelling algorithm independently developed by EMEET.
- Turning on VoiceA noise reduction can greatly reduce some noises during meetings, such as from keyboard tapping, air conditioning noise, and general unwanted background noise
- Short press – turn on/off VoiceA
- Press and hold – turn on/off VoiceA




MIC Mute Button

- Press – mute/unmute MIC
- When the MIC is muted, the LED ring-indicator turns red
- Unmute
- Mute




Answer/End Phone Call Button

- Incoming call – press – answer call
- Outgoing call – press – end a call
- Call going – press/press and hold – reject a call




Volume+/Volume- Button

- Press – volume+ – volume up – LED ring-indicator turns blue
- Short press – volume – volume down – the LED ring-indicator turns blue




Bluetooth pairing

- Press and hold the Bluetooth button – enter Bluetooth pairing mode – the Status indicator flashes blue
- Bluetooth not paired – the Status indicator flashes blue
- Bluetooth turned off
- Press the Bluetooth button – the Status indicator flashes blue
- Bluetooth disconnected – Press Bluetooth button – Bluetooth reconnected
- Bluetooth ready with



Bluetooth Connection

- Connect to your computer by using a USB Dongle.
- Plug-and-play is supported when the device is on.
- When the headset is connected, the Status indicator turns blue.



Headset Connection


- Connect to the headset jack using a 3.5mm headset cable.
- When the headset is connected, the Status indicator turns yellow (not connected to Bluetooth or USB cable).



Note:
When the headset is connected, the speaker is automatically muted.


USB Connection

- Connect to your computer by using a USB cable.



Bluetooth Dongle Connection

- Connect to your computer by using a USB Dongle.
- Plug-and-play is supported when the device is on.
- When the Bluetooth dongle is connected, the Status indicator turns blue.



Status

Status	Bluetooth dongle indicator
During pairing	Flashes blue rapidly
Pairing successful	Flashes blue slowly
Reconnection	Flashes blue slowly
Steady green	Steady green
Call going	Steady green
Mute	Steady red
Low battery alarm	Flashes red rapidly

Download Application

- Visit www.emmeet.com to download the ekeetLink PC desktop app for software updates.
- Note: The device can operate normally even if ekeetLink is not downloaded.



Product Parameters


Note: If the specifications are changed, please refer to the official website information.

Charging input	5V = 2A
Output rating	5W
Charging time	4-5H
Speaker frequency range	20Hz-20KHz
Bluetooth version	VS.0
Bluetooth range	20m (in an open environment)
Product size	135*135*35mm

Contact Us

Official website: www.emmeet.com


概要



- ミュートボタン
- 音量アップ
- 音量ダウン
- スピーカ
- 通話開始/終了ボタン
- アースボタン
- Bluetoothボタン
- マイク穴
- 電源ボタン
- Type-Cポート
- Bluetoothアダプタ


電源オン/オフ

- 電源ボタンを長押しして電源オン/オフ
- 電源を入れたまま、電源ボタンを短押ししてアースからアースへ残量が確認できる




アースリ残量の確認

- 電源を入れたまま、電源ボタンを短押ししてアースからアースへ残量が確認できる




アースリ-低下時の警告

- 電源を入れたまま、アースボタンが赤色で点灯する




VoiceAボタン


- VoiceAはEKEETが独自開発されたノイズキャンセリング機能です
- 短押し-VoiceA/ノイズキャンセリングモードのオン/オフ
- VoiceAをオンにしたまま、会議環境でキーボードの打鍵音やエアコンのノイズや後方と前方の移動音などの雑音を遮断することができます



VoiceA On



VoiceA Off



ミュートボタン

- 短押し-ミュートボタン/ミュートモード
- 赤色で点灯する

