



myFirst Fone **S4**

User Manual

Table of Contents

Introduction	1
• What's Included	
• Before First Use	
• Customer Support	
Download myFirst Circle App	1
Product Overview	2
• Wearing the Watch	
• Specifications	
• Buttons	
• Charge the Watch	
Create an Adult Account	5
Create a Child Account	6
Subscribe to myFirst SIM	8
Using Your Watch	9
• myFirst Fone Gestures	
• Basic Navigation	
• Circle Feed	
• Add a Watch Friend	
• Making a Call	
• Camera	
• magiCode	
FAQ	13
Important Safety Information	13

Introduction

■ What's Included



myFirst
Fone S4



Charging
Cable



User
Manual

CAUTION: There is a risk of explosion if the battery is replaced with an incorrect type. Do not attempt to remove or replace the non-user-replaceable battery. If you encounter any issues with the battery, please contact customer support for assistance.

■ Before First Use

Please read this User Manual thoroughly before using the device.

NOTE: This device features an embedded eSIM and requires an active, paid myFirst SIM subscription plan for full operation. Please follow the instructions in the myFirst Circle app to subscribe.

■ Customer Support

For further information, visit our support page:
<http://support.myfirst.tech>

Download myFirst Circle App

The myFirst Circle App is available in the Apple App Store and Google Play Store. Search for “myFirst Circle” to find the app.



Download




Apple App Store



Google Play


■ Wearing the Watch



The strap should be snug but not too tight or too loose. A comfortable fit ensures that the sensors can function properly.

■ Specifications

- Dimensions: 48.81 × 43 × 14.3 mm
- Wristband compatible circumference: 85–145 mm
- Weight (strap included): 48.7 g
- Water resistance rating: IPX8
- Display: 1.65" AMOLED display with capacitive touch panel, 348 × 442 pixels
- Front camera: 5 MP
- RAM: 1 GB
- Storage: 8 GB
- Positioning: GPS, AGPS, Wi-Fi, LBS
- Multi-GNSS receiver: L1 and L5 dual-band GNSS receiver
- Wireless connectivity: GSM, WCDMA, LTE, Wi-Fi
- Battery capacity: 605 mAh
- Charger input/output: 5 V, 1 A
- Circle App support: iOS 15.0 and Android 8.0 or later



■ Buttons

Power Button



Press and hold the Power Button to turn it on.



Press and hold the Power Button for 8 seconds to turn it off.

SOS Button



To initiate SOS, press and hold the SOS Button for 3 seconds until you can feel the watch vibrating.

Back Button



In any subdirectory, press the Back Button once to return to the previous level.

Magic Button



You can set up your preferred quick access types of button presses by clicking the Magic Button three times in a row.


■ Charge the Watch

Set Up the Charger


- Plug the charging cable into a power adapter.
- Plug an adapter into a power outlet.

Start Charging the Watch


- Use the myFirst authorized magnetic charging cable and connect the magnetic charger as shown.
- Note: Ensure the output voltage is 5 V and the current is 1 A.




Create an Adult Account



Create an adult account using your Google, Facebook, or Apple account, or sign up with your phone number.



Enter a valid mobile phone number for verification.




The verification code will be sent to your mobile phone. Please enter the verification code in the app.



Your account has been created successfully. Tap "Link a device" to connect a device for your child.


Create a Child Account




Tap the "+" icon in the upper right corner of the app's homepage.




Tap "Scan Code" to start scanning. Turn on the watch and scan the QR code displayed on the watch.



The verification code will be sent to the watch. Please enter the verification code on your app.




Tap this button to create your child's account. The device will be linked automatically.




Your child's account is ready and the device is linked. You can now personalize your child's profile.

Subscribe to myFirst SIM


The device has an embedded myFirst eSIM and requires a paid myFirst SIM subscription to operate.




In Settings, tap “Subscriptions”.




Tap “Add a plan”.




Select a child account to add a subscription plan. Only eligible child accounts will be shown.



Select the country/region where the watch will be used to configure network settings and confirm your subscription.



Tap the "Payment" to proceed with the payment.



Now you have subscribed myFirst SIM!

Using Your Watch

■ myFirst Fone Gestures



Tap: Touch one finger on the screen.



Double tap: Tap the screen twice in succession.



Press and Hold: Touch and maintain contact with the screen until an action is triggered.



Swipe right: Move one finger across the watch screen right.



Swipe Left: Move one finger across the watch screen to the left.



Swipe Up: Move one finger across the watch screen up.



Swipe Down: Move one finger across the watch screen down.

■ Basic Navigation



■ Circle Feed

Create your first photo post:



Make your first video post:

1. 
2. 
3. 

■ Add a Watch Friend

To add a friend, both smartwatches must be in close range. Follow these steps carefully to complete the process.

1. 
2. 
3. 
4. 
5. 

■ Making a Call

You can initiate a video call or voice call by tapping on the contact's name in the contacts screen.

1. 
2. 
3. 

■ Camera

Capture photos and videos directly from your wrist, offering a convenient way to document moments.



■ magiCode

With magiCode vibrations, you can communicate discreetly by sending customizable vibration messages.



Q: How long does the battery last on standby mode?

A: Actual usage time may vary depending on usage, environment, temperature, or individual factors. The myFirst Fone is rated for up to 24 hours in standby mode.

Q: Is myFirst Fone waterproof?

A: The myFirst Fone is designed with waterproof capabilities conforming to the IPX8 standard. Ordinary splashes and exposure to water will not affect the normal operation of the device. However, the watch is not suitable for activities such as diving, diving jumps, showering, hot springs, saunas, or other water-related or deep-water activities involving high-speed water flow.

After exposure to seawater, it is recommended to rinse the device gently with clean freshwater and dry it thoroughly to prevent potential corrosion or residue buildup.

Please be advised that the charging cable and charging port are not waterproof. Do not attempt to charge the device in environments where it may come into contact with water or moisture.

Q: Are there any age requirements to use the myFirst Fone?

A: It is suitable for children aged 3 and above. For safety reasons, please keep it out of reach of children under 3 years old and pets to prevent accidental damage or swallowing. myFirst Fone is designed for independent use by children aged 6 to 12.

Q: What should I do if the device is not working properly?

A: Try restarting the watch and checking for software updates. If the issues persist, refer to the user manual for troubleshooting steps or contact customer support.

Q: Is there a warranty for the myFirst Fone?

A: Yes, the watch typically comes with a manufacturer's warranty. Check with the retailer or the official myFirst website for specific warranty terms and conditions.
<https://myfirst.tech/warranty/>

Important Safety Information

WARNING

Failure to read the following warnings could result in an accident or medical event resulting in death or serious injury.

Parent or Legal Guardian

It is a parent's or legal guardian's responsibility to set up the device before a child uses the device. It is a parent's or legal guardian's responsibility to read and understand this document and ensure that the child uses the device in an appropriate and safe manner.

Choking Hazard

This product contains small parts. This product is not for children under 3 years old.

Health Warnings

The device, accessories, and related data are intended to be used only for recreational purposes, not medical purposes, and are not intended to diagnose, monitor, cure, or prevent any disease or

condition. Activity trackers rely on sensors that track your movement and other metrics. The data provided by these devices is intended to be a close estimation of your activity and metrics tracked, but may not be completely accurate.

Battery Warnings

- A lithium-ion battery is used in this device.
- If these guidelines are not followed, batteries may experience a shortened life span or may present a risk of damage to the device, fire, chemical burn, electrolyte leak, and/or injury.
- Do not disassemble, modify, remanufacture, puncture or damage the device.
- Do not remove or attempt to remove the non-user-replaceable battery.
- Do not expose the device or batteries to fire, explosion, or other heat source.

Device Warnings

- Do not leave the device exposed to a heat source or in a high-temperature location, such as in the sun in an unattended vehicle. To prevent the possibility of damage, remove the device from the vehicle or store it out of direct sunlight, such as in the glove.
- Do not operate the device outside of the temperature ranges specified in the printed manual in the product.
- When storing the device for an extended time period, store within the temperature ranges specified in the printed manual in the product.
- Do not use a power cable, data cable and/or power adapter that is not approved or supplied by myFirst.
- If the device overheats, remove it from your wrist immediately and contact customer service.

Safety and Tracking Warning

The assistance feature allows you to send your location to the dedicated contact. This is a supplemental feature and should not be relied upon as a primary method to obtain emergency assistance. myFirst app does not contact emergency services on your behalf.

Mobile Network Subscription Warning

The device's mobile network connected features, such as assistance, live track, location updates and messaging, require that the device have an active mobile network subscription. The device must also be in an area with the appropriate coverage for these features to function, and ensure a stable and reliable connection to the mobile network provider.

Navigation Warning

Use this device only as a navigational aid. Do not attempt to use the device for any purpose requiring precise measurement of direction, distance, location or topography.

CAUTION

Failure to read the following cautions could result in minor or moderate injury, or property damage.

Skin Irritation

Some users may experience skin irritation after prolonged and continuous use of the device, especially if the user has sensitive skin or allergies. If you notice any skin irritation, remove the device and allow the user's skin time to heal. To help prevent skin irritation, ensure the device is clean and dry, and do not over-tighten the device on the user's wrist. Adjust the fit to allow air to flow between the band and the wrist.

NOTICE

Failure to read the following notices could result in personal or property damage, or negatively impact the device functionality.

Battery Notices

Contact your local waste disposal department to dispose of the device/batteries in accordance with applicable local laws and regulations, ensuring proper handling and environmental protection.

GPS Notice

The navigation device may experience degraded performance if you use it in proximity to any device that uses a terrestrial broadband network operating close to the frequencies used by any Global Navigation Satellite System (GNSS), such as the Global Positioning System (GPS). Use of such devices may impair reception of GNSS signals.

FCC Compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Specific Absorption Rate (SAR) information

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were

developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement: The SAR limit in the USA (FCC) is 1.6 W/kg averaged over one gram of tissue.

Device types: This device has also been tested against this SAR limit. This device was tested for typical operations distance with 0 mm for wrist and 5mm for mouth up, the highest SAR_{1g} value is 0.925 W/Kg for mouth up and 0.995W/Kg for wrist worn. To maintain compliance with FCC RF exposure requirements, the use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC Exposure requirements, and should be avoided.

Disclaimer

Information about your wireless device and third-party services:

- myFirst is the mobile carrier associated with this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties.
- myFirst is not responsible for your use of this device or any non-myFirst applications, products, and services, including any personal information you choose to use, submit, or share with others.
- Specific third-party terms and conditions, terms of use, and privacy policies apply. Please review carefully all applicable terms, conditions, and policies prior to using this wireless device and any associated application, product, or service.

