



Make Sound More Pleasant

Thank you for choosing tranbel bluetooth speakers, please read the user's manual carefully before you use it. If you have any questions, please scan the two-dimensional code to enter our website for help.

Instructions



T108 Quick Start up Manual



6970705971087

Others

If the system is not used for a long time, the battery may be quickly depleted. However, after a few recharges, the battery life will be improved.

After sales support


In order to achieve further consulting services and technical support, please contact us via the following telephone or official website, we will respond to you within 24 hours.

Official website: www.tranbel.com


Company name: Shenzhen Tranbel Technology CO., LTD

Address: Building C4, Yinfeng Industrial Park, Hangkong Road, Gushu, Xixiang Street, Bao'an District, Shenzhen, Guangdong, China


1. Packing List




● 1A/9V adapter*1



● 3.5mm audio cable*1




● Tranbel BassBox *1



● Micro USB cable*1

2. product overview



○ Top
● Side

WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. To reduce the risk of fire, do not cover the ventilation opening of the appliance with newspapers, tablecloths, curtains, etc. Do not expose the appliance to naked flame sources (for example, lighted candles).

To reduce the risk of fire or electric shock, do not expose this apparatus to dripping or splashing, and do not place objects filled with liquids, such as vases, on the apparatus. Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine or fire for a long time.

CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Precautions

On safety

Before operating the system, be sure that the operating voltage of the system is identical with that of your local power supply.

About micro-USB cables

To charge, use a micro-USB cable and connect the system to:

- an AC outlet by using a commercially-available USB AC adapter (5V, at least 2A).
- a USB port of a computer.

On operation

Do not insert any small objects, etc., into the jacks or ventilation hole on the rear of the system. The system may short out or malfunction.

8. Troubleshooting

Problem	Solution
T108 will not turn on	● Make sure the T108 has sufficient charge.
Can not pair the T108 with my bluetooth device	● Please make sure that audio cable is plugged out when you are trying the bluetooth function. ● Please make sure the speaker is not connected with any other devices, (the speaker could only pair with 1 device at once) ● The T108 will be automatically connected with the last paired Bluetooth device. The best way is to disconnect the bluetooth of your other devices at first and try it again. (refer to section 4)
T108 appears on my device, but will not connect	● Please make sure the speaker is not connected with any other devices. ● Disconnect the other device from the Tranbel T108. ● Turn the T108 on and off. ● Remove the T108 from the pairing list on the device and then repair.
Could not find bluetooth driver for my Laptop	● For some older generation laptop/desktop, the bluetooth driver on the laptop/desktop might not supported. ● We are suggesting you to buy an external bluetooth USB adaptor for your computer to support bluetooth usage.
Bluetooth range is short	● For smartphone/pad, the straight line bluetooth range varies from 15-30fts depending on the bluetooth driver and OS of the paired device. ● For laptop/desktop, the bluetooth range will drop significantly depending on the bluetooth drive on the computer. ● Since bluetooth is a low power solution, obstacle between speaker and the paired device will degrade the Bluetooth range significantly.

3. Function keys

KEY	Function	Operation
	Power ON	Hold and press for 15 seconds
	Power OFF	Hold and press for 15 seconds
	Bass Volume up	Press
	Bass Volume down	Press
	Receive a Call / End a call	Press
	Last received call	Last received call Double pressing the button
	Reject a call	Hold and press for 3 seconds
	Play/Pause	Press
	Pairing mode	Hold and press for 3 seconds
	Previous track	Press
	Next track	Press

	Volume up	Press
	Volume down	Press

4. How to charge the speaker

Mode 1: Connect the 9V DC charging port with an auxiliary power adapter (recommend)

Mode 2: Use Micro USB charging line to connect 5V adapter charging (please use 5V, 2A USB wall charger.)

1> The red LED indicator light will be turned on when it is charging.

2> After the speaker being fully charged, the red LED light will be turned off automatically.

3> If the speaker is out of battery, the speaker will "beep" twice every 5 minutes to remind for a recharge.

The tranbel T108 will take 2-3 hours to be fully charged.

You can use your tranbel T108 when it is charging.

5. How to pair your bluetooth device with the Tranbel T108

1> Make sure the T108 is fully charged.

2> Make sure that the Aux cable is plugged out when you are trying the bluetooth function. If the AUX cable is plugged in, the Bluetooth function will be disabled.

3> Press the "power button" to make the Bluetooth speaker work, a blue LED light will be turned on and you can also hear a "brief message tone". And the blue LED will start flashing.

4> Turn on the bluetooth function of your smart devices/PC.

5> Search available bluetooth devices on your smart devices/PC. When the "T108" appears on the list, please select it and your device will pair, connecting with the T108.

Very few devices will request a password, if your device does, please enter "0000" (four zeros).

6> After the speaker being paired successfully, you will hear a "brief message tone" again. The blue LED will stop flashing.

7> Support bluetooth device. If the call comes, it will automatically switch to answer mode in any music mode.

IMPORTANT NOTE:

The T108 could only pair with 1 device at once. When you turn on the T108, the T108 will be automatically connected with the last paired Bluetooth device if that Bluetooth device is available and within range.

If the T108 successfully paired with the last device, it will prevent any other bluetooth device from pairing to it. The best way is to disconnect the first device from the T108 before trying to pair to another device.

6. Connecting to non-Bluetooth (AUX-IN) devices

For devices that do not have Bluetooth or support for bluetooth audio, you can connect and play music and audio by connecting your device to the AUX IN jack on the Tranbel T108 with the included 3.5mm audio cable.

1> Press the "power button" to make the bluetooth speaker work.

2> Plug one end of the 3.5 mm audio cable into the AUX IN jack on the left side of the Tranbel T108 and plug the other end into the headphone jack on your device. You can then play your music and audio on the Tranbel T108.

7. NFC connection

Tranbel T08 support using NFC connection bluetooth, connection method is as follows:

1> ensure that your device NFC is available.

2> open the phone NFC function, the phone can be connected to the NFC area near T108.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.