

Do Not Return Card



IMPORTANT



PLEASE DO NOT RETURN TO STORE

If You're Having Trouble, We're Here to Help!




Call us 24/7 at 1-855-292-4087

E-mail us at alsupport@sakar.com or visit us at alteclansing.com



WELCOME

Thank you for purchasing an Altec Lansing product. Download our App to unlock all the features our products have to offer!





JUST LISTEN.



COMFORT PRO


Active Noise Cancelling Wireless Headphones With Spatial Audio

MZX3050


QUICK START GUIDE



In the Box




**Comfort Pro Active Noise Cancelling
Wireless Headphones**



Carry Case




Quick Start Guide



USB-C Charging Cable


A Closer Look



Charging



Connect the headphones to the USB-C Charging Cable (Included) and plug the other end into a USB power port.



The Power Indicator light will illuminate red while charging.



CAUTION


Battery Warning

- This device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacture for further information.

Powering On



To power ON/OFF your headphones, press and hold the Power button for at least 3 seconds.



The Power Indicator light will flash after the headphones powers ON.

REGISTER YOUR PRODUCT

**To receive news, exclusive deals, OTA or
firmware updates, warranty information and
more please register your product at**

alteclansingsupport.com





follow us

@alteclansingofficial



follow us

#alteclansing



follow us

@alteclansingofficial

12 Month Limited Warranty

All Altec Lansing products come with
12 month limited warranty
from the date of its original purchase

24 Hour Customer Support

We love our customers, and we care
about your experience with Altec
Lansing. If you need
assistance, please call us at
1.855.292.4087


or e-mail alsupport@sakar.com
www.alteclansing.com

Altec Lansing Edison, NJ 08817



After Powering ON, your headphones will automatically go into Bluetooth pairing mode.

To connect your headphones to your smartphone, go to settings then select the Bluetooth page. Look under 'available devices' and connect to "AL Comfort Pro".



Button Functions



Volume+/Next Song Button:

- Press to increase volume.
- Press and hold to go to the next track.


Power Button:

- Press and hold for approximately 3 seconds to power on/off.
- Press to answer/end calls.
- Press and hold to reject incoming calls.
- Short press to play/pause.
- Press twice to activate voice assistant.
- Press three times for Low Latency Mode On/Off.
- Press five times to clear pairing.

Volume-/Previous Song:

- Press to decrease volume.
- Press and hold to go to the previous track.

ANC / Transparency Mode




- ANC On
- Transparency On
- ANC Off

Press the ANC button to cycle through the three available modes: ANC ON, Transparency, and ANC OFF.

Active Noise Cancelling mode cancels noise around you.


Transparency Mode turns off ANC and instead uses the microphones to amplify sound around you.

Low Latency Mode



Low Latency Mode: Press the Power Button three times to turn on/off. Low Latency Mode reduces the delay inherent in Bluetooth transmission for improved lip sync.

Spatial Audio



Press the ANC button twice to cycle through the three available Spatial Audio Modes: Spatial Audio, Head Tracking, and Sound Modes (off).

Spatial Audio uses a Head Related Transfer Function to create a 3D soundfield that surrounds you rather than coming from a straight line between Left and Right like Stereo. Most used with Music.

Headtracking adjusts the Spatial Audio based on your head movements so that the origins of sounds seem to stay fixed in the landscape when you move your head. Most used with Games.

For additional user materials and warranty information, please visit alteclansing.com

Notes



**To use voice assistant, you must have a phone that is equipped with a voice assistant.*

**You must be within Bluetooth range to use voice assistant via your headphones*

Your headphones voice assistant feature will not work if a voice assistant is not first enabled within the settings on the phone. For more information, see your phone's user manual.

For additional user materials and
warranty information, please
visit alteclansing.com

Notes

This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FOLLOW US ON



#myalteclansing