



TWS Wireless EarBuds




Model: TW93

User Manual

Overview

Chose eartips



Medium eartips fit for most of the people,
recommend to try if for the first time.

Start to Using

First use



Take out both 2 earbuds then re-insert them
back into the case to activate the earphones.


Notes: If Earbuds fail to be charged, please
charge the case via USB cable (for details,
please refer the following step)

How to pair

1. Activating the EarBuds.
2. Take out the EarBuds from the case, they will auto power on and pair with each other.
3. The LED light on one earplug will be turned off, the other earplug will automatically go into pairing mode.
4. Search for "TW76RK2" on mobile devices and tap to pair it to both EarBuds.

Resetting

Please try the following steps if fail to connect with the mobile device.



1. Turn off the two EarBuds first.
2. Tap the multi-function buttons for 10s (LED will blink red and white light then turn off).
3. The two Earbuds will be put into the charging case to activate, and take out the EarBuds from the case at the same time, they will be automatically matched.
4. The LED light on one earplug will be turned off, the other earplug will automatically go into pairing mode.
5. Search for "TW76RK2" on mobile devices and connect it with EarBuds.



Put the Earbuds into ears lightly with mic towards the front side.


Charging

a Charging the Earbuds



Insert the EarBuds into the charging case(pogo pins should be well-connected)LED light will be Red while charging and turns into White(will be last for 60s) once full charged .

b Charging the Case



The charging case supports wireless charging function (Compatible with Huawei, Samsung, Xiaomi and other Qi-certified wireless transmitters.)


Note: When charging case, one light on mean 20% power,two lights on mean 50% power,three lights on means 75%power, four lights on mean full charged.

Functions

Power-On

Method 1: Take out the EarBuds from the chargingcase, it will auto power on.


Method 2: Tap the multi-function buttons for 3s



Power-Off

Method 1: Put the EarBuds Rack into the chargingcase, it will auto power off.

Method 2: Tap the multi-function buttons for 3s



Answer/Hang up the call

Tap the multi-function button to answer the call, Tap the button again to hang up.



Decline a call

Tap the multi-function button for 1s.



Switch Audio Output

Under the calling status, Tap the multi-function button for 1s to switch audio output between cellphone and Earbuds.



Mute-on/off

Under the calling status, Tap the multi-function button twice to turn on or off the Mute function.



Play/Pause the music

Tap the multi-function button to play/pause the music.



Skip to last song

Tap the multi-function button for 3 times to play last song.



Skip to next song

Tap the multi-function button for 2 times to play next song.



Voice Assistant

Under the standby status, tap the multi-function button 2s to activate the voice assistant (eg. Siri).





Call Redial

Under the standby status , tap the multifunction button 4 times to realize the function of call redial at the end number the phone .



Model: TW93

Transmission Distance: 15 meters

Bluetooth Version: V5.0

Charging Time: about 2 hour

Talking Time: about 5 hours

Battery type :li-ion

Mode: HFP、 HSP、 A2DP、 AVRCP

Battery capacity: 50mAh

Charging Case capacity: 500mAh

Tips

- 1.Before use it, please read the user manualcarefully and keep it for future references.
- 2.It should be fully charged before first-time use.
- 3.If it is not being used for over 1 month,please charge it before use it again.
- 4.Please use the qualified adapter.
- 5.If it cannot be found by your mobile devices,please check whether it is in pairing

mode; if not pair it with mobile devices for a long time, it will exit pairing mode, please re-enter the pairing mode; if a procedure error occurs on mobile devices, please reset it; otherwise, reset the EarBuds.

Warning

1. Never disassemble or modify it to avoid causing any damages or dangers.
2. Do not store it in extreme temperatures (under 0 °C or over 45 °C)
3. Keep it away from the kids.
4. Do not use it during thunderstorms.
5. Do not use harsh chemicals or strong detergent to clean it.
6. Keep it dry.



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.