

210mm

2Boom™



JOURNEY PORTABLE WIRELESS SPEAKER

Model: BX510
Instruction Manual


Getting Started:

Remove any packing from the product.
Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents:

BX510 Speaker
USB rechargeable cable
Instruction manual
Warranty Card

Panel function:



- | | |
|---------------|-------------------|
| 1. Previous | 6. TF Card Slot |
| 2. Play/Pause | 7. Power on / off |
| 3. Next | 8. AUX IN |
| 4. Volume +/- | 9. Charging port |
| 5. Mode | 10. USB Slot |

— 2 —

Function description:

General Function description

1. Volume: Long press button +/- to adjust master volume.
2. Mode: Short press, switch to Bluetooth, USB, TF, FM and AUX-IN mode

MP3 Function description:

1. USB mode: Play music directly from flash drive with MP3, WMA format.
2. TF Card: Play music direct from TF card with MP3, WMA format.
3. Play/Pause: short press to play / pause.
4. Previous/Next: Short press for previous/next song.

FM Function Description:

1. Short press the mode button to switch FM status.
2. Long press Play/Pause button to auto search radio channels.
3. Short press Play/Pause button to mute and unmute.
4. Previous/Next Key: Short press for upwards or downwards to the existing broadcasting station.
5. Note: Please automatic searching radio when first use.

Bluetooth Function Description:

Enter to Bluetooth mode by pressing Mode button. Display will show "BLUE".
Use your Bluetooth enabled device to search "2Boom-BX510" for pairing, there will be a prompt from the speaker when the device pair successfully.

Charging and low battery Description:

Power charging is required once the battery symbol flashed which means low battery power, meanwhile, the volume will be reduced to around 70%. Use the original adapter to charge. Red light will indicate charging and will turn off once fully charged. Note: Charging time can't be less than 12 hours for the first use.

Audio Specifications:

Power Output : 15W
FR. Frequency : 90Hz~20KHz
Speaker Size : 4"40P2
S/N Ratio: 26dB
Power voltage : USB 5V
Battery: 3.7V 1200mAh
Dimension: W377*H113*D165mm

FCC ID: 2A1S7BX510

— 3 —

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or separate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.