

CROWN

JAPAN



CR-MP3003

► User Manual

► MANUAL DE USUARIO

CROWN
JAPAN

1. Messaging

You can receive and send message, and can also use broadcast message.

Message make it possible for you to exchange message With other wireless phone users. Select Message to perform operation.

1.1 Writing Message

You can write a new text message send to others, and also can insert template in the message.

Select the Option after editing a text message:

Send:	send the message only
Save and Send:	send the message while sending
Save:	save the message
Send to Many :	send the message to many
Send By Group:	send the message to all the link of the selected group

1.2 Message Setting

You can setup your MMS through the menu by your need as following:

Server Profile:	Start or edit the service, when you fail to send the MMS, please change online-pattern of the server to WAP.
Send:	Include life, send return, read return, priority etc.
Retrieve:	Include main network, roaming network, Send return, allow to sending reports etc.
Memory Status:	View the storage of the MMS.
Note:	If you fail to send MMS, please change the online-pattern to WAP in the server setting.

1.3 SMS Setting

You can setup the message from the menu, as following:

- SIM Setting:** Offer you four profiles and you can edit their names, set SC Address and Valid Period etc.
- Common Setting:** Set delivery report on or off
- Memory Status:** Check the capacity of message storage
- Preferred Storage:** Set the default message storage location, including phone storage and SIM card.
- Note:** you need support from the service provider to receiver delivery reports.

2. Call history

Enter the main menu Log, select SIM1 or SIM2 to view the dialed calls and answered calls, can also examine the call time, cost and the use of the message.

2.1 SIM 1/2 Call history

Your phone keeps lists of incoming and outgoing calls, even for calls that didn't connect. The most recent calls are listed first.

- Tip:** the phone keeps the only latest call of the same number. To view detail information or performs other operation:

Find the lists of Dialed Calls, Received Calls, Missed Calls. Press ok key to view the detail information: times etc.

Press Option key to perform following operation:

- Delete:** Delete this record.
- Save:** Save the number of this record to phone book.
- Call:** Call the number of this record.

- Send SMS:** Send message to the number of the item.
- Edit :** Enter the number edit screen, you can modify, save or dial the number.

3. Phonebook

Select contacts to open phone book.

The phone book is consisting of phone storage and SIM card storage and you can use both of them.

Phone Storage: With a name, default number, family number, company name, email address, company number, fax number, birthday date and group/individual ting in each item

SIM card Storage: The capacity depends your SIM card type and there is only a name and one business number in each item. For details, please contact your service provider.

Note: Delete the selected names one by one

3.1 Setting

You can perform bellowing operations on the phonebook:

Memory Status: Check the capacity of the phonebook, Including SIM card memory and phone memory.

Preferred Storage: Select SIM card memory or phone Memory as the default storage location when adding a new name.

Tip: You can also choose another storage location when you add a new name.

4. Setting

You can set your favorite wallpaper, ring or some other function.

4.1 SIM Setting

Enter this menu; you can set the mode to be Dual SIM, only SIM1, only SIM2, flight mode.

4.2 Network Setup

When dual SIM mode is activated, you can perform network setup for SIM1 and SIM2 separately. Enter Network Settings, select Network Setup and then you can perform following operations:

- Network:** New search, Select Network
- Selection:** Selection Mode.
- Preferences:** Set the preferred network during searching.
- Band selection:** Set the way how GPRS is connected.

4.3 Security Setup

Enter Security Settings, select Security Setup and then you can perform following operation:

- SIM Lock:** Set a password for your SIM card-open/close.
- PhoneLock:** Set a password for phone lock.
- Keypad Lock:** auto keypad lock on or off and a time after which the keypad is Locked.
- Change Password:** Change the Pin Password, Pin2 Password and Phone Lock Password.
- Note:** For Pin Password, please contact your service provider; Fixed Dial and Barred Dial must be supported by your SIM card .For details, please contact your service provider.

4.4 Call Setting

Enter call Setting form main menu, select Call Setup and then you can perform some operations as following:

- Call Waiting:** Setup the call waiting function.

Call Divert:	Setup the call diverts function.
Call Limit:	Setup the call limit function.
LineSwitch:	Switch your current line and there are 2lines Available.
Call time	Set the call time reminder on or off and its
Reminder:	type and period.
Call time	
Display:	Set if call time shows during calls or not.
Auto Redial:	Set Auto Dial on or off. While it is on, the phone automatically redials 10 times in occasion that the line is busy or cannot be answered and you can press Abort to cancel redialing.
Backlist:	Set 5 numbers, while it is on, the phone automatically shields the incoming calls from the members in blacklist.
IP Dial:	Set IP dial on or off, edit IP number.

5. Multimedia

Your phone offers multimedia applications and you can select Media from main menu to open it.

5.1 Camera

Your phone has a hi-Mega pixel camera that you can take photos whenever and wherever you like. After taking photos, store them in the phone memory or memory card (if any).

Camera Setting: Press left soft key to open Option in viewfinder display and make detail setting.

5.2 Audio player

You can use the audio player to broadcast music. Press OK key to play the current music, and press it again to pause the current music Press the

Left direction key to switch to the before, and right direction key to switch to the next. You can adjust the volume of the MP3 player through the upper direction key and down direction key.

5.3 Video Player

Tap Video Player to open it and view all video files. Press the Options and perform following operations on the selected video (play forward, details, rename, delete, delete all files or sort).

During playing, press the 4-way navigation key up and down to adjust the speed, press the left or right key to contrib. playing rate, press "0" to full screen, press #" to control volume.

5.4 Image viewer

You can perform the following operations

- | | |
|--------------------|---|
| View: | View photos |
| Forward: | Send the current photo to wallpaper list, screen saver list and power on/off display list |
| Rename: | Change name of the photo |
| Delete: | Delete the photo |
| Delete All: | Delete all photos |
| Files Sort: | Arrange the photos by name, type, time, size or random |
| Storage: | Choose photos in the phone memory or memory card. |

5.5 FM radio

Choose Radio menu to turn the radio function.

- | | |
|--------------|---|
| Note: | While tuning the radio in, you can dial or hear the call normally. When on the phone, the volume of the radio will become silence automatically |
|--------------|---|

6. File manager

Tap from the main menu to open it and you can find the storage devices and the capacity of total space and free space. On different objects, there are different operations.

7. Organizer

7.1 Calendar

7.2 Alarm

7.3 Flashlight

7.4 Tasks

7.5 Bluetooth

7.6 Calculator

8. e-Book reader

You can use e-book. Select Option and enter:

Open eBook: You can open the e-book.

Clean up Bookshelf: Cleanup the e-book catalog.

Global Setting: You can set the style, font and page of the e-book system before you read the e-book.

Book Info: There is e-book information, include the name, size and format of e-book.

Delete: You can delete this e-book.

Delete All: You can delete all e-book.

Sort: You can sort e-book by name, format, time or size.

Apply global setting: You can restore default of e-book system.

Help: You can read manual of e-book

9. Service

9.1 WAP

Your phone supports service subject to WAP .You can access the service provided by network service operator. You can acquire the information about news, weather forecast, flight, etc.

Notice: GPRS service needs the support of network.
You can enjoy it in the coverage areas of GPRS network.

Homepage: Access the Home page. Home page is your preset website of WAP If you do not set the Home Page, your phone will access the default website.

Favorites: View the bookmarks. You can select one of them to access the website.

Recent Visits: the option will record the web addresses you viewed before.

Offline page: the option will view the web addresses offline.

Input URL: This function for the input you want to connect the web site

Settings: Some settings of surfing the Internet.

1. Active Profiles: Setting parameters of visit website.

2. Options: Select the service groups and some settings of browsing websites.

3. Clear Cache: Clear cache you viewed.

4. Clear Cookie: Clear cookie the web remembered.

5. Select SIM: Select SIM 1 or SIM 2.

FCC Warning

Specific Absorption Rate (SAR) information SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this mobile phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 5mm from the body.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes

or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.