



140 Finn Court
Farmingdale, New York 11735
800.442.7787
www.andreacommunications.com
support@andreacommunications.com

Thank you for purchasing the
**Andrea Communications
BT-875 Wireless
Bluetooth® Stereo Headphones.**
We hope you enjoy them!

This instruction manual will get you started
and help you make the most
of your new headphones.

Andrea Communications BT-875 Stereo
Headphones offer clear, full-bodied sound with
wireless Bluetooth® operation.


- Pair the headphones with any Bluetooth®-capable device to listen to music wirelessly.
- Play music from a compatible Micro SD/TF card (not included) with a card slot built into the ear cup.
- Use the 3.5mm auxiliary cable (included) to listen to music on any non-Bluetooth®-enabled device.
- A convenient, built-in microphone allows for hands-free phone calls with just the touch of a button.
- Soft padded ear cushions and an adjustable headband ensure a secure and comfortable fit.
- Headphones fold for easy portability.
- Carry bag included.

WHAT'S IN THE BOX

BT-875 WIRELESS BLUETOOTH® STEREO HEADPHONES



ABOUT YOUR BT-875 HEADPHONES



1	ON/OFF Button
2	Answer/Hang Up/Reject Call
3	Pause/Resume Playback
4	Micro SD/TF Card Slot
5	Volume Down/Previous Track
6	Volume Up/Next Track
7	LED Indicator Light
8	Built-in Microphone
9	Mini USB Port
10	AUX Port

GETTING STARTED

Follow these three steps before using your headphones:

1. Charge your headphones
2. Activate Bluetooth® on your device
3. Pair your headphones to your mobile phone, tablet, or computer*

Your BT-875 is easy to operate. Several of the buttons on the headphones perform different functions, depending on how long you press them.

Instruction	Duration
Tap	Tap briefly
Press	Approx. 1 second
Press and Hold	Approx. 5 seconds

CHARGING YOUR HEADSET

To charge the Li-ion battery, simply connect the headphones to a computer using the supplied mini-USB cable.

When the LED battery indicator has a solid red light, the headphones are charging. It will take approximately two (2) hours for the battery to be fully charged.

PLEASE NOTE:

- Before using the headphones for the first time, ensure the battery is fully charged.
- To prevent the headphones from short-circuiting, avoid using them while the battery is charging.
- The lifetime of the battery will be significantly reduced if your headphones are left uncharged for a long period of time. Therefore, we recommend that you recharge your headphones at least once a month.

*The computer must have Bluetooth® capabilities. Functionality may be limited when plugged into the computer. BT-875 Headphones are not intended for voice recognition.

MODES OF OPERATION

The BT-875 has three (3) different modes of operation:

BLUETOOTH® MODE

To pair the headphones to your device:

1. Turn the BT-875 ON. A voice will tell you the current mode.
2. Your device should automatically "discover" the headphones; look for BT-875.
3. If you hear "connected," the pairing was successful; the headphones are ready to use.
4. If you pair the headphones to a mobile phone, you will be able to receive, answer, and reject calls.

PLEASE NOTE:

If too many devices are connected via Bluetooth®, it may cause interference when searching for the device during pairing.

MICRO SD/TF CARD READER MODE

The BT-875 will accept a TF/Micro SD card up to 64Gb (not included) and supports mp3 files.

1. Insert a TF or Micro SD card into the card reader slot on the ear cup.
2. Turn the BT-875 ON; if the card has loaded files, music will start playing immediately.
3. If the card is blank, the BT-875 can be used as a flash drive to load files onto the card. With power ON and TF/Micro SD card inserted, simply plug the USB cable into your computer and the headphones and load files as usual.
4. Be sure and turn the headphones OFF before removing the Micro SD card to prevent stored data from being lost or damaged.

AUX MODE

Use the supplied auxiliary cable to convert the BT-875 from wireless to wired headphones. Make sure that power button is in the OFF position. Do not install the auxiliary cable when the headphones are on. Simply plug one end of the cable into the 3.5mm AUX jack on the BT-875 and connect the other end of the cable to the AUX or Headphone port on your device. This will disable Bluetooth® functionality until the cable is unplugged.

PLEASE NOTE:

The built-in microphone will not work when the BT-875 Headphones are used in wired mode.

HOW TO USE YOUR BT-875 WIRELESS BLUETOOTH® STEREO HEADPHONES

Listening to Music

Function	Operation	Button
Volume up	Playing music	Press & Hold +» to increase volume
Volume down	Playing music	Press & Hold «• to decrease volume
Pause	Playing music	Tap ► to pause the music
Resume	Pausing	Tap ► to restart the music
Previous track	Playing music	Press the «• to go back to the previous track
Next track	Playing music	Press the +» to advance to the next track

Making a Call

Function*	Operation	Button
Answer a call	Incoming call	Tap 📞 to answer the phone
End a call	During a call	Tap 📞 again to disconnect
Reject a call	Incoming call	Press and Hold 📞 to reject a call
Volume up	During a call	Press the +» to increase volume
Volume down	During a call	Press the «• to decrease volume

* Not all mobile phones support all of these functions. Please refer to your phone's user's manual for more information.

WARNING



For your comfort, health, and safety, do not use headphones at high volumes for extended periods of time. Doing so can cause permanent hearing loss. Always listen at moderate levels. Do not use while driving, cycling, operating machinery, or during any activities that require you to hear the sounds around you.

To prevent hearing damage, it is recommended that you turn the volume all the way down before turning off the headphones. When you turn them back on, increase the volume until it reaches a comfortable and safe level.

CARE AND MAINTENANCE

Follow these recommendations to keep your BT-875 Wireless Bluetooth® Stereo Headphones working for years to come.

- DO NOT modify or attempt to repair these headphones. Doing so will void your warranty.
- DO NOT expose these headphones to liquids (including rain), moisture, or humidity.
- DO NOT expose these headphones to flammable materials or an open flame to avoid the risk of explosion.
- DO NOT use chemical cleaners on these headphones; use only a soft, dry cloth.
- When not in use, turn the headphones off and store in a cool, dry place. Extreme temperatures (below -10°C/14°F or above 45°C/113°F) can shorten battery life and may affect operation. High temperatures may also degrade performance.
- DO NOT place the headphones in direct sunlight.

TECHNICAL SPECIFICATIONS

Bluetooth Version	V4.2
Battery Capacity	300mAh
Driver Diameter	40mm
Frequency Range	20Hz-20,000Hz
Impedance	32 Ohm
Sensitivity	105B ± 3dB
Power Supply	5V DC
Receiver Distance	10m
Charging Time	1.5 hours
Standing Time	12.5 hours
Playing Time	7 hours
Talking Time	7 hours

TECHNICAL SERVICE

We hope that you enjoy your Andrea Communications BT-875 Wireless Bluetooth® Stereo Headphones.

If you have any additional questions, please visit our website at www.andreacommunications.com/support or contact our Technical Service Team via email at support@andreacommunications.com or by phone at 1.800.442.7787 (USA & Canada) for assistance.

WARRANTY INFORMATION

To learn more about our Limited Warranty, please visit our website at www.andreacommunications.com/warranty-information.

FCC INSTRUCTIONS

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the product and the receiver
- Connect the product into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference and 2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction



BT-875 BLUETOOTH HEADSET



www.andreacommunications.com