




INSTRUCTION MANUAL

Answer Phone Calls & Play Music through Bluetooth®

Bluetooth® DID: D038430
Bluetooth® QDID: 91274
FCC ID: 2AM7T-CB-335126

Bluetooth® is a registered
trademark of Bluetooth SIG, Inc.

IMPORTANT SAFETY INFORMATION:

1. Read all instructions before using this product.
2. Do not leave it unattended while charging.
3. Do not expose to water or moist environments.
4. Do not use if the item has been damaged in any way.
5. Do not expose to intense heat or cold.
6. Do not disassemble or adjust the item in any way.
7. Never dispose of batteries in the garbage.

This is unlawful under state and federal environmental laws and regulations. Always take used batteries to your local battery recycling center.

Specifications:

BT Version: 4.2 Support A2DP V1.2, AVRCPV1.4
Maximum Output: 2W
S/N ratio: >80db
Frequency Range: 160Hz-20 KHz
Battery Voltage: 3.7V DC
Distortion THD: <1%
Speaker Unit: 4ohms, 2W
Nominal Voltage: 3.7V DC
Battery: Built-in lithium battery, 3.7V DC/250mAh
Working Time: 1.5-2.5 hours (varies with volume)

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits.



Functions:

1. Speaker/Listening
2. Mode Button: press to switch between music mode & phone mode.
3. Adjust Volume/Song: Press and hold to increase the volume. Short press will skip to the next track.
4. ON/OFF Button: Long press to turn ON/OFF. Short press to play or pause the music. Incoming calls: Short press to answer. Long press to refuse it.
5. Adjust Volume/Song: Press and hold to decrease the volume. Short press will skip to the previous track.
6. LED Indicator
7. Micro USB Charging Port
8. Microphone
9. Hole for Cord

Bluetooth® Connection:

Press & hold the ON/OFF button until there is voice command & LED flashes blue. The device is ready to pair. Make sure the Bluetooth® function on your device is ON. Search for & select "Banana Phone". A voice command will state that the connection is successful. If a password is requested, use "0000".